

I n t e r n a t i o n a l   T e l e c o m m u n i c a t i o n   U n i o n

# ITU-T

TELECOMMUNICATION  
STANDARDIZATION SECTOR  
OF ITU

# G.983.2

(07/2005)

SERIES G: TRANSMISSION SYSTEMS AND MEDIA,  
DIGITAL SYSTEMS AND NETWORKS

Digital sections and digital line system – Optical line  
systems for local and access networks

---

## **ONT management and control interface specification for B-PON**

ITU-T Recommendation G.983.2

ITU-T G-SERIES RECOMMENDATIONS  
TRANSMISSION SYSTEMS AND MEDIA, DIGITAL SYSTEMS AND NETWORKS

INTERNATIONAL TELEPHONE CONNECTIONS AND CIRCUITS	G.100–G.199
GENERAL CHARACTERISTICS COMMON TO ALL ANALOGUE CARRIER-TRANSMISSION SYSTEMS	G.200–G.299
INDIVIDUAL CHARACTERISTICS OF INTERNATIONAL CARRIER TELEPHONE SYSTEMS ON METALLIC LINES	G.300–G.399
GENERAL CHARACTERISTICS OF INTERNATIONAL CARRIER TELEPHONE SYSTEMS ON RADIO-RELAY OR SATELLITE LINKS AND INTERCONNECTION WITH METALLIC LINES	G.400–G.449
COORDINATION OF RADIOTELEPHONY AND LINE TELEPHONY	G.450–G.499
TRANSMISSION MEDIA CHARACTERISTICS	G.600–G.699
DIGITAL TERMINAL EQUIPMENTS	G.700–G.799
DIGITAL NETWORKS	G.800–G.899
DIGITAL SECTIONS AND DIGITAL LINE SYSTEM	G.900–G.999
General	G.900–G.909
Parameters for optical fibre cable systems	G.910–G.919
Digital sections at hierarchical bit rates based on a bit rate of 2048 kbit/s	G.920–G.929
Digital line transmission systems on cable at non-hierarchical bit rates	G.930–G.939
Digital line systems provided by FDM transmission bearers	G.940–G.949
Digital line systems	G.950–G.959
Digital section and digital transmission systems for customer access to ISDN	G.960–G.969
Optical fibre submarine cable systems	G.970–G.979
<b>Optical line systems for local and access networks</b>	<b>G.980–G.989</b>
Access networks	G.990–G.999
QUALITY OF SERVICE AND PERFORMANCE – GENERIC AND USER-RELATED ASPECTS	G.1000–G.1999
TRANSMISSION MEDIA CHARACTERISTICS	G.6000–G.6999
DATA OVER TRANSPORT – GENERIC ASPECTS	G.7000–G.7999
ETHERNET OVER TRANSPORT ASPECTS	G.8000–G.8999
ACCESS NETWORKS	G.9000–G.9999

*For further details, please refer to the list of ITU-T Recommendations.*

# **ITU-T Recommendation G.983.2**

## **ONT management and control interface specification for B-PON**

### **Summary**

In the B-PON system defined in ITU-T Rec. G.983.1 [3] (called ATM-PON in ITU-T Rec. G.983.1), the ONTs are located at the customer site. The B-PON element management system will only manage ONTs as part of the B-PON system through the OLT using the ONT management and control interface (OMCI).

This Recommendation presents requirements for the OMCI. Firstly, it specifies managed entities of a protocol-independent Management Information Base (MIB) that models the exchange of information between the OLT and ONT, then it covers the ONT management and control channel, protocol and detailed messages. This 2nd revised version of ITU-T Rec. G.983.2 incorporates the material from G.983.2 Amendment 1 (2003), G.983.2 Amendment 2 (2005), G.983.2 Implementers' Guide (2003), G.983.6 (2002), G.983.7 (2001), G.983.8 (2003), G.983.9 (2004), G.983.10 (2004) into the base text of G.983.2 (2002). It also includes minor corrections, clarifications, and augmentation of functions.

### **Source**

ITU-T Recommendation G.983.2 was approved on 14 July 2005 by ITU-T Study Group 15 (2005-2008) under the ITU-T Recommendation A.8 procedure.

## FOREWORD

The International Telecommunication Union (ITU) is the United Nations specialized agency in the field of telecommunications. The ITU Telecommunication Standardization Sector (ITU-T) is a permanent organ of ITU. ITU-T is responsible for studying technical, operating and tariff questions and issuing Recommendations on them with a view to standardizing telecommunications on a worldwide basis.

The World Telecommunication Standardization Assembly (WTSA), which meets every four years, establishes the topics for study by the ITU-T study groups which, in turn, produce Recommendations on these topics.

The approval of ITU-T Recommendations is covered by the procedure laid down in WTSA Resolution 1.

In some areas of information technology which fall within ITU-T's purview, the necessary standards are prepared on a collaborative basis with ISO and IEC.

## NOTE

In this Recommendation, the expression "Administration" is used for conciseness to indicate both a telecommunication administration and a recognized operating agency.

Compliance with this Recommendation is voluntary. However, the Recommendation may contain certain mandatory provisions (to ensure e.g., interoperability or applicability) and compliance with the Recommendation is achieved when all of these mandatory provisions are met. The words "shall" or some other obligatory language such as "must" and the negative equivalents are used to express requirements. The use of such words does not suggest that compliance with the Recommendation is required of any party.

## INTELLECTUAL PROPERTY RIGHTS

ITU draws attention to the possibility that the practice or implementation of this Recommendation may involve the use of a claimed Intellectual Property Right. ITU takes no position concerning the evidence, validity or applicability of claimed Intellectual Property Rights, whether asserted by ITU members or others outside of the Recommendation development process.

As of the date of approval of this Recommendation, ITU had not received notice of intellectual property, protected by patents, which may be required to implement this Recommendation. However, implementors are cautioned that this may not represent the latest information and are therefore strongly urged to consult the TSB patent database.

© ITU 2006

All rights reserved. No part of this publication may be reproduced, by any means whatsoever, without the prior written permission of ITU.



# CONTENTS

	<b>Page</b>
1 Scope .....	1
2 References.....	1
3 Abbreviations.....	3
4 Reference model and terms .....	7
4.1 OMCI in ITU-T Rec. G.983.1 .....	7
4.2 ONT functions .....	9
4.3 VP and VC Mux functionality in the ONT .....	12
5 Requirements of the management interface specification .....	12
5.1 Configuration management .....	13
5.2 Fault management .....	15
5.3 Performance management .....	15
5.4 Security management .....	16
6 Protocol-independent MIB for the OMCI .....	16
6.1 Managed entities.....	17
6.2 Managed entity relation diagrams .....	23
7 MIB description.....	40
7.1 ONT equipment management.....	42
7.2 ANI management.....	59
7.3 UNI management.....	62
7.4 VP and VC MUX management.....	218
7.5 Traffic management.....	229
8 ONT Management and Control Channel (OMCC) .....	243
9 ONT management and control protocol .....	244
9.1 ONT management and control protocol cell format.....	244
9.2 Message flow control and error recovery .....	251
9.3 OMCI handling within the ONT .....	254
Annex A – Transport of video return path service.....	256
A.1 Network overview .....	256
A.2 Mode 1 STB-ONU Interface .....	257
A.3 Mode 1 ONU-network interface.....	258
A.4 Mode 2 STB-ONU interface .....	259
A.5 Mode 2 ONU-network interface.....	259
Appendix I – OMCI common mechanisms and services.....	261
I.1 Common mechanisms .....	261
I.2 Common services .....	270
I.3 Common services with PON protection .....	307
I.4 Common services with DBA support.....	316

	<b>Page</b>
Appendix II – OMCI message set.....	319
II.1    General remarks.....	319
II.2    Message layout .....	321
Appendix III – Support of F4/F5 maintenance flows in the ONT .....	351
III.1    General principle .....	351
III.2    Definition of the F4/F5 segment and end-to-end applicability .....	351
III.3    OMCI support of F4/F5 flows in the ONT.....	352
Appendix IV – Traffic management options .....	353
IV.1    Priority Queue <sub>B-PON</sub> .....	353
IV.2    Clarification of ONT functional blocks.....	354
IV.3    An example of the traffic scheduler configuration.....	355
Appendix V – MAC addresses and Ether types.....	357
Appendix VI – Transparent support of video return path service.....	358
VI.1    Network overview .....	358
BIBLIOGRAPHY .....	360

# ITU-T Recommendation G.983.2

## ONT management and control interface specification for B-PON

### 1 Scope

This Recommendation specifies the ONT Management and Control Interface (OMCI) for the B-PON system defined in ITU-T Rec. G.983.1 [3] (called ATM-PON in ITU-T Rec. G.983.1) to enable multi-vendor interoperability between the OLT and the ONT.

The OMCI specification addresses the ONT configuration management, fault management and performance management for B-PON system operation and for several services including:

- ATM adaptation layers 1, 2, and 5;
- Circuit Emulation Service;
- Ethernet services, including MAC Bridged LAN, VLAN tagging and filtering;
- Internet Protocol Routing;
- Wireless LAN (IEEE 802.11) service;
- ADSL and VDSL services;
- Voice services, including ISDN;
- Wavelength division multiplexing, including video;
- PON protection switching;
- Dynamic Bandwidth Assignment;
- Enhanced Security.

The focus of this OMCI specification is on FTTH and FTTBusiness ONTs. The Recommendation defines a protocol necessary to support the capabilities identified for these ONTs. It also allows optional components and future extensions.

### 2 References

The following ITU-T Recommendations and other references contain provisions which, through reference in this text, constitute provisions of this Recommendation. At the time of publication, the editions indicated were valid. All Recommendations and other references are subject to revision; users of this Recommendation are therefore encouraged to investigate the possibility of applying the most recent edition of the Recommendations and other references listed below. A list of the currently valid ITU-T Recommendations is regularly published. The reference to a document within this Recommendation does not give it, as a stand-alone document, the status of a Recommendation.

- [1] ITU-T Recommendation G.784 (1999), *Synchronous digital hierarchy (SDH) management*.
- [2] ITU-T Recommendation G.774 (2001), *Synchronous digital hierarchy (SDH) – Management information model for the network element view*.
- [3] ITU-T Recommendation G.983.1 (2005), *Broadband optical access systems based on Passive Optical Networks (PON)*.
- [4] ITU-T Recommendation I.321 (1991), *B-ISDN protocol reference model and its application*.
- [5] ITU-T Recommendation I.363.1 (1996), *B-ISDN ATM Adaptation Layer specification: Type 1 AAL*.

- [6] ITU-T Recommendation I.363.5 (1996), *B-ISDN ATM Adaptation Layer specification: Type 5 AAL*.
- [7] ITU-T Recommendation I.371 (2004), *Traffic control and congestion control in B-ISDN*.
- [8] ITU-T Recommendation I.610 (1999), *B-ISDN operation and maintenance principles and functions*.
- [9] ITU-T Recommendation I.751 (1996), *Asynchronous transfer mode management of the network element view*.
- [10] ITU-T Recommendation Q.824.6 (1998), *Stage 2 and stage 3 description for the Q3 interface – Customer administration: Broadband Switch Management*.
- [11] ITU-T Recommendation I.432.1 (1999), *B-ISDN user-network interface – Physical layer specification: General characteristics*.
- [12] ITU-T Recommendation I.356 (2000), *B-ISDN ATM layer cell transfer performance*.
- [13] IEEE 802.1D-2004, *Media Access Control (MAC) Bridges*.
- [14] ITU-T Recommendation I.363.2 (2000), *B-ISDN ATM Adaptation Layer specification: Type 2 AAL*.
- [15] ITU-T Recommendation I.366.1 (1998), *Segmentation and Reassembly Service Specific Convergence Sublayer for the AAL type 2*.
- [16] ITU-T Recommendation I.366.2 (2000), *AAL type 2 service specific convergence sublayer for narrow-band services*.
- [17] IETF RFC 2096 (1997), *IP Forwarding Table MIB*.
- [18] IEEE 802.1Q-2003, *Virtual Bridged Local Area Networks*.
- [19] IEEE 802.11-1999, *Standard for Information technology – Telecommunications and information exchange between systems – Local and Metropolitan Area networks – Specific requirements – Part 11: Wireless LAN Medium Access Control (MAC) and Physical Layer (PHY) specifications, Annex D*.
- [20] ITU-T Recommendation G.997.1 (2005), *Physical layer management for digital subscriber line (DSL) transceivers*.
- [21] IETF RFC 3728 (2004), *Definitions of Managed Objects for Very High Speed Digital Subscriber Lines (VDSL)*.
- [22] ITU-T Recommendation G.983.3 (2001), *A broadband optical access system with increased service capability by wavelength allocation*.
- [23] ITU-T Recommendation G.983.4 (2001), *A broadband optical access system with increased service capability using dynamic bandwidth assignment*.
- [24] ITU-T Recommendation G.983.5 (2002), *A broadband optical access system with enhanced survivability*.
- [25] SCTE 55-1 (2002), *Digital Broadband Delivery System: Out Of Band Transport Part 1: Mode A*.
- [26] SCTE 55-2 (2002), *Digital Broadband Delivery System: Out Of Band Transport Part 2: Mode B*.

### 3 Abbreviations

This Recommendation uses the following abbreviations:

AAL	ATM Adaptation Layer
ABR	Available Bit Rate
ABT/DT	ATM Block Transfer Delayed Transmission
ABT/IT	ATM Block Transfer Immediate Transmission
ADSL	Asymmetrical Digital Subscriber Line
AES	Advanced Encryption Standard
AN	Access Node
ANI	Access Node Interface
AP	Access Point
APON	ATM over Passive Optical Network
APS	Automatic Protection Switching
ARC	Alarm Reporting Control
ARP	Address Resolution Protocol
ATC	ATM Transfer Capabilities
ATM	Asynchronous Transfer Mode
ATU-C	ADSL Transceiver Unit, Central office end
ATU-R	ADSL Transceiver Unit, Remote terminal end
AVC	Attribute Value Change
BER	Bit Error Rate
BES	Block Errored Second
B-ISDN	Broadband Integrated Services Digital Network
B-PON	Broadband Passive Optical Network
BRAS	Broadband Remote Access Server
BSS	Basic Service Set
CBR	Constant Bit Rate
CCA	Clear Channel Assessment
CES	Circuit Emulation Service
CFI	Canonical Format Indicator
CFP	Contention Free Period
CLEI	Common Language Equipment Identification
CLP	Cell Loss Priority
CNR	Carrier-to-Noise Ratio
CRC	Cyclic Redundancy Check
CSO	Composite Second Order
CSS	Controlled Slip Second

CTB	Composite Triple Beat
CTP	Connection Termination Point
CTS	Clear To Send
DBA	Dynamic Bandwidth Assignment
DBR	Deterministic Bit Rate
DCF	Distributed Coordination Function
DSL	Digital Subscriber Line
DSSS	Direct-Sequence Spread Spectrum
DTIM	Delivery Traffic Indication Message
ES	Errored Second
ESS	Extended Service Set
FEC	Forward Error Correction
FHSS	Frequency-Hopping Spread Spectrum
FTTB	Fibre to the Building
FTTB <sub>Business</sub>	Fibre to the Business
FTTC	Fibre to the Curb
FTTC <sub>ab</sub>	Fibre to the Cabinet
FTTH	Fibre to the Home
GFR	Guaranteed Frame Rate
HE	Head End
HEC	Header Error Control
HN	Home Network
HOL	Head of the Line
IBSS	Independent Basic Service Set
ICMP	Internet Control Message Protocol
ICV	Integrity Check Value
IF	Interface
IP	Internet Protocol
IR	Infrared
ISDN	Integrated Services Digital Network
LAN	Local Area Network
LIM	Line Interface Module
LME	Sublayer Management Entity
LSB	Least Significant Bit
LT	Line Terminal
MAC	Media Access Control
MCM	Multiple Carrier Modulation

ME	Managed Entity
MIB	Management Information Base
MLME	MAC Layer Management Entity
MMPDU	MAC Management Protocol Data Unit
MPDU	MAC Protocol Data Unit
MSDU	MAC Service Data Unit
MSB	Most Significant Bit
MSDU	MAC Service Data Unit
MTU	Maximum Transmission Unit
NMS	Network Management System
NSCds	Number of Subcarrier – Downstream
NSCus	Number of Subcarrier – Upstream
NT	Network Terminal
OAN	Optical Access Network
ODN	Optical Distribution Network
OLT	Optical Line Terminal
OMCC	ONT Management and Control Channel
OMCI	ONT Management and Control Interface
ONT	Optical Network Terminal
ONU	Optical Network Unit
OpS	Operations System
PCF	Point Coordination Function
PHY	Physical Interface
PLCP	Physical Layer Convergence Protocol
PM	Performance Monitoring
PMD	Physical Medium Dependent
PMS-TC	Physical Media Specific – Transmission Convergence
PON	Passive Optical Network
POTS	Plain Old Telephone Service
PSD	Power Spectral Density
QoS	Quality of Service
QPSK	Quadrature Phase Shift Keying
RF	Radio Frequency
RFI	Radio Frequency Interference
RM	Resource Management
RTS	Request To Send
SBR	Statistical Bit Rate

SCM	Single Carrier Modulation
SDP	Simple Device Protocol
SDT	Structured Data Transfer
SES	Severely Errored Second
SIFS	Short Interframe Space
SME	Station Management Entity
SNI	Service Node Interface
SNR	Signal-to-Noise Ratio
SSCS	Service-Specific Convergence Sublayer
STA	Station
STB	Set Top Box
TC	Transmission Convergence
TCA	Threshold Crossing Alert
TCI	Tag Control Information
TE	Terminal Equipment
TPID	Tag Protocol Identifier
TU	Time Unit
UAS	Unavailable Seconds
UBR	Unspecified Bit Rate
UNI	User Network Interface
UPC	Usage Parameter Control
VBR	Variable Bit Rate
VC	Virtual Channel
VCC	Virtual Channel Connection
VCi	Virtual Channel Identifier
VDSL	Very High Speed DSL
VID	VLAN Identifier
VLAN	Virtual Local Area Network
VP	Virtual Path
VPC	Virtual Path Connection
VPI	Virtual Path Identifier
VRP	Video Return Path
VTU-O	VDSL Transceiver Unit, ONU end (a.k.a. VTU-C)
VTU-R	VDSL Transceiver Unit, Remote Terminal end
WEP	Wired Equivalent Privacy
WRR	Weighted Round Robin
xDSL	x Digital Subscriber Line




## 4 Reference model and terms

### 4.1 OMCI in ITU-T Rec. G.983.1

The network architecture reference model for B-PON is described in ITU-T Rec. G.983.1 [3] and shown in Figure 1. The B-PON fits various access network architectures, i.e., Fibre to the Home (FTTH), Fibre to the Building/Curb (FTTB/C) and Fibre to the Cabinet (FTTCab).

The terminology of ONT, which will be used throughout this Recommendation, is more broadly defined as an ONU used for the FTTH and Fibre to the Business (FTTBusiness) configurations. In general, the differences between FTTH and FTTBusiness are that FTTBusiness will serve more than one end user, have stricter availability requirements, and be able to afford more features and functions than FTTH. Throughout the text, with the exception of the ONT<sub>B-PON</sub> Data managed entity description, the term ONT should generally be read as implying either ONT or ONU, whichever is appropriate for the particular instance.

The OMCI specification fits into the overall G.983.1 [3] model for an access network system as illustrated in Figure 1.




G.983.2\_F01

**Figure 1/G.983.2 – Reference model**

For protected B-PON systems, three reference logical models are possible. Protected models 1 and 2 correspond to protection architectures described in ITU-T Rec. G.983.5. Protected model 3 describes an additional protection scheme option.

### 1) Protected reference model-1


In this model, the termination point of the OMCI is common between the working side and the protection side. The OMCI specifications specific to this arrangement are described in this Recommendation in 4.2.1, 7.2.3, and clause I.3.



**Figure 2/G.983.2 – Protected reference model-1**

### 2) Reference model-2


In this model, the OMCI has two distinct termination points: one for the working side and one for the protection side. The OMCI specifications are the same as those in unprotected systems, as either OMCI connection is identical to that shown in Figure 1.



**Figure 3/G.983.2 – Protected reference model-2**

### 3) Reference model-3

In this model, the OMCI has two distinct termination points: one for the working side and one for the protection side. In addition, this model includes separate ONTs for the working side and the protection side. The OMCI specifications for this model are the same as those for protected reference model 2.




**Figure 4/G.983.2 – Protected reference model-3**

## 4.2 ONT functions

As shown in Figure 5, the functions of the ONT are:

- access network line termination function (AN-LT);
- user network interface line termination function (UNI-LT), noting that in the Fibre to the Business case the UNIs from one ONT may belong to different users;
- ATM multiplexing and de-multiplexing function (ATM-Mux).




**Figure 5/G.983.2 – ONT functional diagram**

### 4.2.1 Protection switching modelling

According to ITU-T Rec. G.983.5, there are two types of protection architecture: 1+1 architecture and 1:1 architecture. Thus, two models can be considered when describing the relationship between ONT features and protection features.

### 1) 1+1 model


Figure 6 shows a 1+1 model ONT. In this model, the traffic in the working entity and the traffic in the protection entity are the same. The TC Adaptor provides the same traffic to the working PON-LT and the protection PON-LT.



**Figure 6/G.983.2 – 1+1 model ONT (ANI side)**

### 2) 1:1 model

Figure 7 shows a 1:1 model ONT. In this model, extra traffic can be supported. The working entity conveys the traffic in normal operation. If the working entity has failed, or a forced switch/manual switch to the protection entity operation has been carried out, only the protection entity conveys the traffic. The TC Adaptor for normal traffic provides the traffic to the working PON-LT when the working PON-LT is enabled. The TC Adaptor for normal traffic provides the traffic to the protection entity when the working PON-LT is disabled. The TC Adaptor for extra traffic provides the extra traffic to the protection entity only when the working entity is enabled.




**Figure 7/G.983.2 – 1:1 model ONT (ANI side)**


### 4.2.2 Dynamic bandwidth assignment modelling

A T-CONT buffer managed entity is introduced in order to specify the DBA function. T-CONT buffer can contain Priority Queues and Traffic Schedulers and be associated with the TC Adapter. Two models are considered regarding the association between the T-CONT buffers and Priority Queues or Traffic Schedulers.

In model 1, the Priority Queues, Traffic Schedulers and the T-CONT Buffers are inherently associated with each other in a fixed fashion. In model 2, the Priority Queues, Traffic Schedulers and T-CONT buffers can be associated flexibly. Figures 8 and 9 show the two models.




**Figure 8/G.983.2 – ONT model 1**



**Figure 9/G.983.2 – ONT model 2**

The simplest and default configuration is for the Priority Queues and T-CONT buffers. This can guarantee the minimum delay of traffic assuming enough bandwidth is provided for the ONT. Optionally, one or more stages of WRR and/or HOL scheduling can be installed in order to guarantee minimum bandwidths, classes of services, and other traffic controls. A multi-stage Traffic Scheduler can be implemented as shown in Figure 10 as an example.



**Figure 10/G.983.2 – ONT model with traffic scheduler**

### 4.3 VP and VC Mux functionality in the ONT

In ITU-T Rec. G.983.1 [3], the end-to-end B-PON system (i.e., OLT, ODN and ONT) can function as an ATM VP cross-connection with both provisioned and on-demand connectivity. The configuration of the ATM VP Cross-Connection can be initiated by:

- a) the network element operations system via the management interface (e.g., Q3);
- b) the Service Node (SN) over a VB5.2 Broadband Bearer Connection Control (B-BCC) protocol.

The ONT, in contrast, always acts as a provisioned ATM multiplexer. The OMCI itself does not distinguish between these two cases, because the OLT always provisions the ONT connections via the OMCI. The OLT can, however, assign different priorities to OMCI messages such that, in the case of b), a fast response time of the OMCI is achieved.

The OLT and ONT as a whole can function as a VP as well as a VC switch. The ONT itself can cross-connect traffic at the VP level or the VC level, depending upon implementation. Additionally, this choice can be different for the ATM and non-ATM UNIs. This is more fully described in 5.1.

## 5 Requirements of the management interface specification

The OMCI is used by the OLT to control an ONT. This protocol allows the OLT to:

- a) establish and release connections across the ONT;
- b) manage the UNIs at the ONT;
- c) request configuration information and performance statistics;
- d) autonomously inform the system operator of events such as link failures.

The OMCI protocol runs across an ATM connection between the OLT controller and the ONT controller that is established at ONT initialization. The OMCI protocol is asymmetric: the controller

in the OLT is the master and the one in the ONT is the slave. A single OLT controller using multiple instances of the protocol over separate control channels may control multiple ONTs.

The ONT management and control interface requirements given in this Recommendation are needed to manage the ONT in the following areas:

- a) Configuration management;
- b) Fault management;
- c) Performance management;
- d) Security management.

### **5.1 Configuration management**


Configuration management provides functions to exercise control over, identify, collect data from and provide data to the ONT. This involves the following:

- a) Configuration of equipment;
- b) Configuration of the UNIs;
- c) Configuration of the VP Network CTP<sub>B-PONS</sub> and ATM Cross-Connections;
- d) Configuration of Interworking VCC Termination Points (non-ATM UNIs only);
- e) Configuration of the OAM flows;
- f) Configuration of the physical ports;
- g) Configuration of AAL profiles;
- h) Configuration of service profiles;
- i) Configuration of traffic descriptors;
- j) Configuration of T-CONT buffers and Traffic Schedulers.

The ONT can support various cross connect and non-cross connect modes at the VP and VC level.

In cases where the ONT provides standard ATM UNI services, the ONT typically supports VP cross-connection in order to free VPI values on the UNI (the VPI value on the ANI is not free because the same VPI value cannot be assigned to different ONTs due to the specification of ITU-T Rec. G.983.1, and VP cross-connection on the ONT resolves this limitation for the UNI).

In the case of non-ATM UNI services, the VC providing the service must be terminated. To represent this, the OMCI unifies the VC termination and interworking VCCTP into the Interworking VCC Termination Point ME. Figure 11 shows the termination model. For non-ATM LIMs, the aggregate of traffic parameters for the various VC terminations is represented by the Traffic Descriptor Profile Pointer associated with the VP Network CTP that contains the VC terminations.




NOTE – VC represents unification of VCCTP and Interworking VCCTP.

**Figure 11/G.983.2 – VP cross-connection termination model**

For cases such as the support of ONUs with xDSL interfaces, it is generally necessary to implement VC cross-connections. VC cross-connection can be supported by the ONT/ONU, as indicated by the termination model shown in Figure 12.

For cases when the ONT provides no ATM interfaces, there are non-cross connected modes of operation that are available, in either the VP or VC level. However, the implementer may choose to use cross-connect modes even in this case.



**Figure 12/G.983.2 – VC cross-connection termination model**

There are eight combinations of cross-connection modes for an ONT. These are listed in Table 0. Related to this, the ONT has two traffic management modes: Priority-based, or Cell Rate-based. An ONT implementer is free to choose any cross-connect and traffic management mode combination.



**Table 0/G.983.2 – Cross-connection modes for ONTs**

Mode	ATM IF	non-ATM IF	
Value	ATM layer	Cross connection	ATM layer
0	VP	no	VP
1	VP	yes	VP
2	VP	yes	VC
3	VP	no	VC
4	VC	no	VP
5	VC	yes	VP
6	VC	yes	VC
7	VC	no	VC

## 5.2 Fault management

The ONT supports *limited* fault management only. Most of the operations are limited to failure indication. The OMCI supports failure reporting on the following managed entities that are described throughout clause 7:

- a)  $\text{ONT}_{\text{B-PON}}$ ;
- b) Subscriber Line Cardholder;
- c) Subscriber Line Card;
- d) Physical Path Termination Point ATM UNI;
- e) Physical Path Termination Point Ethernet UNI;
- f) Physical Path Termination Point CES UNI;
- g) TC Adapter $_{\text{B-PON}}$ ;
- h) Interworking VCC Termination Point;
- i) VP Network CTP $_{\text{B-PON}}$ ;
- j) Physical Path Termination Point POTS UNI;
- k) Physical Path Termination Point ADSL UNI;
- l) Physical Path Termination Point VDSL UNI;
- m)  $\text{ONU}_{\text{B-PON}}$ ;
- n) VC Network CTP $_{\text{B-PON}}$ .

An alarm table is defined for each of these entities.

The ONT shall also support selective OAM cell loop-back testing at the UNI. The ONT diagnostics are limited to the ONT self test. The OLT or element manager will process the information from the ONT; for example, the OLT will determine the severity of each alarm when reporting it to the network operator. ATM management of continuity monitoring is not a part of this Recommendation (see [B-1] and ITU-T Rec. I.751 [9]).

## 5.3 Performance management

The ONT has only *limited* performance monitoring. For the low-cost FTTH ONT, the performance monitoring is limited to PMD and TC layer performance monitoring. However, for the FTTBusiness ONT, ATM cell level protocol monitoring, traffic management and UPC disagreement monitoring may be required. The following are related managed entities:

- a) UPC Disagreement Monitoring History Data $_{\text{B-PON}}$ ;

- b) AAL 1 Protocol Monitoring History Data<sub>B-PON</sub>;
- c) AAL 5 Protocol Monitoring History Data<sub>B-PON</sub>;
- d) Ethernet Performance Monitoring History Data;
- e) CES Physical Interface Monitoring History Data;
- f) TC Adapter Protocol Monitoring History Data;
- g) AAL 2 CPS Protocol Monitoring History Data<sub>B-PON</sub>;
- h) Priority Queue<sub>B-PON</sub>;
- i) MAC Bridge PM History Data;
- j) MAC Bridge Port PM History Data;
- k) Voice PM History Data;
- l) VP PM History Data;
- m) IP Router PM History Data 1;
- n) IP Router PM History Data 2;
- o) ICMP PM History Data 1;
- p) ICMP PM History Data 2;
- q) VC PM History Data;
- r) Ethernet Performance Monitoring History Data 2;
- s) IEEE 802.11 Counters;
- t) ADSL ATU-C Performance Monitoring History Data;
- u) ADSL ATU-R Performance Monitoring History Data;
- v) ADSL ATU-C Channel Performance Monitoring History Data;
- w) ADSL ATU-R Channel Performance Monitoring History Data;
- x) TC Adaptor Performance Monitoring History Data ADSL;
- y) VDSL VTU-O Physical Interface Monitoring History Data;
- z) VDSL VTU-R Physical Interface Monitoring History Data;
- z1) VDSL VTU-O Channel Performance Monitoring History Data;
- z2) VDSL VTU-R Channel Performance Monitoring History Data;
- z3) AAL 2 SSCS Protocol Monitoring History Data<sub>B-PON</sub>.

Note that it is not required to upload all the performance monitoring-related managed entities during the MIB upload (see 7.1.2). Furthermore, all PM objects are created at the request of the OLT.

All the history data shall be maintained in the OLT. ATM management of performance monitoring is not a part of this Recommendation (see [B-1] and ITU-T Rec. I.751 [9]).

## 5.4 Security management

There are no security features of the OMCI.

## 6 Protocol-independent MIB for the OMCI

The OMCI should be defined to allow vendors to offer modular, incremental capabilities to meet different levels of customer needs. This Recommendation first targets FTTH and FTTBusiness ONTs. It defines a protocol necessary to support capabilities identified by ITU-T Rec. G.983.1 [3]. It is important for early deployment and interoperability, yet it allows for optional components and future extensions.

A protocol-independent MIB is used to describe the exchange of information across the OMCI and forms the basis from which protocol-specific models (e.g., Simple Device Protocol for the ONT) are defined. This MIB has as much commonality as possible with the related generic MIB as defined in other ITU-T Recommendations. It is intended to make the OMCI relatively simple while maintaining consistency with the MIB used by the interface between the network-element manager and the OLT.

## 6.1 Managed entities

The protocol-independent MIB presented in this Recommendation has been defined in terms of *managed entities*. The managed entities are abstract representations of resources and services in an ONT.

This Recommendation uses three levels for indicating the degree of compliance necessary for specific functions and managed entities associated with the OMCI specification:

- **Requirement (R):** Entities necessary for operational compatibility;
- **Conditional Requirements (CR):** Entities necessary when the specified optional function is implemented;
- **Option (O):** Entities that may be useful and required by an operator but that are not necessary for operational compatibility.

The possible managed entities are listed in Table 1.

**Table 1/G.983.2 – Managed entities in the OMCI**

Managed entity	Required/ Optional	Description	Defined in clause
802.1p Mapper Service Profile	O	Used to define mapping of 802.1 frames to VCC TPs based on 802.1p priority bits	7.3.95
802.11 Counters	O	Used for IEEE 802.11 interface supported by the ONT	7.3.61
802.11 General Purpose Object	CR	Used for IEEE 802.11 interface supported by the ONT	7.3.59
802.11 MAC&PHY Operation and Antenna Data	CR	Used for IEEE 802.11 interface supported by the ONT	7.3.60
802.11 PHY FHSS DSSS IR Tables	O	Used for IEEE 802.11 interface supported by the ONT	7.3.62
802.11 Station Management data 1	CR	Used for IEEE 802.11 interface supported by the ONT	7.3.57
802.11 Station Management data 2	CR	Used for IEEE 802.11 interface supported by the ONT	7.3.58
802.1p Mapper Service Profile	CR	Used for 802.1p Priority Mapping of data interfaces	7.3.95
AAL 1 Profile <sub>B-PON</sub>	CR	Used when the ONT supports CES UNIs	7.3.8
AAL 1 Protocol Monitoring History Data <sub>B-PON</sub>	O	Used when AAL 1 layer performance monitoring is supported	7.3.9
AAL 2 CPS Protocol Monitoring History Data <sub>B-PON</sub>	O	Used when AAL 2 layer performance monitoring is supported	7.3.20
AAL 2 Profile <sub>B-PON</sub>	CR	Used when the ONT supports AAL 2	7.3.18
AAL 2 PVC Profile <sub>B-PON</sub>	CR	Used when the ONT supports AAL 2 PVC	7.3.19

**Table 1/G.983.2 – Managed entities in the OMCI**

<b>Managed entity</b>	<b>Required/ Optional</b>	<b>Description</b>	<b>Defined in clause</b>
AAL 2 SSCS Parameter Profile 1	CR	Used when the ONT supports AAL 2 SSCS	7.3.22
AAL 2 SSCS Parameter Profile 2	CR	Used when the ONT supports AAL 2 SSCS	7.3.23
AAL 2 SSCS Protocol Monitoring History Data <sub>B-PON</sub>	CR	Used when AAL 2 layer performance monitoring is supported	7.3.21
AAL 5 Profile <sub>B-PON</sub>	CR	Used when the ONT supports LAN UNIs	7.3.10
AAL 5 Protocol Monitoring History Data <sub>B-PON</sub>	O	Used when AAL 5 layer performance monitoring is supported	7.3.11
ADSL ATU-C Channel Performance Monitoring History Data	O	Performance monitoring data for an ADSL ATU-C channel	7.3.79
ADSL ATU-C Performance Monitoring History Data	O	Performance monitoring data for an ADSL ATU-C modem Path	7.3.77
ADSL ATU-R Channel Performance Monitoring History Data	O	Performance monitoring data for an ADSL ATU-R Channel	7.3.80
ADSL ATU-R Performance Monitoring History Data	O	Performance monitoring data for an ADSL ATU-R modem path	7.3.78
ADSL Channel Configuration Profile	CR	Contains Configuration for a Channel	7.3.72
ADSL Channel Downstream Status Data	CR	Contains status on the Downstream Channel	7.3.67
ADSL Channel Upstream Status Data	CR	Contains status on the Upstream Channel	7.3.68
ADSL Downstream PSD Mask Profile	CR	Contains Masking information for the Downstream PSD	7.3.75
ADSL Downstream RFI Bands Profile	CR	Contains information on the Downstream RFI Bands	7.3.76
ADSL Line Configuration Profile Part 1	CR	Contains the Line Parameters for an ADSL line	7.3.69
ADSL Line Configuration Profile Part 2	CR	Contains the Line Parameters for an ADSL line	7.3.70
ADSL Line Configuration Profile Part 3	CR	Contains the Line Parameters for an ADSL line	7.3.71
ADSL Line Inventory and Status Data Part 1	CR	Contains the inventory and status information on the ADSL Line	7.3.65
ADSL Line Inventory and Status Data Part 2	CR	Contains the inventory and status information on the ADSL Line	7.3.66
ADSL Subcarrier Masking Downstream Profile	CR	Contains masking information for the Downstream subcarriers	7.3.73
ADSL Subcarrier Masking Upstream Profile	CR	Contains masking information for the Upstream subcarriers	7.3.74

**Table 1/G.983.2 – Managed entities in the OMCI**

<b>Managed entity</b>	<b>Required/ Optional</b>	<b>Description</b>	<b>Defined in clause</b>
ANI	O	PON IF, description purposes only, see clause 7.2 (ANI Management)	7.2.2
ARP Configuration Data	CR	Used for IP Port supported by the ONT	7.3.47
ARP Service Profile	CR	Used for IP Port supported by the ONT	7.3.46
ATM VC Cross-Connection	O	Used for VC multiplexing with VCI translation in the ONU	7.4.5
ATM VP Cross-Connection	CR	Used for VP multiplexing with VPI translation in the ONT	7.4.2
CES Physical Interface Monitoring History Data	O	Used for the CES interface performance monitoring	7.3.15
CES Service Profile <sub>B-PON</sub>	CR	Used for CES services supported by the ONT	7.3.12
Ethernet Performance Monitoring History Data	O	Used for Ethernet interface performance monitoring	7.3.14
Ethernet Performance Monitoring History Data 2	O	Used for Ethernet performance monitoring	7.3.55
ICMP PM History Data 1	O	Used for ICMP performance monitoring	7.3.42
ICMP PM History Data 2	O	Used for ICMP performance monitoring	7.3.43
Interworking VCC Termination Point	CR	Used for non-ATM UNIs	7.3.7
IP Port Configuration Data	CR	Used for IP Port supported by the ONT	7.3.37
IP Route Table	CR	Used for IP Router supported by the ONT	7.3.44
IP Router Configuration Data	CR	Used for IP Router supported by the ONT	7.3.39
IP Router PM History Data 1	O	Used for IP Router performance monitoring	7.3.40
IP Router PM History Data 2	O	Used for IP Router performance monitoring	7.3.41
IP Router Service Profile	CR	Used for IP Router supported by the ONT	7.3.38
IP Static Routes	CR	Used for IP Router supported by the ONT	7.3.45
LES Service Profile	CR	Used for LES services supported by the ONT	7.3.25
Logical N × 64 kbit/s Sub-port Connection Termination Point	CR	Used as logical interface for structured CES	7.3.4
MAC Bridge Configuration Data	CR	Used for MAC bridge supported by the ONT	7.3.30
MAC Bridge PM History Data	O	Used for MAC bridge performance monitoring	7.3.35
MAC Bridge Port Bridge Table Data	CR	Used for MAC bridge supported by the ONT	7.3.34
MAC Bridge Port Configuration Data	CR	Used for MAC bridge supported by the ONT	7.3.31
MAC Bridge Port Designation Data	CR	Used for MAC bridge supported by the ONT	7.3.32

**Table 1/G.983.2 – Managed entities in the OMCI**

<b>Managed entity</b>	<b>Required/ Optional</b>	<b>Description</b>	<b>Defined in clause</b>
MAC Bridge Port Filter Preassign Table	O	Used for Ether type filtering	7.3.51
MAC Bridge Port Filter Table Data	CR	Used for MAC bridge supported by the ONT	7.3.33
MAC Bridge Port PM History Data	O	Used for MAC bridge port performance monitoring	7.3.36
MAC Bridge Service Profile	CR	Used for MAC bridge supported by the ONT	7.3.29
Multicast Interworking VCC Termination Point	CR	Used to manage multicasting support	7.3.97
OLT <sub>B-PON</sub>	O	Used for OLT identification for interoperability facilitation	7.3.96
ONT Data	R	Used for OMCI MIB management	7.1.2
ONT <sub>B-PON</sub>	R	Used for ONT equipment management	7.1.1
ONU <sub>B-PON</sub>	O	Used for ONU equipment management	7.1.8
Physical Path Termination Point 802.11 UNI	CR	Used for IEEE 802.11 interface supported by the ONT	7.3.56
Physical Path Termination Point ADSL UNI Part 1	CR	Used for the physical path termination point at an ADSL CO modem	7.3.63
Physical Path Termination Point ADSL UNI Part 2	CR	Used for the physical path termination point at an ADSL CO modem	7.3.64
Physical Path Termination Point ATM UNI	CR	Used for physical path termination point at the ATM UNI	7.3.1
Physical Path Termination Point CES UNI	CR	Used for physical path termination point at the CES UNI	7.3.3
Physical Path Termination Point Ethernet UNI	CR	Used for physical path termination point at the Ethernet UNI	7.3.2
Physical Path Termination Point ISDN UNI	O	Used for ISDN port supported by the ONT	7.3.48
Physical Path Termination Point LCT UNI	O	Used for local craft terminal port	7.3.54
Physical Path Termination Point POTS UNI	CR	Used for physical path trail termination point at the POTS UNI	7.3.26
Physical Path Termination Point VDSL UNI	CR	Used for the physical path termination point at a VDSL connection	7.3.82
Physical Path Termination Point Video ANI	O	Used for video input port	7.3.53
Physical Path Termination Point Video UNI	O	Used for video port	7.3.52
PON IF Line Card	CR	Used for the PON line card plug-in, only used if PON interface is implemented on a plug-in unit	7.1.6

**Table 1/G.983.2 – Managed entities in the OMCI**

<b>Managed entity</b>	<b>Required/ Optional</b>	<b>Description</b>	<b>Defined in clause</b>
PON IF Line Cardholder	CR	Used for the PON line card plug-in slot, only used if PON interface is implemented on a plug-in unit	7.1.5
PON Physical Path Termination Point	O	Used for physical path at the ANI, description purpose only, see 7.2 (ANI Management)	7.2.1
PON TC Adapter	O	Used for TC layer at PON interface, description purpose only, see 7.2 (ANI Management)	7.2.3
Priority Queue <sub>B-PON</sub>	CR	Used for ONTs that support priority queues to multiplex ATM traffic flows	7.5.1
Software Image	R	Used for the software image of the ONT. Software image for the subscriber line cards is optional	7.1.7
Subscriber Line Card	CR (Note)	Used for the UNI line card plug-in	7.1.4
Subscriber Line Cardholder	CR (Note)	Used for the UNI line card plug-in slot	7.1.3
TC Adapter Protocol Monitoring History Data	O	Used when TC layer performance monitoring is supported	7.3.16
TC Adapter <sub>B-PON</sub>	CR	Used for TC layer at the UNI side for the ATM UNI	7.3.6
TC Adaptor Performance Monitoring History Data ADSL	O	Performance monitoring data for the ADSL ATM Data Path	7.3.81
T-CONT Buffer	CR	Used when one or more T-CONT buffers are supported.	7.2.4
Threshold Data <sub>B-PON</sub>	CR	Used for the set-up of threshold values	7.3.17
Traffic Descriptors	CR	Used for the ONT that supports traffic shaper to specify ATM layer traffic characteristics in the case of accommodation of non-ATM UNI. Moreover, in the case of accommodation of ATM UNI, Traffic Descriptors may be used for the UPC function in the ONT, if it is required.	7.5.2
Traffic Scheduler	CR	Used when Traffic Scheduler is used.	7.5.5
UNI <sub>B-PON</sub>	R	User network interface	7.3.5
UPC Disagreement Monitoring History Data <sub>B-PON</sub>	CR	Used for the ONT that supports UPC	7.5.4
VC Network CTP <sub>B-PON</sub>	O	Used for VC link termination in the VC MUX	7.4.4
VC PM History Data	O	Used for VC performance monitoring	7.4.6
VDSL Band Plan Configuration Profile	CR	Parameters used to configure a VDSL Band Plan Configuration Profile.	7.3.88
VDSL Channel Configuration Profile	CR	Parameters used to configure a VDSL Channel Configuration Profile	7.3.87


**Table 1/G.983.2 – Managed entities in the OMCI**

<b>Managed entity</b>	<b>Required/ Optional</b>	<b>Description</b>	<b>Defined in clause</b>
VDSL Channel Data	CR	Contains the Channel Parameters for VDSL Fast and Slow channels	7.3.85
VDSL Line Configuration Profile	CR	Parameters used to configure a VDSL Line Configuration Profile	7.3.86
VDSL VTU-O Channel Performance Monitoring History Data	O	Performance monitoring data for a VDSL VTU-O channel	7.3.91
VDSL VTU-O Physical Data	CR	Contains the Physical Layer Parameters for a VTU-O	7.3.83
VDSL VTU-O Physical Interface Monitoring History Data	O	Monitoring Data for a VDSL VTU-O Physical Interface	7.3.89
VDSL VTU-R Channel Performance Monitoring History Data	O	Performance monitoring data for an VDSL VTU-R channel	7.3.92
VDSL VTU-R Physical Data	CR	Contains the Physical Layer Parameters for a VTU-R	7.3.84
VDSL VTU-R Physical Interface Monitoring History Data	O	Monitoring Data for a VDSL VTU-R Physical Interface	7.3.90
Video Return Path Service Profile	CR	Used for Video Return Path service	7.3.93
Video Return Path Statistics	O	Used for Video Return Path service	7.3.94
VLAN Tagging Filter Data	O	Used for VLAN tagging	7.3.50
VLAN Tagging Operation Configuration Data	O	Used for VLAN tagging	7.3.49
Voice CTP	CR	Used for Voice termination point supported by the ONT	7.3.27
Voice PM History Data	O	Used for voice performance monitoring	7.3.28
Voice Service Profile AAL	CR	Used for AAL Voice services supported by the ONT	7.3.24
VP Network CTP <sub>B-PON</sub>	R	Used for the VP link termination in the VP Mux	7.4.1
VP PM History Data	O	Used for VP performance monitoring	7.4.3
NOTE – The preferred solution is that the Subscriber Line Card and Subscriber Line Cardholder managed entities should always be modelled, regardless of whether or not the ONT has integrated interfaces; however, for reasons of backward compatibility, these managed entities remain as "CR."			



## 6.2 Managed entity relation diagrams

The relationships between the required managed entities are given in Figures 13 to 31. Figure 13 gives the legend of symbols used in these diagrams. Note that the Threshold Data<sub>B-PON</sub> managed entity may be associated with any managed entity that has thresholded counters. This is indicated by a special symbol to reduce congestion on the figures. Also note that several managed entities in the figures are optional or conditionally required; hence, they may not be used in some implementations.




**Figure 13/G.983.2 – Legend for managed entity relation diagrams**




Figure 14 shows an ONT with cardholders on both UNI and ANI side (an ONT with integrated interfaces on the UNI and/or ANI side can be modelled by Figure 14 as well, since integrated interfaces use "pseudo" Subscriber Line Cards and Cardholders). Note that extensions of Figure 14 are possible as well, e.g., an ONT with several Subscriber Line Cardholders on the UNI side and one integrated PON interface.

As for the ATM functions, there are 12 possible models allowed for ONTs: with four models for the ATM interfaces, and eight models for the non-ATM interfaces. The six VP models are illustrated in Figures 15 to 20. It should be noted that in each diagram, the term "VP" can be replaced with "VC", to produce the VC model.




G.983.2\_F15

**Figure 15/G.983.2 – Managed entity relation diagram for ATM interfaces with VP level cross-connections and priority queue-based traffic management**




**Figure 16/G.983.2 – Managed entity relation diagram for ATM interfaces with VP level cross-connections and cell rate-based traffic management**




G.983.2\_F17

**Figure 17/G.983.2 – Managed entity relation diagram for non-ATM interfaces with VP level cross-connections and priority queue-based traffic management**




G.983.2\_F18

**Figure 18/G.983.2 – Managed entity relation diagram for non-ATM interfaces with VP level cross-connections and cell rate-based traffic management**



G.983.2\_F19

**Figure 19/G.983.2 – Managed entity relation diagram for non-ATM interfaces with VP level non-cross-connect and priority queue-based traffic management**




G.983.2\_F20

**Figure 20/G.983.2 – Managed entity relation diagram for non-ATM interfaces with VP level non-cross-connect and cell rate-based traffic management**




Figures 21 to 31 show the relation diagrams for the non-ATM interfaces supported to date in the OMCI. Please note that the Interworking VCC TP managed entity is common between Figures 17 to 20 and between Figures 21 to 31. The diagrams are partitioned in this way for brevity and clarity.




G.983.2\_F21

Figure 21/G.983.2 – Managed entity relation diagram for MAC Bridged LAN interfaces




G.983.2\_F22

Figure 22/G.983.2 – Managed entity relation diagram for IP router interfaces




G.983.2\_F23

**Figure 23/G.983.2 – Managed entity relation diagram for structured CES interfaces**




**Figure 24/G.983.2 – Managed entity relation diagram for unstructured CES interfaces**



G.983.2\_F25


**Figure 25/G.983.2 – Managed entity relation diagram for AAL 2-based voice interfaces**




G.983.2\_F26

**Figure 26/G.983.2 – Managed entity relation diagram for AAL 1-based voice interfaces**






**Figure 28/G.983.2 – Managed entity relation diagram for VDSL interfaces**




**Figure 29/G.983.2 – Managed entity relation diagram for IEEE 802.11 interfaces**





G.983.2\_F30

**Figure 30/G.983.2 – Managed entity relation diagram for video interfaces, including the optional video return path function**



G.983.2\_F31

**Figure 31/G.983.2 – Managed entity relation diagram for 802.1p mapper interfaces**

## 7 MIB description

A detailed description of all ONT managed entities is provided in the clauses that follow. The descriptions include:

- the purpose of the entity;
- the relationship(s) that the entity supports with other managed entities;
- the attributes of the entity;

- d) the management operations that may be performed on the entity;
- e) the notifications generated by the managed entity.

These clauses are organized as follows:

- a) ONT equipment management;
- b) ANI (i.e., PON IF) management;
- c) UNI management;
- d) VP layer management;
- e) traffic management.

A managed entity can be instantiated by the ONT autonomously or on explicit request of the OLT via a create command.

Attributes of a managed entity for which no create action exists (i.e., a managed entity which is auto-instantiated by the ONT) can be (R), (W), or (R, W). On the other hand, attributes of a managed entity for which a create action exists (i.e., a managed entity which is instantiated on explicit request by the OLT) can be either (R), (W), (R, W), (R, Set-by-create), (W, Set-by-create), or (R, W, Set-by-create). For attributes that are not "Set-by-create", a default value will be specified in this Recommendation which will be assigned to the attribute on instantiation of the managed entity.

The following gives a more detailed explanation for each of the possible cases:

- (R): On instantiation of the managed entity (either autonomously or on request of the OLT via a create action), the ONT sets the attribute to a default value. The OLT can only read the value of the attribute. In case of an autonomous attribute value change, the ONT will send an attribute value change notification to the OLT.
- (W): On instantiation of the managed entity (either autonomously or on request of the OLT via a create action), the ONT sets the attribute to a default value. The OLT can only write the value of the attribute. In case of an autonomous attribute value change, the ONT will NOT send an attribute value change notification to the OLT.
- (R, W): On instantiation of the managed entity (either autonomously or on request of the OLT via a create action), the ONT sets the attribute to a default value. The OLT can both read and write the value of the attribute. In case of an autonomous attribute value change, the ONT will send an attribute value change notification to the OLT.
- (R, Set-by-create): On instantiation of the managed entity (by necessity on request of the OLT via a create action), the ONT sets the attribute to the value specified in the create command. Subsequently, the OLT can only read the value of the attribute. In case of an autonomous attribute value change, the ONT will send an attribute value change notification to the OLT.
- (W, Set-by-create): On instantiation of the managed entity (by necessity on request of the OLT via a create action), the ONT sets the attribute to the value specified in the create command. Subsequently, the OLT can only write the value of the attribute. In case of an autonomous attribute value change, the ONT will NOT send an attribute value change notification to the OLT.
- (R, W, Set-by-create): On instantiation of the managed entity (by necessity on request of the OLT via a create action), the ONT sets the attribute to the value specified in the create command. Subsequently, the OLT can both read and write the value

of the attribute. In case of an autonomous attribute value change, the ONT will send an attribute value change notification to the OLT.

In all bit vectors indicated in this Recommendation, bit 1 represents the least significant bit, while bit 8 represents the most significant bit within a byte. If the bit vector is made up of more than one byte, then the numbering starts from the least significant byte onwards.

In all attribute descriptions that refer to the Boolean values "true" and "false", true will be coded as 0x01 and false will be coded as 0x00.

In all attribute descriptions that refer to spaces, the value 0x20 must be used for the entire size of the attribute.

The notifications generated by a managed entity stem from the following events: Alarms, Attribute Value Changes (AVCs), Threshold Crossing Alerts (TCAs), and Test results. Alarms, TCAs, and failures of autonomous self tests are all reported via "Alarm" messages. AVCs are reported via "Attribute Value Change" messages. Test results are reported:

- a) via a "Test result" message if the test is invoked by a "Test" command from the OLT;
- b) via an "Alarm" message in the case of failure of an autonomous self test (in start-up phase). Details about these messages and the related coding are in Appendix II.

## 7.1 ONT equipment management

### 7.1.1 ONT<sub>B-PON</sub>

This managed entity represents the ONT as equipment.

An instance of this managed entity is automatically created by the ONT after initialization. After the creation of this managed entity, the associated attributes are updated according to the data within the ONT itself.

#### *Relationships*

All other managed entities in this Recommendation are related directly or indirectly to the ONT<sub>B-PON</sub> entity.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. There is only one instance and it has the number 0x0000. (R) (mandatory) (2 bytes)

**Vendor id:** This attribute identifies the vendor of the ONT, and is the same as the 4 most significant bytes of the ONT serial number as specified in ITU-T Rec. G.983.1. Upon autonomous instantiation, this attribute consists of all spaces. (R) (mandatory) (4 bytes)

**Version:** This attribute identifies the version of the ONT as defined by the vendor. The printable value of "0" shall be used when version information is not available or applicable to the ONT being represented. Upon autonomous instantiation, this attribute consists of all spaces. (R) (mandatory) (14 bytes)

**Serial Number:** The serial number is unique for each ONT. Note that the serial number of the ONT is already defined in ITU-T Rec. G.983.1 [3] and contains the vendor id and/or the version number. The first four bytes are the ASCII encoded vendor ID four letter mnemonic. The second four bytes are a binary encoded 'serial number', under the complete control of the vendor in question. Upon autonomous instantiation, this attribute consists of all zeroes. (R) (mandatory) (8 bytes)

**Traffic management option:** This attribute identifies the upstream traffic management function implemented in the ONT. There are two options:

- 1) "Priority controlled upstream traffic" (0x00): the upstream traffic coming from the user is given a priority.
- 2) "Cell rate controlled upstream traffic" (0x01): the maximum upstream traffic of each individual connection is guaranteed.

Note that the Traffic management option will not apply to downstream traffic. In other words, there is no need for a traffic descriptor for the downstream direction and downstream priority queues can be used. Upon autonomous instantiation, this attribute is set to the value that describes the ONT's implementation. The OLT must adapt its model to conform to the ONT's selection. (R) (mandatory) (1 byte)

**VP/VC cross-connection function option:** This attribute identifies the support of ATM VP or VC cross-connection management functions for the interworking connections to non-ATM UNIs. The value is set according to Table 0. Upon autonomous instantiation, this attribute is set to the value that describes the ONT's implementation. The OLT must adapt its model to conform to the ONT's selection. (R) (mandatory) (1 byte)

**Battery backup:** This attribute provides a Boolean indication of whether or not the ONT supports battery backup. False will indicate that no battery is provisioned; true indicates that a battery is provisioned. Upon autonomous instantiation, this attribute is set to false. (R, W) (mandatory) (1 byte)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) the functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not a managed entity is capable of performing its task. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**Equipment id:** This attribute may be used to identify the specific type of ONT. In North America, this may be used for the equipment CLEI code. Upon autonomous instantiation, this attribute consists of all spaces. (R) (optional) (20 bytes)

**OMCC Version:** This attribute is used to identify the specific version of the OMCC protocol being used by the ONT. This is used to allow the OLT to manage a network with ONTs that support different OMCC versions. Valid values include 0x00 (2000 version), 0x01 (2002 version), and 0x02 (2005 version). Future versions will be added sequentially. Default value is 0x00. (R) (optional) (1 byte)

**Vendor Product Code:** This attribute is used to provide a vendor-specific product code for the ONT. Upon autonomous instantiation, this attribute consists of all spaces. (R) (optional) (2 bytes)

**Security Capability:** This attribute is used to advertise the advanced security modes of the ONT. The following codepoints are defined:

- 0: No extra security features are supported;
- 1: AES encryption of the downstream payload is supported;
- 2..255: Reserved for future use.

Upon autonomous instantiation, this attribute will be set to zero. (R) (optional) (1 byte)

**SecurityMode:** This attribute is used to select the advanced security mode for the ONT. Note that all secure VPs in an ONT must use the same security mode at any time. The following codepoints are defined:

- 0: Churning algorithm will be used;
- 1: AES algorithm will be used;
- 2..255: Reserved for future use.

Upon autonomous instantiation, this attribute will be set to zero. (R, W) (optional) (1 byte)

**Total T-CONT buffer number:** This attribute provides a total number of T-CONT buffers, which are not associated with the PON IF line card. Upon autonomous instantiation, this attribute will be set to zero. (R) (mandatory if DBA supported) (1 byte)

**Total Priority Queue number:** This attribute provides a total number of priority queues, which are not associated with the PON IF line card. Upon autonomous instantiation, this attribute will be set to zero. (R) (mandatory if DBA supported) (1 byte)

**Total Traffic Scheduler number:** This attribute provides a total number of Traffic Schedulers, which are not associated with the PON IF line card. The ONT supports NULL function, HOL (Head Of the Line) scheduling and WRR (Weighted Round Robin) from the priority control and guarantee of minimum rate control points of view, respectively. If the ONT does not have any Traffic Scheduler, this attribute should be 0x00. Upon autonomous instantiation, this attribute will be set to zero. (R) (mandatory if DBA supported) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Reboot:** Reboot the ONT.

**Test:** This action is used to initiate an ONT self test. Test outcome is "Pass" or "Fail".

**Synchronize Time:** This action is used to synchronize the start time of all Monitoring managed entities of the ONT with the reference time of the OLT and to reset the registers of the Monitoring managed entities. The effect of this action is that all counters of all Monitoring managed entities are set to 0x00 and restart counting. Also, the value of the Interval End Time attribute of the Monitoring managed entities is set to 0x00 and restarts counting.

Note that no other OMCI action has the same effect: synchronization of the start time is not guaranteed at start-up or after a MIB reset command (optional).

#### *Notifications*

**Attribute value change:** This notification is used to report autonomous changes to the attributes of this managed entity. The attribute value change notification shall identify the attribute changed and its new value. The list of AVCs for this managed entity is given in Table 2a.

**Alarm:** This notification is used to notify the managed system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 2b.

**Test result:** For the "Test result" event, notification is sent to the OLT via an alarm ONLY if the ME fails the autonomous self test.

**Table 2a/G.983.2 – AVC list for ONT<sub>B-PON</sub>**

Number	Attribute value change	Description
1-7	N/A	
8	OpState	Operational state of ONT <sub>B-PON</sub>
9-16	Reserved	

**Table 2b/G.983.2 – Alarm list for ONT<sub>B-PON</sub>**

Number	Event	Description
	Alarm	
0	EquipmentAlarm	A functional failure on an internal interface
1	PoweringAlarm	Loss of external power
2	BatteryMissing	Battery is provisioned but missing
3	BatteryFailure	Battery is provisioned and present but cannot recharge
4	BatteryLow	Battery is provisioned and present but its voltage is too low
5	PhysicalIntrusionAlarm	Applies if the ONT is supported with detection such as door or box open
	Test result	
6	ONTSelfTestFailure	ONT has failed autonomous self test
7	DyingGasp	ONT is powering off imminently
8-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.1.2 ONT data

This managed entity is contained in the ONT managed entity and is used to model the MIB itself. Clause I.1.2 explains the use of this managed entity with respect to MIB synchronization. Clause I.1.4 explains the alarm synchronization process, also issued on this managed entity.

An instance of this managed entity is automatically created by the ONT after initialization. After the creation of this managed entity, the associated attributes are updated according to the data within the ONT itself.

#### *Relationships*

One instance of this managed entity is contained in the instance of the ONT managed entity.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. There is only one instance and it has the number 0x0000. (R) (mandatory) (2 bytes)

**MIB data sync:** This attribute is used to check the alignment of the MIB of the ONT with the corresponding MIB within the OLT. MIB data sync is a "sequence number" checked by the OLT to see if the MIB snapshots for the OLT and ONT have the same sequence number. Refer to I.1.1 for a detailed description of this attribute. Upon autonomous instantiation, this attribute is set to 0x00. (R, W) (mandatory) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get all alarms:** Latch a snapshot (i.e., copy) of the current alarm statuses of all managed entities and reset the alarm message counter.

**Get all alarms next:** Get the latched alarm status of the next managed entity within the current snapshot.

**MIB reset:** Reset the MIB data sync attributes to 0x00 and reset the MIB of the ONT to its default state. This default MIB consists of one instance of the ONT<sub>B-PON</sub> managed entity, one instance of the ONT Data managed entity, two instances of the Software Image managed entity, zero or more instances of the Subscriber Line Cardholder managed entity, zero or more instances of the PON IF Line Cardholder, and zero or more instances of the Priority Queue<sub>B-PON</sub> managed entity (for the priority queues that reside in the ONT).

**MIB upload:** Latch a snapshot (i.e., copy) of the current MIB.

**MIB upload next:** Get the latched attribute values of the managed entity within the current snapshot.

### *Notifications*

None.

### **7.1.3 Subscriber line cardholder**

This managed entity represents the slots of the ONT that are capable of holding Subscriber Line Cards. One or more of these entities are contained in the ONT. Each Subscriber Line Cardholder can contain 0 or 1 subscriber Linecard.

An instance of this managed entity shall exist for each slot. Instances of this managed entity are created automatically by the ONT after the ONT initialization. After the creation of this managed entity, the associated attributes are updated according to the data within the ONT itself.

Instances of this managed entity are also created for ONTs with integrated interfaces on the UNI side. They then represent virtual Subscriber Line Cardholders.

### *Relationships*

An instance of the Subscriber Line Cardholder may contain instances of the Subscriber Line Card managed entity to model the containment of Subscriber Line Cards within slots of the ONT.

### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The first byte of this two-byte identifier is set to:

- 0x00 if the ONT has non-integrated interfaces on the UNI side
- 0x01 if the ONT has integrated interfaces on the UNI side.

The second byte of this identifier is the slot id.

To accommodate a universal code for the ONT slot id for both PON and UNI interfaces, one could interpret the least significant 7 bits of the slot id as the actual physical slot number with the most significant bit serving as an interface type (UNI/ANI) indicator. Therefore, the coding of the UNI slot id is in the range of 0x01-0x7F (1-127). For reasons of backward compatibility, integrated Subscriber Line interfaces (i.e., no plug-in UNI cards) can also be associated with a "pseudo" slot id 0x00. The code 0x01 is used for the leftmost lower slot of the ONT when looking at the side where the Subscriber Line Cards are plugged in, 0x02 is used for the next slot just to the right of the previous one, and so forth; numbering on the next higher shelf continues at its left edge.

NOTE 1 – Up to 127 slots are supported.



(R) (mandatory) (2 bytes)

**Actual Plug-in unit Type:** This attribute is equal to the type of the LIM in the cardholder or equal to a value of 0x00 (= no LIM) if the cardholder is empty. This attribute will then be redundant with attribute "Type" of the managed entity Subscriber Line Card. (R) (mandatory) (1 byte)

**Expected Plug-in unit Type:** This attribute identifies which type of plug-in unit is provisioned for the slot. For type coding, see Table 3. The value of 0x00 (no LIM) means that the Subscriber Line Cardholder is not provisioned to contain a LIM. The value of 0xFF (255) means that the Subscriber Line Cardholder is configured for plug-and-play. Upon autonomous instantiation, this attribute is set to 0x00. For integrated interfaces, this attribute represents the type of interface. (R, W) (mandatory) (1 byte)

#### Actions

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### Notifications

**Attribute Value Change:** This notification is used to report autonomous changes of the Actual Plug-in unit type. The attribute value change notification shall identify the attribute changed and its new value. The AVCs for this managed entity are listed in Table 4a. For ONTs with integrated interfaces, AVCs are not supported.

NOTE 2 – In the AVC tables, the numbering follows that of the Attribute mask coding found in Table II.1. Accordingly, each AVC table has a maximum of 16 entries. If an existing attribute does not emit AVCs, then "N/A" (not applicable) is listed in the AVC column. "Reserved" is used for numbers that do not correspond to an existing attribute.

**Alarm:** This notification is used to notify the management system that there is something wrong with the provisioned plug-in unit. Both ONT and OLT should know the alarm list (see Table 4b) used by this entity. In case of no provisioning (no LIM configured) or in case the SubscriberLine Cardholder has been configured for plug-and-play, no alarms are raised. If the plugInLIMMissingAlarm is active, the plugInTypeMismatchAlarm shall not be raised. For ONTs with integrated interfaces, alarms are not supported.

**Table 3/G.983.2 – Subscriber line card types**

Coding	Contents	Description
0	no LIM	Default value
1	A1.5	ATM 1.544 Mbit/s module
2	A2	ATM 2.048 Mbit/s
3	A6.3	ATM 6.312 Mbit/s module
4	A6.3U	ATM 6.312 Mbit/s module, Remote (U-interface)
5	A8	ATM 8.448 Mbit/s
6	A25	ATM 25.6 Mbit/s module
7	A34	ATM 34.368 Mbit/s module
8	A45	ATM 44.736 Mbit/s module
9	A45/34	Configurable ATM 44.736/34.368 Mbit/s module
10	A150SMF SDH	ATM STM-1 SMF UNI
11	A150MMF SDH	ATM STM-1 MMF UNI

**Table 3/G.983.2 – Subscriber line card types**

<b>Coding</b>	<b>Contents</b>	<b>Description</b>
12	A150UTP SDH	ATM STM-1 UTP UNI
13	C1.5 (DS1)	1.544 Mbit/s Local (T-interface) AAL 1 module
14	C2.0 (E1)	2.048 Mbit/s Local (T-interface) AAL 1 module
15	C6.3 (J2)	6.312 Mbit/s Local (T-interface) AAL 1 module
16	C-DS1/E1	Configurable DS1/E1 AAL 1 module
17	C-DS1/E1/J1	Configurable DS1/E1/J1 AAL 1 module
18	C6.3U (J2)	6.312 Mbit/s Remote (U-interface) AAL 1 module
19	C192k	192 kbit/s Local (T-interface) AAL 1 module
20	C44.7 (DS3)	44.736 Mbit/s Local (T-interface) AAL 1 module
21	C34.3 (E3)	34.368 Mbit/s Local (T-interface) AAL 1 module
22	10Base-T	10 Base-T Ethernet LAN IF
23	100Base-T	100 Base-T Ethernet LAN IF
24	10/100Base-T	10/100 Base-Tx Ethernet LAN IF
25	Token Ring	Token Ring LAN IF
26	FDDI	FDDI LAN IF
27	FR	Frame relay
28	C1.5 (J1)	1.544 Mbit/s Local (T-interface) AAL 1 module
29	A150SMF SONET	ATM OC-3 SMF UNI
30	A150MMF SONET	ATM OC-3 MMF UNI
31	A150UTP SONET	ATM OC-3 UTP UNI
32	POTS	Plain Old Telephony Service
33	ISDN-BRI	ISDN Basic Rate Interface
34	Gigabit Ethernet	Gigabit Ethernet IF
35	ADSL	ADSL IF
36	SHDSL	SHDSL IF
37	VDSL	VDSL IF
38	Video Service	Video module
39	LCT	Local craft terminal interface
40	802.11	IEEE 802.11 interface
41	ADSL/POTS	Combination ADSL and POTS interfaces
42	VDSL/POTS	Combination VDSL and POTS interfaces
43..249	Reserved	
250	PON1244155	Asymmetric 1244/155 Mbit/s PON IF
251	PON1244622	Asymmetric 1244/622 Mbit/s PON IF
252	PON622symm	Symmetric 622/622 Mbit/s PON IF
253	PON155	Symmetric 155/155 Mbit/s PON IF
254	PON622	Asymmetric 155/622 Mbit/s PON IF

**Table 3/G.983.2 – Subscriber line card types**

<b>Coding</b>	<b>Contents</b>	<b>Description</b>
255	Plug-and-play/Unknown	Plug-and-play (for the Subscriber Line Cardholder managed entity only) Unrecognized module (for the Subscriber Line Card managed entity only)

**Table 4a/G.983.2 – AVC list for subscriber line cardholder**

<b>Number</b>	<b>Attribute value change</b>	<b>Description</b>
1	ActualType	Actual type of LIM in cardholder
2-16	Reserved	


**Table 4b/G.983.2 – Alarm list for subscriber line cardholder**

<b>Number</b>	<b>Alarm</b>	<b>Description</b>
0	PlugInLimMissingAlarm	Configured Plug-in LIM is not present
1	PlugInTypeMismatchAlarm	Inserted Plug-in LIM is wrong type
2	ImproperCardRemoval	Card has been removed without being deprovisioned. (This is a redundant alarm that is used to help the OLT distinguish between transitions from state S2 to state S1 and transitions from state S4 to state S1. This alarm is sent only when a transition occurs from state S2 to state S1. See Table 32 for state diagrams.)
3-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

Figure 32 shows a state diagram of the various behaviours of inserting/removing a particular Subscriber Line Card into/from a Subscriber Line Cardholder that is provisioned to a specific type or to plug-and-play.

In the figure, state S3' is conceptually identical to state S3 except in the behaviour when entering or leaving this state upon provisioning or deprovisioning.

In order to avoid a cluttered picture, the following state transitions, although possible, are not shown in the figure: from S3 to S9 on provisioning of plug-and-play mode, from S3' to S8 on provisioning of plug-and-play mode, from S9 to S3 on deprovisioning of plug and play-mode, and from S8 to S3' on deprovisioning of plug-and-play mode.



G.983.2\_F32

**Figure 32/G.983.2 – Subscriber line cardholder state diagram**

NOTE 3 – The state diagram presented in Figure 32 is not applicable for ONTs with integrated interfaces.

#### 7.1.4 Subscriber line card

This managed entity is used to represent the subscriber line card that is provisioned in an ONT slot. For ONTs with integrated interfaces on the UNI side, this managed entity represents available types of interfaces. An instance of this managed entity shall be automatically created by the ONT when the OLT has provisioned the subscriber line card (i.e., when the OLT has set attribute "Expected Plug-in Unit Type" of the Subscriber Line Cardholder to a specific LIM type). See 7.1.3. Moreover, an instance of this managed entity can also be created by the ONT at the request of the OLT if the attribute "Expected Plug-in Unit Type" of the corresponding Subscriber Line Cardholder is equal to the value 0xFF (255), which corresponds to "plug-and-play". For ONTs with integrated interfaces on the UNI side, an instance of this managed entity is automatically created for each instance of the Subscriber Line Cardholder managed entity.

An instance of this managed entity shall be deleted by the ONT when the OLT has deprovisioned the subscriber line card (i.e., when the OLT has set attribute "Expected Plug-in Unit Type" of the Subscriber Line Cardholder to 0x00, i.e., "no LIM"). Moreover, an instance of this managed entity can also be deleted by the ONT on request of the OLT if the attribute "Expected Plug-in Unit Type" of the corresponding Subscriber Line Cardholder is equal to the value 0xFF, i.e., "plug-and-play". For ONTs with integrated interfaces on the UNI side, an instance of this managed entity cannot be deleted by an OLT request.

##### *Relationships*

One instance of this managed entity is contained by an instance of the Subscriber Line Cardholder.

##### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The number used is the same as the instance number used for the Subscriber Line Cardholder managed entity instance containing this Subscriber Line Card instance. (R, Set-by-create (if applicable)) (mandatory) (2 bytes)

**Type:** This attribute identifies the Subscriber Line Card type. This attribute is a unique code as defined in Table 3. The value of 0xFF (255) means "unknown", i.e., the inserted Subscriber Line Card cannot be recognized by the ONT. In this case, the attribute's Serial Number, Version and Vendor id do not contain valid information. Upon autonomous instantiation, this attribute is set to 0x00. (R, Set-by-create (if applicable)) (mandatory) (1 byte)

**Number of ports:** This attribute gives the quantity of access ports on the Subscriber Line Card. Upon instantiation, this attribute is set equal to 0x01. (R) (optional) (1 byte)

**Serial Number:** The serial number is unique for each Subscriber Line Card. Note that the serial number may contain the vendor id and/or version number. For ONTs with integrated interfaces on the UNI side, this value is identical to the value of the Serial Number attribute of the ONT<sub>B-PON</sub> managed entity. Upon instantiation, this attribute consists of all spaces. (R) (mandatory) (8 bytes)

**Version:** This attribute identifies the version of the Subscriber Line Card as defined by the vendor. A value of 0x00 shall be used when version information is not available or applicable to the ONT being represented. For ONTs with integrated interfaces on the UNI side, this value is identical to the value of the Version attribute of the ONT<sub>B-PON</sub> managed entity. Upon autonomous instantiation, this attribute consists of all spaces. (R) (mandatory) (14 bytes)

**Vendor id:** This attribute identifies the vendor of the Subscriber Line Card. For ONTs with integrated interfaces on the UNI side, this value is identical to the value of the Vendor id attribute of the ONT<sub>B-PON</sub> managed entity. Upon instantiation, this attribute consists of all spaces. (R) (optional) (4 bytes)

**Administrative State:** This attribute is used to "unlock" (value 0x00) and "lock" (value 0x01) the functions performed by the Subscriber Line Card. When the administrative state is set to "lock", all user traffic to and from this Subscriber Line Card is blocked and alarms for this Subscriber Line Card and all associated managed entities are no longer generated. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W, Set-by-create (if applicable)) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not the managed entity is capable of performing its task. Valid values are enabled (0x00), disabled (0x01), and unknown (0x02). Upon instantiation, this attribute is set to (0x02). (R) (optional) (1 byte)

**BridgedorIPInd:** This attribute indicates whether the Ethernet interface is bridged or derived from an IP router function (Bridged: 0x00; IP router: 0x01; 0x02 Bridged and IP Router). 0x02 means that both bridged and IP router functions are supported by the subscriber line card. Upon autonomous instantiation, the value 0x00 is used. (R, W) (optional, only applicable for subscriber line cards with Ethernet interfaces) (1 byte)

**Equipment id:** This attribute may be used to identify the vendor's specific type of line card. This attribute applies only to line cards that do not have integrated interfaces. In North America, this may be used for the equipment CLEI code. Upon instantiation, this attribute consists of all spaces. (R) (optional) (20 bytes)

**CardConfiguration:** This attribute is used to select the appropriate configuration on configurable line cards (e.g., T1/E1). Table 3 specifies 3 configurable card types: A45/34 (code 9), C-DS1/E1 (code 16), and C-DS1/E1/J1 (code 17). Values are indicated below for the allowed card types and configurations.

Card Type	Configuration	Value
A45/34	ATM 44.736 Mbit/s	0x00
	ATM 34.368 Mbit/s	0x01
C-DS1/E1	DS1	0x00
	E1	0x01
C-DS1/E1/J1	DS1	0x00
	E1	0x01
	J1	0x02

Upon autonomous instantiation, the value 0x00 is used. (R, W, Set-by-create (if applicable)) (mandatory for configurable line cards) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity (optional, only when plug-and-play is supported).

**Delete:** Delete an instance of this managed entity (optional, only when plug-and-play is supported).

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Reboot:** Reboot the Subscriber Line Card.

**Test:** Test the Subscriber Line Card (this action is optional).

## Notifications

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify the attribute and its new value. The list of AVCs for this managed entity is given in Table 5a.

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 5b.

NOTE – For ONTs with integrated interfaces on the UNI side, alarms are not applicable except perhaps for video support. Use of alarms for video support is considered optional and is for future study.

**Test result:** For the "Test result" event, notification is sent to the OLT via an alarm ONLY if the ME fails the autonomous self test.

**Table 5a/G.983.2 – AVC list for subscriber line card**

Number	Attribute value change	Description
1-6	N/A	
7	OpState	Operational state of Subscriber Line Card
8	N/A	
9-16	Reserved	

**Table 5b/G.983.2 – Alarms list for subscriber line card**

Number	Event	Description
0	EquipmentAlarm	A failure on an internal interface or failed self test
1	PoweringAlarm	LIM fuse failure or failure of LIM DC/DC converter
	Test result	
2	SelfTestFailure	Failure of Subscriber Line Card autonomous self test
3-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.1.5 PON IF line cardholder

This managed entity represents slots of the ONT that are capable of holding a network card on the ANI side. An instance of this managed entity shall exist for each slot. Instances of this managed entity are created automatically by an ONT that supports PON IF plug-in after the ONT initialization. (For integrated PON interfaces, no instances of this managed entity need to be created. However, if PON IF-based traffic management features (T-CONTs, Priority queues, and Traffic Schedulers) are to be modelled, an instance of this entity facilitates this.)

NOTE 1 – This definition merely provides a placeholder to facilitate equipment management of removable PON IF line cards.

## Relationships

An instance of the PON IF Line Cardholder may contain instances of the PON IF Line Card managed entity to model the containment of PON IF Line Cards within slots of the ONT.

## *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The first byte of this two-byte identifier is always 0x00. The second byte of this identifier is the slot id.

To accommodate a universal code of the ONT slot id for both PON and UNI interfaces, one must interpret the least significant 7 bits of the slot id as the actual physical slot number with the most significant bit serving as an interface type (UNI/ANI) indicator. Therefore, the coding of the PON IF Line Card slot id is in the range of 0x81-0xFF (129-255). The code 0x81 (129) is used for the leftmost lower slot of the ONT when looking at the side where the PON IF Line Cards are plugged in, 0x82 (130) is used for the next slot just to the right of the previous one, and so forth; numbering on the next higher shelf continues at its left edge. (R) (mandatory) (2 bytes)

NOTE 2 – Only up to 127 slots are supported.

## *Actions*

**Get:** Get one or more attributes.

## *Notifications*

None.

### **7.1.6 PON IF line card**

This managed entity is used to model a field-replaceable PON IF Line Card contained within an ONT.

An instance of this managed entity shall be automatically created by the ONT. (For integrated PON interfaces, no instances of this managed entity need to be created. However, if PON IF-based traffic management features (T-CONTs, Priority queues, and Traffic Schedulers) are to be modelled, an instance of this entity facilitates this.)

NOTE – This definition merely provides a placeholder to facilitate equipment management of removable PON IF line cards.

## *Relationships*

One instance of this managed entity is contained by an instance of the PON IF Line Cardholder.

## *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The number used is the same as the instance number used for the PON IF Line Cardholder managed entity instance containing this PON IF Line Card instance. (R) (mandatory) (2 bytes)

**Serial Number:** The serial number is unique for each PON IF Line Card. Upon autonomous instantiation, this attribute consists of all spaces. (R) (mandatory) (8 bytes)

**Version:** This attribute identifies the version of the PON IF Line Card as defined by the vendor. Upon autonomous instantiation, this attribute consists of all spaces. (R) (mandatory) (14 bytes)

**Vendor id:** This attribute identifies the vendor of the PON IF Line Card. Upon autonomous instantiation, this attribute consists of all spaces. (R) (optional) (4 bytes)

**Equipment id:** This attribute may be used to identify the vendor's specific type of PON interface card. This attribute applies only to PON interface cards that do not have integrated interfaces. In North America, this may be used for the equipment CLEI code. Upon instantiation, this attribute consists of all spaces. (R) (optional) (20 bytes)



**Total T-CONT buffer number:** This attribute provides a total number of T-CONT buffers, which are associated with the PON IF line card. Upon autonomous instantiation, the value 0x00 is used. (R) (mandatory) (1 byte)

**Total Priority Queue number:** This attribute provides a total number of priority queues, which are associated with the PON IF line card. Upon autonomous instantiation, the value 0x00 is used. (R) (mandatory) (1 byte)

**Total Traffic Scheduler number:** This attribute provides a total number of Traffic Schedulers, which are associated with the PON IF line card. The ONT supports NULL function, HOL (Head Of the Line) scheduling and WRR (Weighted Round Robin) from the priority control and guarantee of minimum rate control points of view, respectively. If the ONT does not have any Traffic Scheduler, this attribute should be 0x00. Upon autonomous instantiation, the value 0x00 is used. (R) (mandatory) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Reboot:** Reboot the PON IF Line Card.

**Test:** Test the PON IF Line Card (this action is optional and for further study). If testing is used, a "Test Result" event should be added to the notifications and event list.

#### *Notifications*

**Attribute Value Change:** This notification is used to report autonomous changes to the attributes of this managed entity. The notification shall identify the attribute that changed and its new value. If additional attributes are added, any relevant AVCs should be listed in a table.

**Alarm:** Alarms on the PON IF are transmitted to the OLT by PLOAM messages (see ITU-T Rec. G.983.1 [3]). There are no OMCI-based alarms for the PON IF.

### **7.1.7 Software image**

This managed entity represents a program stored in the ONT.

Two instances of this managed entity shall be automatically created by the ONT after the creation of an ONT managed entity (mandatory) and each Subscriber Line Card managed entity (optional – not applicable for ONTs with integrated interfaces on the UNI side). It is used to report to the management system the software currently installed in non-volatile memory. After the creation of the instances of this managed entity, the associated attributes are updated according to the data within the ONT and Subscriber Line Cards.

#### *Relationships*

Two instances of this managed entity are contained in an instance of the ONT and Subscriber Line Card managed entities.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The number consists of a two-byte field. The first field (MSB) identifies the ME instance (ONT (value 0x00) or removable Subscriber/PON IF Line Card (value 0x01-0x7F/0x81-0xFF)) containing the associated Software Image ME. The second field (LSB) distinguishes between the two (redundant) Software Image ME instances (values 0x00 and 0x01). (R) (mandatory) (2 bytes)

**Version:** This attribute identifies the version of the software. Upon autonomous instantiation, this attribute consists of all spaces. (R) (mandatory) (14 bytes)

**Is committed:** This attribute indicates whether the associated software image is "committed" (value 0x01) or "uncommitted" (value 0x00). By definition, the "committed" software image will be loaded and executed upon a reboot of the ONT and/or associated removable Subscriber/PON IF Line Card ME. During normal operation, one software image will always be "committed" while the other is "uncommitted". Under no circumstances are both software images allowed to be "committed" at the same time. On the other hand, both software images are only allowed to be non-committed at the same time if both are invalid. Upon autonomous instantiation, this attribute of instance 0 shall be initialized to "committed" and this attribute of instance 1 shall be initialized to "uncommitted". (R) (mandatory) (1 byte)

**Is active:** This attribute indicates whether the associated software image is "active" (value 0x01) or "inactive" (value 0x00). By definition, the active software image is one that is currently loaded and executing in the ONT (or associated Subscriber/PON IF Line Card). Under normal operation, one software image will always be "active" while the other is "inactive". Under no circumstances are both software images allowed to be "active" at the same time. On the other hand, both software images are only allowed to be inactive at the same time if both are invalid. Upon autonomous instantiation, this attribute of instance 0 shall be initialized to "active" and this attribute of instance 1 shall be initialized to "inactive". (R) (mandatory) (1 byte)

**Is valid:** This attribute indicates whether the associated software image is "valid" (value 0x01) or "invalid" (value 0x00). By definition, a software image is "valid" if it has been verified to be an executable code image. The verification mechanism is not subject to standardization; however, at a minimum it must include a data integrity (CRC) check of the entire code image. Upon autonomous instantiation, the associated code image is verified and this attribute is set according to the result of this verification. (R) (mandatory) (1 byte)

## Actions

**Get:** Get one or more attributes.

**Start Download:** Initiate a software download sequence to the alternate (i.e., currently inactive) software image. This action is only valid for a software image that is currently inactive and is not committed (i.e., is not selected as the bootable image). (optional)

**Download Section:** Download a section of a software image. This action is only valid for a software image that is currently being downloaded (image 1 in state S2/image 0 in state S2'). (optional)

**End Download:** Signal the completion of a download sequence, providing both the valid CRC and version information for a final verification of an associated downloaded software image. This action is only valid for a software image that is currently being downloaded (image 1 in state S2/image 0 in state S2'). (optional)


**Activate Image:** Load/execute a valid software image. When this action is applied to a software image that is currently inactive, execution of the current code image is suspended; the associated software image is loaded from non-volatile memory; and execution of this new code image is initiated. When this action is applied to a software image that is already active, a soft restart is performed (i.e., the software image is not reloaded from non-volatile memory, execution of the current volatile code image is simply restarted). This action is only valid for a valid software image. (optional)

**Commit Image:** Select a valid software image to be the default image to be loaded and executed by the boot code upon start-up (i.e., set the Is\_committed attribute value to 0x01 for the associated Software Image ME and set the Is\_committed attribute value to 0x00 for the other Software Image ME). This action is only valid for a valid software image. (optional)

In Figure 33, a state diagram is given, showing an example of the "life cycle" of software images under the actions given above. State S0 is a conceptual initialization state when neither of the software images is valid (i.e., executable). During S0, the OMCC is not functional.

*Notifications*

None.



G.983.2\_F33

Figure 33/G.983.2 – Software image state diagram

### 7.1.8 ONU<sub>B-PON</sub>

This managed entity represents the ONU as equipment.

An instance of this managed entity is automatically created by the ONU after initialization. After the creation of this managed entity, the associated attributes are updated according to the data within the ONU itself.

The ONU<sub>B-PON</sub> managed entity has the same Relationships, Attributes, Actions, and Notifications as the ONT<sub>B-PON</sub> managed entity. The only difference is the M.E. type, which is useful to higher layer management systems to identify ONUs as shared network equipment and ONTs as dedicated termination equipment.

## 7.2 ANI management

The OMCI will not maintain the basic PON interface information. The OLT will maintain the PON interface related managed entities and will get all the basic ONT-related information needed for those managed entities via PLOAM cells (e.g., Transmit Failure) as specified in ITU-T Rec. G.983.1 [3]. However, these entities are used to hold DBA and APS control information. For the purpose of description, the ONT will autonomously create one instance of each of the managed entities "PON Physical Path Termination Point", "ANI" and "PON TC Adapter" upon creation of the ONT<sub>B-PON</sub> managed entity. In cases where DBA or APS are provided, the appropriate attributes will be set accordingly.

### 7.2.1 PON physical path termination point

An instance of this managed entity represents a point in the ONT where a PON Physical Path terminates and physical path level functions (e.g., path overhead functions) are performed.

An instance of this managed entity is automatically created by the ONT after initialization. However, this instance will not be reported during a MIB upload.

#### *Relationships*

One or more instances of this managed entity are contained in an instance of the ONT or PON IF Line Card managed entities.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the PON IF. The first byte is the slot id (defined in 7.1.5). If the PON IF is integrated, this value is 0x80 (128). The second byte is the port id with value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a PON IF Line Card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

#### *Actions*

None.

#### *Notifications*

None.

### 7.2.2 ANI

This managed entity is used to organize data associated with the Access Network Interface (ANI) supported by the ONT. One instance of this managed entity shall exist for each ONT.

An instance of this managed entity is automatically created by the ONT after initialization. However, this instance will not be reported during a MIB upload, unless DBA is supported.

## Relationships

One or more instances of this managed entity are contained in an instance of the ONT<sub>B-PON</sub> or PON IF Line Card managed entities.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the PON IF. The assigned number is the same as the id of the PON Physical Path Termination Point with which this ANI is associated. (R) (mandatory) (2 bytes)

**SR indication:** This boolean attribute indicates the capability of status reporting. The value TRUE means that the status reporting is available for all T-CONT buffers which are associated with the ANI. The default value is false. (R) (Mandatory if DBA supported) (1 byte)

**Total Data Grant:** This attribute provides the total number of data grants that are able to be supported in this ANI port. Upon autonomous instantiation, this attribute will be set to zero. (R) (Mandatory if DBA supported) (1 byte)

**Total DS Grant:** This attribute provides the total number of divided slot grants that are able to be supported in this ANI port. Upon autonomous instantiation, this attribute will be set to zero. (R) (Mandatory if DBA supported) (1 byte)

**T-CONT reporting types:** This attribute provides a special code that indicates the kinds of reports that this ONT can perform. Value 0x00 means that T-CONT buffer reporting uses one byte. Value 0x01 means that T-CONT buffer reporting uses one byte or two bytes. Value 0x02 means that T-CONT buffer reporting uses one byte or two or four bytes. More explanation is described in ITU-T Rec. G.983.4. Upon autonomous instantiation, this attribute will be set to zero. (R) (Optional) (1 byte)

## Actions

**Get:** Get one or more attributes.

## Notifications

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify the attribute and its new value. The AVCs for this managed entity are given in Table 6a.

**Table 6a/G.983.2 – AVC list for physical path termination point ATM ANI**

Number	Attribute value change	Description
1	N/A	
2	Total Data Grant	Number of data grants supported
3	Total DS Grant	Number of Divided slot grants supported
4	T-CONT reporting type	The type of DBA reports supported
5-16	Reserved	

### 7.2.3 PON TC adapter

An instance of this managed entity represents a point in the ONT where the adaptation of the ATM Layer to the underlying physical infrastructure (i.e., the PON) takes place. One instance of this managed entity shall exist for each ONT.

An instance of this managed entity is automatically created by the ONT after initialization. However, this instance will not be reported during an MIB upload, unless APS is supported.

## Relationships

One instance of this managed entity will exist for the PON Physical Path Termination Point managed entity.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the PON Physical Path Termination Point with which this PON TC Adapter is associated. For the 1+1 protection model, the PON TC Adapter is associated with the PON Physical Path Termination Point of the working entity. For the 1:1 protection model, the PON TC Adapter is associated with the PON Physical Path Termination Point of the working entity for normal traffic and of the protection entity for extra traffic. (R) (mandatory) (2 bytes)

**TC Adapter type:** This attribute represents PON TC Adapter type. Valid values are provided below.

0x0: protection function is not available;

0x1: 1+1 architecture is available;

0x2: 1:1 architecture is available and normal traffic shall be adapted;

0x3: 1:1 architecture is available and extra traffic shall be adapted.

Upon autonomous instantiation, this attribute will be set to zero. (R) (mandatory for PON protection) (1 byte)

**Protection pointer:** This attribute provides the instance id of the PON Physical Path Termination Point that serves as the protection entity. This attribute is valid only when TC adapter type is 0x1 or 0x2. Upon autonomous instantiation, this attribute will be set to zero. (R) (mandatory for PON protection) (2 bytes)

**Revertive Ind:** This attribute indicates whether the protection scheme uses revertive mode (= TRUE, value 0x01) or non-revertive mode (= FALSE, value 0x00). Upon autonomous instantiation, this attribute will be set to false. (R) (mandatory for PON protection) (1 byte)

**Wait To Restore Time:** This attribute specifies the amount of time, in seconds, to wait after a fault clears before restoring traffic to the protected trail/connection/line that initiated the switching. Upon autonomous instantiation, this attribute will be set to zero. (R, W) (mandatory for PON protection) (2 bytes)

**Switching Guard Time:** This attribute specifies the amount of time, in milliseconds, that must elapse after detection of a fault before a protection trail/connection/line can be used to transport the normal traffic signal and/or to select the normal traffic signal. Upon autonomous instantiation, this attribute will be set to zero. (R, W) (optional) (2 bytes)

## Actions

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

## Notifications

None.

### 7.2.4 T-CONT buffer

An instance of this managed entity represents a logical object to the data grant provided by the OLT. A T-CONT buffer can accommodate ATM cells in priority queues or Traffic Schedulers that exist in the ATM layer. Therefore, the T-CONT buffer is regarded as a logical buffer.

### *Relationships*

One or more instances of this managed entity are contained in an instance of the ONT managed entity.

### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is associated with the physical capability that realizes the T-CONT buffer. The first byte is the slot id of the PON IF card with which this T-CONT buffer is associated. For integrated PON IF interfaces, this byte can be associated with "pseudo" slot id 0x80 (128). If the ONT has T-CONT buffers that are not associated with the PON IF card at the creation of this instance, the first byte of this T-CONT buffer is 0xFF. The second byte is the T-CONT id that is numbered by the ONT itself. The T-CONT id is numbered in ascending order with the range of 0x00 to 0xFF in each PON-IF Line Card or ONT core. (R) (mandatory) (2 bytes)

**ANI Pointer:** This attribute provides the ANI instance id in which this T-CONT buffer can send ATM cells in response to one of data grants. Upon autonomous instantiation this attribute consists of the 0x8001 or 0x8101. (The default value should be decided in consideration of the backward compatibility.) (R,W) (Mandatory) (2 bytes)

**Policy:** This attribute represents scheduling policy. Valid values include but are not limited to "Null" (value 0x00), "HOL" (value 0x01) or "WRR" (value 0x02). Upon autonomous instantiation this attribute consists of the 0x01. (R) (mandatory) (1 byte)

### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

### *Notifications*

None.

## **7.3 UNI management**

### **7.3.1 Physical path termination point ATM UNI**

This managed entity represents the point at an ATM UNI in the ONT where physical paths terminate and physical path level functions (e.g., path overhead functions) are performed.

An instance of this managed entity shall be automatically created/deleted by the ONT upon the creation/deletion of a Subscriber Line Card of ATM type.

### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as ATM type.

### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot id (defined in 7.1.3). The second byte is the port id with a value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a subscriber line card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Expected type:** The following coding is used for this attribute: 0x00 = by autosensing, 0x01 to 0xFE (1 to 254) = one of the values from Table 3 that is compatible with the type of the LIM. Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)



**Sensed type:** If the value of "Expected type" is not equal to 0x00, then the value of "Sensed type" equals the value of "Expected type". If the value of "Expected type" equals 0x00, then the value of "Sensed type" equals one of the values from Table 3 (0x01 to 0xFE) and by necessity is compatible with the Type of the Subscriber Line Card managed entity. Upon autonomous instantiation, the value 0x00 is used. (R) (mandatory if the ONT supports LIMs with configurable interface types, e.g., ATM45/34) (1 byte)

**Cable configuration:** For an ATM45 interface, there are two options for the cable length. This attribute is used to select the option. Value 0x00: cable length  $\leq$  68.6 m; value 0x01 cable length  $>$  68.6 m. (R, W) (mandatory for interfaces with cable configuration options) (1 byte)

**Loopback Configuration:** This attribute represents the loopback configuration of this physical interface. Value 0x00: no loopback; value 0x01: loopback2 ("Loopback2" refers to a loopback at the ONT to the OLT. The OLT can execute a physical level loopback test after loopback2 is set.). Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) the functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify the attribute and its new value. The AVCs for this managed entity are given in Table 6b.

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarms for this entity are given in Table 6c. The SDH and SONET interface related alarm should be consistent with the existing standards. The relevant Recommendations are ITU-T Recs G.744, M.3100 and Q.834.1.

**Table 6b/G.983.2 – AVC list for physical path termination point ATM UNI**

Number	Attribute value change	Description
1	N/A	
2	SensedType	Sensed SLC type (values given in Table 3)
3	N/A	
4	N/A	
5	N/A	
6	OpState	Operational state
7-16	Reserved	

**Table 6c/G.983.2 – Alarm list for physical path termination point ATM UNI**

Number	Alarm	Description
0	TF	Transmitter failure
1	LOS	Loss of signal
2	LOF	Loss of frame
3	OOF	Out of frame
4	RAI	Remote alarm indication
5	ERR	Block error
6	OOF (PLCP)	Out of frame (physical layer convergence protocol)
7	RAI (PLCP)	Remote alarm indication (physical layer convergence protocol)
8	ERR (PLCP)	Block error (physical layer convergence protocol)
9	REI (PLCP)	Remote error indication (physical layer convergence protocol)
10	SONET/SDH MS-SD	Multiplex section – signal degraded
11	SONET/SDH MS-RDI	Multiplex section – remote defect indication
12	SONET/SDH MS-ERR	Multiplex section – block error
13	SONET/SDH MS-REI	Multiplex section – remote error indication
14	SONET/SDH MS-AIS	Multiplex section – alarm indication signal
15	SONET/SDH P-RDI	Path – remote defect indication
16	SONET/SDH P-ERR	Path – block error
17	SONET/SDH P-REI	Path – remote error indication
18	SONET/SDH P-AIS	Path-alarm indication signal
19	SONET/SDH LOP	Loss of pointer in the VC4
20	1.5 M REC	1.544 Mbit/s receive alarm
21	1.5 AIS	1.544 Mbit/s alarm indication signal
22	1.5 M BAIS	1.544 Mbit/s back alarm indication signal
23	6 M REC	6.312 Mbit/s receive alarm
24	6 M SEND	6.312 Mbit/s send alarm
25	6 M ERR	6.312 Mbit/s block error
26	2 M RDI	2.048 Mbit/s remote defect indication
27	2 M E-ERR	2.048 Mbit/s CRC-4 error indication
28	2 M AIS	2.048 Mbit/s alarm indication signal
29	8 M RDI	8.448 Mbit/s remote defect indication
30	8 M AIS	8.448 Mbit/s alarm indication signal
31	34 M RDI	34.368 Mbit/s remote defect indication
32	34 M AIS	34.368 Mbit/s alarm indication signal
33	34 M FEBE	34.368 Mbit/s far end block error
34	45 M RDI	44.736 Mbit/s remote defect indication
35	45 M AIS	44.736 Mbit/s alarm indication signal
36	45 IDLE	44.736 Mbit/s idle
37-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.2 Physical path termination point Ethernet UNI

This managed entity represents the points at an Ethernet UNI in the ONT where physical paths terminate and physical path level functions (e.g., Ethernet function) are performed.

An instance of this managed entity shall be automatically created/deleted by the ONT upon the creation/deletion of a Subscriber Line Card of Ethernet type.

#### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as a native LAN type (e.g., Ethernet).

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot id (defined in 7.1.3). The second byte is the port id with value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a subscriber line card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Expected type:** The following coding is used for this attribute: 0x00 = by autosensing, 0x01 to 0xFE (1 to 254) equals one of the values from Table 3 that is compatible with the type of the LIM. Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)

**Sensed type:** If the value of "Expected type" is not equal to 0x00, then the value of "Sensed type" equals the value of "Expected type". If the value of "Expected type" equals 0x00, then the value of "Sensed type" = one of the values from Table 3 and by necessity is compatible with the Type of Subscriber Line Card managed entity. Upon autonomous instantiation, the value 0x00 is used. (R) (mandatory if the ONT supports LIMs with configurable interface types, e.g., 10/100 BaseT card) (1 byte)

**Auto Detection Configuration:** For 10/100 Base-Tx Ethernet interfaces, this attribute is used to set the configuration options: Auto-sensing: 0x00; 10BaseT: 0x01; 100BaseT: 0x02; Gigabit Ethernet: 0x03; 10BaseT Auto-sensing: 0x10; 10BaseT (half duplex): 0x11; 100BaseT (half duplex): 0x12; Gigabit Ethernet (half duplex): 0x13; Gigabit Ethernet Auto-sensing: 0x20. Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory for interfaces with auto detection options) (1 byte)

**Ethernet loopback configuration:** This attribute is used to set the Ethernet loopback configuration: No loopback (value 0x00), Loop3 (value 0x03, Loopback of downstream traffic after PHY transceiver). Loop 3 is depicted in Figure 34. Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) the functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**ConfigurationInd:** This attribute indicates the configuration status of the Ethernet UNI. 10BaseT (full duplex): 0x01; 100BaseT (full duplex): 0x02; Gigabit Ethernet (full duplex): 0x03; 10BaseT (half duplex): 0x11; 100BaseT (half duplex): 0x12; Gigabit Ethernet (half duplex): 0x13; When the configuration status is not detected (e.g., Ethernet link is not established or line card is not yet installed), the value 0x00 is used. Upon autonomous instantiation, the value 0x00 is used. (R) (mandatory) (1 byte)

**MaxFrameSize:** This attribute denotes the maximum allowed frame size to be transmitted across this interface. Upon autonomous instantiation, the value 1518 is used. (R,W) (mandatory) (2 bytes)

**DTEorDCEInd:** This attribute indicates whether the Ethernet interface wiring is DTE or DCE (DCE: 0x00; DTE: 0x01). Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)

**PauseTime:** This attribute allows the ONT line card to request that the customer terminal temporarily suspend sending data. Units are in "pause\_quanta" (1 pause\_quantum equals 512 bits times of the particular implementation). Values: 0x0000 to 0xFFFF. Upon autonomous instantiation, the value 0x0000 is used. (R,W) (optional) (2 bytes)


**BridgedorIPInd:** This attribute indicates whether the Ethernet interface is bridged or derived from an IP router function (Bridged: 0x00; IP router: 0x01; 0x02: depends on Subscriber Line Card.) 0x02 means that the SLC "BridgedorIPInd" attribute will be either 0x00 or 0x01. Upon autonomous instantiation, the value 0x02 is used. (R, W) (optional) (1 byte)

**ARC:** This attribute is used to control alarm reporting from this managed entity. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ARCInterval:** This attribute provides a provisionable length of time. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**PPPoE Filter:** This attribute may be used to control filtering of PPPoE packets on this Ethernet port. The value 0x00 is used to disable filtering. The value 0x01 is used to enable filtering. When filtering is enabled, all packets other than PPPoE packets will be discarded. Default value is 0x00. (R,W) (optional) (1 byte)

**Power control:** This attribute controls whether power is provided to an external equipment over the Ethernet PPTP. Value 0x01 enables power over Ethernet. The default value 0x00 disables power feed. (R, W) (optional) (1 byte)



**Figure 34/G.983.2 – Schematic diagram of Loop 3**

#### Actions

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

## Notifications

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify its new value. The AVC list is given in Table 6d.

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 6e. See also Appendix III.

**Table 6d/G.983.2 – AVC list for physical path termination point Ethernet UNI**

Number	Attribute value change	Description
1	N/A	
2	SensedType	Sensed type of Ethernet interface. Valid values are 0x01 (10BaseT), 0x02 (100BaseT) and 0x03 (Gigabit).
3	N/A	
4	N/A	
5	N/A	
6	OpState	Operational state
7-10	N/A	
11-16	Reserved	

**Table 6e/G.983.2 – Alarm list for physical path termination point Ethernet UNI**

Number	Alarm	Description
0	LAN-LOS	No carrier at the Ethernet UNI
1-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.3 Physical path termination point CES UNI

This managed entity represents the points at a CES UNI in the ONT where physical paths terminate and physical path level functions are performed.

An instance of this managed entity shall be automatically created/deleted by the ONT upon the creation/deletion of a Subscriber Line Card of CES type.

## Relationships

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as CES type.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot id (defined in 7.1.3). The second byte is the port id with a value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a subscriber line card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)


**Expected type:** The following coding is used for this attribute: 0x00 = by autosensing, 0x01 to 0xFE (1 to 254) equals one of the values from Table 3 that is compatible with the type of the LIM. Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)

**Sensed type:** If the value of "Expected type" is not equal to 0x00, then the value of "Sensed type" equals the value of "Expected type". If the value of "Expected type" equals 0x00, then the value of "Sensed type" = one of the values from Table 3 and by necessity is compatible with the Type of the Subscriber Line Card managed entity. Upon autonomous instantiation, the value 0x00 is used. (R) (mandatory for the case of ONT supports LIMs with configurable interface types, e.g., C1.5/2/6.3) (1 byte)

**CES loopback configuration:** This attribute represents the loopback configuration of the physical interface. (See Figure 35.)

- Value 0x00: no loopback;
- value 0x01: payload loopback;
- value 0x02: line loopback;
- value 0x03: OpS-directed loopback1 (loopback from/to ATM network side);
- value 0x04: OpS-directed loopback2 (loopback from/to CES UNI side);
- value 0x05: OpS-directed loopback3 (loopback of both ATM network side and CES UNI side);
- value 0x06: Manual button-directed loopback (Read only);
- value 0x07: Network-side Code inband-directed loopback (Read only);
- value 0x08: SmartJack-directed loopback (Read only);
- value 0x09: Network-side Code inband-directed loopback. (ARMED) (Read only).

Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)



NOTE – For loopback3, note that both paths are wrapped independently.

**Figure 35/G.983.2 – Schematic diagram of loopback1, loopback2, and loopback3**

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) the functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**DS1Framing:** This attribute indicates the framing structure used. Valid values are "ExtendedSuperFrame" (0x00), "SuperFrame" (0x01), "UnFrame" (0x02), "G.704" (0x03) and "JT-G.704" (0x04). Upon autonomous instantiation, the value 0x00 is used. (R, W) (1 byte) (mandatory)

**Encoding:** This attribute denotes the encoding scheme required. Valid values are "B8ZS" (value 0x00), "AMI" (value 0x01), "HDB3" (0x02), and "B3ZS" (0x03). Upon autonomous instantiation, the value 0x00 is used. (R, W) (1 byte) (mandatory)

**LineLength:** This attribute provides the length of the twisted pair cable from the physicalPathTTP of type "DS1" interface to the DSX1 cross-connect point or the length of the DS3 cable from the physicalPathTTP of type "DS3" to the DSX3 cross-connect point. Valid values are given in Table 6f. Upon autonomous instantiation for DS1 interfaces, the value 0x00 is used for non-power feed type DS1, and the value 0x06 is used for power feed type DS1. Upon autonomous instantiation for DS3 interfaces, the value 0x0F is used. (R, W) (1 byte) (optional)

**DS1Mode:** This attribute indicates the mode of DS1 used. The valid values are "Mode#1" (value 0x00), "Mode#2" (value 0x01), "Mode#3" (value 0x02), and "Mode#4" (value 0x03). Moreover, each Mode is defined as described in Table 6g. Upon autonomous instantiation, the value 0x00 is used. (R,W) (optional) (1 byte)

**Table 6f/G.983.2 – Valid values for LineLength attribute**

Value	Power feed	Line length
0x00	Non-power feed type DS1	0-33.5 m (0-110 ft)
0x01	Non-power feed type DS1	33.5-67.1 m (110-220 ft)
0x02	Non-power feed type DS1	67.1-100.6 m (220-330 ft)
0x03	Non-power feed type DS1	100.6-134.1 m (330-440 ft)
0x04	Non-power feed type DS1	132.1-167.6 m (440-550 ft)
0x05	Non-power feed type DS1	167.6-201.2 m (550-660 ft)
0x06	Power feed type DS1 (Wet-T1), short-haul	0-40.5 m (0-133 ft)
0x07	Power feed type DS1 (Wet-T1), short-haul	40.5-81.1 m (133-266 ft)
0x08	Power feed type DS1 (Wet-T1), short-haul	81.1-121.6 m (266-399 ft)
0x09	Power feed type DS1 (Wet-T1), short-haul	121.6-162.5 m (399-533 ft)
0x0A	Power feed type DS1 (Wet-T1), short-haul	162.5-199.6 m (533-655 ft)
0x0B	Power feed type DS1 (Wet-T1), long-haul	0 dB
0x0C	Power feed type DS1 (Wet-T1), long-haul	7.5 dB
0x0D	Power feed type DS1 (Wet-T1), long-haul	15 dB
0x0E	Power feed type DS1 (Wet-T1), long-haul	22.5 dB
0x0F	DS3 power feed	0-68.5 m (0-225 ft)
0x10	DS3 power feed	68.5-137.1 m (226-450 ft)

**Table 6g/G.983.2 – Coding of DS1Mode attribute**

Mode	Connect	Line length	Power feed	Loop back
#1	DS1-CPE	Short Haul	Without power feed	Smart Jack
#2	DS1-CPE	Long Haul	Without power feed	Smart Jack
#3	DS1-NIU-CPE	Long Haul	Without power feed	Intelligent Office Repeater
#4	DS1-NIU-CPE	Long Haul	With power feed	Intelligent Office Repeater

**ARC:** This attribute is used to control alarm reporting from this managed entity. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ARCInterval:** This attribute provides a provisionable length of time. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**LineType:** This attribute denotes the line type used in the application for DS3 or E3 interfaces. Valid values are:

- 0x00, Other;
- 0x01, ds3m23;
- 0x02, ds3syntran;
- 0x03, ds3CbitParity;
- 0x04, ds3ClearChannel;
- 0x05, e3Framed;
- 0x06, e3plcp.

(R, W) (mandatory for DS3 and E3 interfaces, not applicable to other interfaces) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify its new value. The list of AVCs for this managed entity is given in Table 7a.

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 7b. These alarms should be consistent with the existing standards.

**Table 7a/G.983.2 – AVC list for physical path termination point CES UNI**

Number	Attribute value change	Description
1	N/A	
2	SensedType	Sensed SLC type (values given in Table 3)
3	CESLoopbackConfig	Loopback configuration of physical interface
4	N/A	
5	OpState	Operational state
6-8	N/A	
9-16	Reserved	



**Table 7b/G.983.2 – Alarm list for physical path termination point CES UNI**

Number	Alarm	Description
0	TF	Transmitter failure
1	LOS	Loss of signal
2	LOF	Loss of frame
3	OOF	Out of frame
4	RAI	Remote alarm indication
5	1.5 M BAIS	1.544 Mbit/s back alarm indication signal
6	R-INH	Receive alarm – inhibit
7	6 M REC	6.312 Mbit/s receive alarm
8	6 M SEND	6.312 Mbit/s send alarm
9	6 M ERR	6.312 Mbit/s block error
10	6 M BERR	6.312 Mbit/s back error
11	34 M REC	34.368 Mbit/s receive alarm
12	34 M AIS	34.368 Mbit/s alarm indication signal
13	2 M REC	2.048 Mbit/s receive alarm
14	2 M AIS	2.048 Mbit/s alarm indication signal
15	1.5 M REC	1.544 Mbit/s receive alarm
16	1.5 AIS	1.544 Mbit/s alarm indication signal
17	INFO0	INFO0 reception (INFO0)
18	45 M RDI	44.736 Mbit/s remote defect indication
19	45 M AIS	44.736 Mbit/s alarm indication signal
20-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.4 Logical $N \times 64$ kbit/s sub-port connection termination point

This managed entity is used to generically model *logical* sub-ports contained within a higher level physical layer interface (e.g., DS0s within a DS1, DS1s within a DS3, etc.). A single instance of this managed entity can represent an arbitrary (i.e., consecutive or non-consecutive) group of multiple channels/time slots (e.g., multiple DS0/DS1) at the user side as an integral bundle.

An instance of this managed entity shall be created by the OLT before the creation of an associated Interworking VCC Termination Pointer (see 7.3.7, Interworking VCC termination point).

#### *Relationships*

Zero or more instances of this ME shall be contained in an instance of the Physical Path Termination Point CES UNI.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**Physical Path Termination Pointer:** This attribute provides a pointer to the instance of the corresponding Physical Path Termination Point CES UNI managed entity id. (R, Set-by-create) (mandatory) (2 bytes)

**List of Time Slots:** This attribute provides a bitmap, which indicates the time slots. Each bit indicates whether the corresponding time slot is included in the connection or not. The correspondence is as indicated in Table 8. (R, Set-by-create) (mandatory) (12 bytes)

**Table 8/G.983.2 – Coding list of time slots**

Byte	Bit							
	8	7	6	5	4	3	2	1
1	TS 0	TS 1	TS 2	TS 3	TS 4	TS 5	TS 6	TS 7
2	TS 8	TS 9	TS 10	TS 11	TS 12	TS 13	TS 14	TS 15
...								
12	TS 88	TS 89	TS 90	TS 91	TS 92	TS 93	TS 94	TS 95

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

#### *Notifications*

None.

### **7.3.5 UNI<sub>B-PON</sub>**

This managed entity is used to organize data associated with the ATM User Network Interfaces (UNIs) supported by the ONT. For non-ATM UNIs, this is used as a logical ATM UNI. One instance of this managed entity shall exist for each UNI supported by the ONT.

Instances of this managed entity shall be automatically created/deleted by the ONT immediately following the creation/deletion of a Subscriber Line Card managed entity. After the creation of an instance of this managed entity, the associated attributes are updated according to the data within the Subscriber Line Card (if present) or within the ONT for the case of integrated interfaces on the UNI side.

Note that this managed entity is an aggregation of UNI and UNInfo managed entities.

#### *Relationships*

Zero or more instances of the UNI<sub>B-PON</sub> managed entity may be contained in an instance of a Subscriber Line Card managed entity.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The assigned number is the same as the id of the Physical Path Termination Point with which this UNI is associated. (R) (mandatory) (2 bytes)

**Local Maximum Number of Supportable VPCs:** This attribute identifies the number of VPCs that can be supported by the ONT at this end of the interface. Default is 0x0100 (256). (R) (mandatory for ATM interfaces) (2 bytes)

**Local Maximum Number of Allocated VPI Bits:** This attribute identifies the maximum number of allocated bits of the VPI sub-field that can be supported by the ONT at this UNI. Default is 0x08. (R) (mandatory for ATM interfaces) (1 byte)

**Loopback Location Code:** This attribute provides the code that identifies incoming ATM layer OAM loopback cells that are to be looped-back at this UNI (see also Appendix III). The default of this attribute consists of all 0xFFs. (R, W) (mandatory for ATM interfaces) (16 bytes)

**Configuration Option Status:** This attribute holds the UNI Configuration Code field. Its bits are assigned as described in Table 9. Upon autonomous instantiation, the value zero is used. (R, W) (mandatory) (2 bytes)

**Administrative State:** This attribute is used to "unlock" (value 0x00) and "lock" (value 0x01) the functions performed by the UNI. When the Administrative State attribute is set to "lock", all user traffic to and from this UNI is blocked and alarms for this UNI and all associated managed entities are no longer generated. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Table 9/G.983.2 – Coding of the configuration option status attribute**

Bit	Name	Setting
1	ServerTrailFaultPropagation ATM layer	0: Upstream VP-AIS generation in the ATM cell flow is deactivated 1: Upstream VP-AIS generation in the ATM cell flow is activated
2	ServerTrailFaultPropagation TC layer	0: All TC layer alarm reporting through the OMCC is inhibited 1: All TC layer alarm reporting through the OMCC is not inhibited
3	ServerTrailFaultPropagation PHY layer	0: All PHY layer alarm reporting through the OMCC is inhibited 1: All PHY layer alarm reporting through the OMCC is not inhibited
4	ServerTrailFaultPropagation AAL layer	0: All AAL layer alarm reporting through the OMCC is inhibited 1: All AAL layer alarm reporting through the OMCC is not inhibited
5-16	Reserved	

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### **7.3.6 TC Adapter<sub>B-PON</sub>**

An instance of this managed entity represents a point in the ATM subscriber line card where the adaptation of the ATM layer to the underlying physical infrastructure (e.g., SDH or PDH transport network) takes place. ITU-T Rec. I.321 [4] identifies this adaptation function as one of many functions performed at the Transmission Convergence (TC) Sublayer of the B-ISDN protocol stack. This managed entity is responsible for generating alarms that report the (in)ability of the managed entity to delineate ATM cells from the payload of a terminated digital transmission path.

An instance of this managed entity shall be automatically created/deleted by the ONT upon the creation/deletion of an ATM UNI and its Physical Path Termination Point.

#### *Relationships*

Zero or more instances of this managed entity shall be contained in the Subscriber Line Card managed entity. One instance of this managed entity shall exist for each instance of the Physical Path Termination Point managed entity.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the Physical Path Termination Point with which this TC Adapter<sub>B-PON</sub> is associated. (R) (mandatory) (2 bytes)

**Framer configuration:** Some UNIs such as the ATM45 have two methods of mapping ATM cells into the payload of a DS3 frame: physical layer convergence protocol (PLCP) based mapping and HEC based mapping. This attribute is used to select the "PLCP option" (value 0x01) or the "HEC option" (value 0x00). Upon autonomous instantiation, this attribute is set to "PLCP option". (R, W) (mandatory for interfaces with framer configuration options) (1 byte)

**Cell Scrambling Control:** This attribute is used to activate/deactivate the ATM cell scrambling function. This attribute is only present for ATM interfaces where ATM cell scrambling may be controlled, i.e., "activated" (value 0x01) or "deactivated" (value 0x00). [B-7] requires cell scrambling for ATM/SONET interfaces but allows cell scrambling to be controlled (i.e., turned on and off) for ATM/DS3 interfaces. Upon autonomous instantiation, this attribute is set to "activated". (R, W) (mandatory for interfaces with scrambling options) (1 byte)

**Cell Rate Decoupling Type:** This attribute is used to select the cell rate decoupling type whenever ITU-T Rec. I.432.1 [11] and [B-8] give different definitions. ITU-T defined type: 0x00; ATM Forum defined type: 0x01. Upon autonomous instantiation, 0x00 is used. (R, W) (mandatory for interfaces with decoupling options) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

## Actions

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

## Notifications

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify the attribute and its new value. The list of AVCs for this managed entity is given in Table 10a.

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 10b.

**Table 10a/G.983.2 – AVC list for TC Adapter<sub>B-PON</sub>**

Number	Attribute value change	Description
1-3	N/A	
4	OpState	Operational state of TC Adapter <sub>B-PON</sub>
5-16	Reserved	

**Table 10b/G.983.2 – Alarm list for TC Adapter<sub>B-PON</sub>**

Number	Alarm	Description
0	LCD	Loss of cell delineation
1-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.7 Interworking VCC termination point

An instance of this managed entity represents a point in the ONT where the interworking of a service (e.g., CES, IP) or underlying physical infrastructure (e.g., nxDSO/DS1/DS3/E3/Ethernet) takes place. At this point, ATM cells are generated from a bit stream (e.g., nxDSO/DS1/DS3/E3/Frame Relay/Ethernet) or a bit stream is reconstructed from ATM cells.

Instances of this managed entity are created and deleted by the ONT on request of the OLT.

#### *Establishment of a "CES interworking connection"*

Since it is more complicated to introduce the "pointer list" as an attribute, the following mechanism will be used to create a CES interworking connection:

- for structured service: Create first a VP Network CTP<sub>B-PON</sub> instance *and* an  $N \times 64$  kbit/s Sub-port Connection Termination Point instance, and then create an Interworking VCC Termination Point; the latter would contain a reference to the VP Network CTP<sub>B-PON</sub> instance on one hand and the  $N \times 64$  kbit/s Sub-port Connection Termination Point instance on the other hand; or
- for unstructured service: Create first a VP Network CTP<sub>B-PON</sub> instance, and then create an interworking VCC Termination Point; the latter would contain a reference to the VP Network CTP<sub>B-PON</sub> instance on one hand and to the Physical Path Termination Point CES UNI instance on the other hand.

#### *Establishment of other connection types*

Create first a VP Network CTP<sub>B-PON</sub> instance, and then create an interworking VCC Termination Point. The latter would contain a reference to the VP Network CTP<sub>B-PON</sub>.

#### *Relationships*

One instance of this managed entity shall exist for each occurrence of transformation of a data stream into ATM cells and vice versa. Note that the attributes "AAL Profile pointer" and "Service Profile pointer" imply relationships to these managed entities.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The value 0xFFFF is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**VCI Value:** This attribute identifies the VCI value associated with this Interworking VCC Termination Point. (R, Set-by-create) (mandatory) (2 bytes)

**VP/VCNetworkCTP Connectivity Pointer:** This attribute provides an instance identifier of the VP Network CTP<sub>B-PON</sub> or VC Network CTP<sub>B-PON</sub> that is associated with this Interworking VCC Termination Point. (R, Set-by-create) (mandatory) (2 bytes)

**Interworking Option:** This attribute identifies the type of non-ATM function that is being interworked; the option can be CES (0x00), MAC Bridge LAN (0x01), Voice (0x02) service, IP Router (0x03), VRP (0x04), or 802.1p mapper (0x05). (R, Set-by-create) (mandatory) (1 byte)

**Service Profile Pointer:** This attribute provides the service profile type and a pointer to the instance of a service profile, such as the CES Service Profile<sub>B-PON</sub> (if the interworking option = 0x00), MAC Bridge Service Profile (if the interworking option = 0x01), Voice Service Profile AAL (if the interworking option = 0x02), IP Router Service Profile (if the interworking option = 0x03), Video Return Path (if the interworking option = 0x04), or 802.1p mapper service profile (if interworking option = 0x05). (R, Set-by-create) (mandatory) (2 bytes)

**AAL Profile Pointer:** This attribute provides the AAL profile type and a pointer to an instance of AAL Profile such as AAL 1 Profile<sub>B-PON</sub> if the interworking option = 0x00, AAL 1 Profile<sub>B-PON</sub> or AAL 2 Profile<sub>B-PON</sub> if the interworking option = 0x02, or AAL 5 Profile<sub>B-PON</sub> if the interworking option = 0x01, 0x03, 0x05, or 0x04 mode 1. If the interworking option is 0x04 mode 2, then this pointer is not used. (R, Set-by-create) (mandatory) (2 bytes)

**Interworking Termination Point pointer:** This attribute is used for in the case of Circuit Emulation Services, and provides a pointer to the associated instance(s) of the following managed entities (depending on the service provided):


- Physical Path Termination Point CES UNI;
- logical  $N \times 64$  kbit/s sub-port Connection Termination Point

In all other non-ATM services, the relationship between the Interworking Termination Point and the IW VCC Termination point is derived from other managed entity relations, and this attribute is set to 0x0000, and not used. (R, Set-by-create) (mandatory) (2 bytes)

**AAL Loopback configuration:** This attribute is used to set the loopback configuration: No loopback (value 0x00), Loopback 1 (value 0x01, loopback of downstream traffic before FEC of AAL 1), Loopback 2 (value 0x02, loopback of downstream traffic after FEC of AAL 1), loopback after AAL (value 0x03, loopback of downstream traffic after any AAL). Loopback after AAL is depicted in Figure 36. Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)

**PPTP Counter:** This attribute represents the number of instances of PPTP managed entities associated with this instance of the Interworking VCC Termination Point managed entity. If only one instance of a PPTP managed entity is associated with this instance of the Interworking VCC Termination Point managed entity, this attribute is set to 0x01. If multiple instances of PPTP managed entities are associated with this instance of the Interworking VCC Termination Point managed entity (i.e., in case of AAL 2 multiplexing), this attribute is set to 0xZZ, where ZZ represents the number of associated PPTP instances. (R) (optional) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)



**Figure 36/G.983.2 – Schematic diagram of loopback after AAL**

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify the attribute and its new value. The list of AVCs for this managed entity is given in Table 11a.

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 11b. See also Appendix III.

**Table 11a/G.983.2 – AVC list for interworking VCC termination point**

Number	Attribute value change	Description
1-9	N/A	
10	OpState	Operational state of Interworking VCC Termination Point
11-16	Reserved	

**Table 11b/G.983.2 – Alarm list for interworking VCC termination point**

Number	Alarm	Description
0	End-to-end VC-AIS-LMIR	End-to-end VC-AIS receiving indication (optional)
1	End-to-end VC-RDI-LMIR	End-to-end VC-RDI receiving indication (optional)
2	End-to-end VC-AIS-LMIG	End-to-end VC-AIS generation indication (optional)
3	End-to-end VC-RDI-LMIG	End-to-end VC-RDI generation indication (optional)
4	Segment Loss of Continuity	Loss of continuity is detected when the Interworking VCC Termination Point is a segment end point (optional)
5	End-to-End Loss of Continuity	Loss of continuity is detected at the Interworking VCC Termination Point (optional)
6	CSA	Cell starvation alarm
7-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.8 AAL 1 Profile<sub>B-PON</sub>

This managed entity organizes data that describes the AAL Type 1 processing functions of the ONT. It is used with the Interworking VCC Termination Point managed entity.

In an ATM environment, AAL Type 1 configuration parameters are associated with an Interworking VCC Termination Point managed entity through a pointer relationship. Each instance of this managed entity defines a combination of parameter values that may be associated with multiple Interworking VCC Termination Point instances.

This managed entity is instantiated/deleted on request of the OLT.

#### *Relationships*

One instance of this managed entity shall exist for each combination of AAL 1 parameter values used within an ONT and may be associated with zero or more instances of the Interworking VCC Termination Point.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**Subtype:** This attribute identifies the AAL subtype. Valid values for this attribute are "null" (value 0x00), "voice-band based on 64 kbit/s" (value 0x01), "Synchronous Circuit Emulation" (value 0x02), "Asynchronous Circuit Emulation" (value 0x03), "High-quality Audio" (value 0x04) and "Video" (value 0x05). (R, Set-by-create) (mandatory) (1 byte)

**CBR Rate:** This attribute represents the rate of the CBR service supported by the AAL. Allowed values are 64 kbit/s (value 0x40), 1544 kbit/s (value 0x0608), 44 736 kbit/s (value 0xAEC0),  $n \times 64$  kbit/s (value  $n \times 0 \times 40$ ), 2048 kbit/s (value  $0 \times 0800$ ), etc. (R, Set-by-create) (mandatory) (2 bytes)

**Forward Error Correction Type:** This attribute indicates the FEC method: no FEC (value 0x00), FEC for Loss Sensitive Signal Transport (value 0x01), or FEC for Delay Sensitive Signal Transport (value 0x02). (R, Set-by-create) (optional) (1 byte)

**Structured Data Transfer:** This attribute indicates whether Structured Data Transfer (SDT) has been configured at the AAL. A value of 0x01 means SDT has been selected. A value of 0x00 means that no SDT has been selected. This attribute value cannot be set to 0x01 when the Forward Error Correction Type attribute equals 0x01. (R, Set-by-create) (optional) (1 byte)



**Partially Filled Cells:** This attribute identifies the number of leading octets in use. (R, Set-by-create) (optional) (1 byte)

**Clock Recovery Type:** This attribute indicates whether the clock recovery type is "synchronous" (value 0x00), which indicates that timing is derived from the physical interface, "SRTS" (Synchronous Residual Time Stamp, value 0x01), or "ACR" (Adaptive Clock Recovery, value 0x02). (R, Set-by-create) (mandatory) (1 byte)

**Cell Loss Integration Period:** This attribute represents the duration in milliseconds of the cell loss integration period. If the cell loss persists for such a period, the Interworking VCC Termination Point managed entity associated with this entity will generate a cell starvation alarm. (R, Set-by-create) (mandatory) (2 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

#### *Notifications*

None.

### **7.3.9 AAL 1 protocol monitoring history Data<sub>B-PON</sub>**

This managed entity contains the last completed 15-minute interval performance monitoring data collected as a result of performing Segmentation and Reassembly (SAR) Level and Convergence Sublayer (CS) protocol monitoring. All the attribute counters, e.g., the Header Errors, are only updated at the end of each period. Instances of this managed entity are created by the OLT whenever an instance of the Interworking VCC Termination Point managed entity is created that represents AAL 1 functions. Instances of this managed entity are deleted by the OLT.

#### *Relationships*

One instance of this managed entity can exist for each instance of the Interworking VCC Termination Point managed entity that represents AAL 1 functions.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the Managed Entity id of the corresponding Interworking VCC Termination Point. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0xFFFF is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Header Errors:** This attribute represents a count of the number of AAL 1 header errors detected, including those corrected. Header errors include correctable and not correctable CRC and parity errors. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**Sequence Violations:** This attribute represents a count of incoming AAL Type 1 SAR-PDUs where the sequence count in the PDU header causes a transition from the SYNC state to the OUT OF SEQUENCE state as defined by ITU-T Rec. I.363.1. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**Cell Loss:** This attribute represents a count of the number of lost cells, as detected by the AAL 1 sequence number processing, for example. This count records the number of cells detected as lost in the network prior to the destination interworking function AAL 1 layer processing. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**Cell Misinsertion:** This attribute represents a count of sequence violation events that the AAL CS interprets as misinserted cells as defined by ITU-T Rec. I.363.1. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**Buffer Underflows:** This attribute represents a count of the number of times the reassembly buffer underflows. In the case of a continuous underflow caused by a loss of ATM cell flow, a single buffer underflow should be counted. If the interworking function is implemented with multiple buffers, such as a cell level buffer and a bit level buffer, then either buffer underflow will cause this count to be incremented. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**Buffer Overflows:** This attribute represents a count of the number of times the reassembly buffer overflows. If the interworking function is implemented with multiple buffers, such as a cell level buffer and a bit level buffer, then either buffer overflow will cause this count to be incremented. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**SDT Pointer Reframes:** This attribute represents a count of the number of events in which the AAL 1 reassembler finds that a structured data pointer is not where it is expected and must be reacquired. This count is only meaningful for structured data transfer modes as unstructured modes do not use pointers. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (optional) (4 bytes)

**SDT Pointer Parity Check Failures:** This attribute represents a count of the number of times the AAL reassembler detects a parity check failure at the point where a structured data pointer is expected. This count is only meaningful for structured data transfer modes as unstructured modes do not use pointers. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (optional) (4 bytes)

### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 12.

**Table 12/G.983.2 – Alarm list for AAL 1 Protocol Monitoring History Data<sub>B-PON</sub>**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	Header errors	Header errors threshold crossing	1
1	Sequence Violation	Sequence Violation threshold crossing	2
2	Cell loss	Cell loss threshold crossing	3
3	Cell misinsertion	Cell misinsertion threshold crossing	4
4	Buffer Underflows	Buffer Underflows threshold crossing	5
5	Buffer Overflows	Buffer Overflows threshold crossing	6
6	SDT Pointer Reframes	SDT Pointer Reframes threshold crossing	7
7	SDT Pointer Parity Check Failures	SDT Pointer Parity Check Failures threshold crossing	8
8-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.10 AAL 5 Profile<sub>B-PON</sub>

This managed entity organizes data that describe the AAL Type 5 processing functions of the ONT. It is used with the Interworking VCC Termination Point managed entity.

In an ATM environment, AAL Type 5 configuration parameters are associated with an Interworking VCC Termination Point managed entity through a pointer relationship. Each instance of the managed entity defines a combination of parameter values that may be associated with multiple Interworking VCC Termination Point instances.

This managed entity is instantiated/deleted on request of the OLT.

### Relationships

One instance of this managed entity shall exist for each combination of AAL 5 parameter values used within an ONT and may be associated with zero or more instances of the Interworking VCC Termination Point.

### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**Max CPCS PDU Size:** This multi-valued attribute represents the maximum CPCS PDU size that will be transmitted over the connection in both the upstream and downstream direction of transmission. (R, Set-by-create) (mandatory) (2 bytes)

**AAL Mode:** This attribute indicates whether the AAL for the supporting VPC is operating in one of the following optional modes: message assured (0x00), message unassured (0x01), streaming assured (0x02), or streaming non-assured (0x03). (R, Set-by-create) (mandatory) (1 byte)

**SSCS Type:** This attribute identifies the SSCS type for the AAL. Valid values are "null" (0x00), "Data SSCS based on SSCOP, assured operation" (0x01), "Data SSCS based on SSCOP, non-assured operation" (0x02), or "Frame Relay SSCS" (0x03). (R, Set-by-create) (mandatory) (1 byte)

### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

### *Notifications*

None.

## **7.3.11 AAL 5 protocol monitoring history Data<sub>B-PON</sub>**

This managed entity contains the last completed 15-minute interval performance monitoring data collected as a result of performing Segmentation and Reassembly (SAR) Level and Convergence Sublayer (CS) protocol monitoring. All of the attribute counters, e.g., the CRC violations, are only updated at the end of each period.

Instances of this managed entity are created automatically by the OLT whenever an instance of the Interworking VCC Termination Point managed entity is created that represents the AAL 5 functions. Instances of this managed entity are deleted by the OLT.

### *Relationships*

One instance of this managed entity can exist for each instance of the Interworking VCC Termination Point managed entity that represents AAL 5 functions.

### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the Managed Entity id of the corresponding Interworking VCC Termination Point. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Sum of Invalid CS Field Errors:** This attribute provides a sum-of-errors count for invalid Convergence Sublayer (CS) field errors. For AAL Type 5, this attribute provides a single count of the number of CS PDUs discarded due to one of the following error conditions: Invalid Common Part Indicator (CPI), oversized received SDU, or length violation. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**CRC Violations:** This attribute represents a count of CRC violations that were detected for the incoming SAR PDUs. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**Reassembly Timer Expirations:** This attribute provides a count of reassembly timer expirations. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory if reassembly timer is implemented) (4 bytes)

**BufferOverflows:** This attribute indicates the number of times that there was not enough buffer space for a reassembled packet. Default value is 0x00. (R) (mandatory) (4 bytes)

**EncapProtocolErrors:** This attribute indicates the number of times that the RFC 1483 encapsulation protocol detects a bad header. Default value is 0x00. (R) (mandatory) (4 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### *Notifications*

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-minute period since that is when the actual counters are reset to 0x00. The alarm list for this entity is given in Table 13.

**Table 13/G.983.2 – Alarm list for AAL 5 protocol monitoring history data<sub>B-PON</sub>**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	Invalid Fields	Exceeds threshold	1
1	CRC Violation	Exceeds threshold	2
2	Reassembly Timer Expirations	Exceeds threshold	3
3	Buffer Overflows	Exceeds threshold	4
4	Encap Protocol Errors	Exceeds threshold	5
5-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.12 CES Service Profile<sub>B-PON</sub>

An instance of this managed entity is used to organize data that describe the CES Service functions of the ONT. An instance of this managed entity shall be created and deleted by the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall be contained in the ONT<sub>B-PON</sub> managed entity. One instance of this managed entity may be associated with zero or more instances of the Interworking VCC Termination Point.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for the instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**CES Buffered CDV Tolerance:** This attribute represents the duration of user data that must be buffered by the CES interworking entity to offset the Cell Delay Variation. This timing will be in 10 µs increment. The default value for DS1 CES is 750 µs and 1000 µs for DS3 CES. (R, W, Set-by-create) (mandatory) (2 bytes)

**Channel Associated Signalling:** This attribute selects which AAL 1 format should be used. It applies to structured interfaces only. For unstructured interfaces, this value, if present, must be set to the default of 0x00. The valid values are basic (0x00), e1Cas (0x01), SfCas (0x02), ds1EsfCas (0x03), and j2Cas (0x04). (R, W, Set-by-create) (optional) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### 7.3.13 This clause intentionally left blank

### 7.3.14 Ethernet performance monitoring history data

This managed entity contains the last completed 15-minute interval collected statistic data for an Ethernet interface. The statistic data value is only updated at the end of each period.

Instances of this managed entity are created/deleted by the OLT after an instance of Physical Path Termination Point Ethernet UNI managed entity is created/deleted.

#### *Relationships*

One instance of this Ethernet Performance Monitoring History Data managed entity can exist for each instance of the Physical Path Termination Point Ethernet UNI.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is the same as the id of the Physical Path Termination Point Ethernet UNI. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the statistic data values are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The statistic data value is updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**FCSErrors:** This attribute provides a count of frames received on a particular interface that are an integral number of octets in length but do not pass the Frame Check Sequence (FCS) check. The count represented by an instance of this object is incremented when the MAC service returns the frameCheckError status to the Link Layer Control (LLC) or other MAC user. Received frames for which multiple error conditions are obtained are counted exclusively according to the error status presented to the LLC. Default value is 0x00. (R) (mandatory) (4 bytes)

**Excessive Collision Counter:** This attribute provides a count of frames for which transmission on a particular interface fails due to excessive collisions. Default value is 0x00. (R) (mandatory) (4 bytes)

**Late Collision Counter:** This attribute indicates the number of times that a collision is detected on a particular interface later than 512 bit-times into the transmission of a packet. Default value is 0x00. (R) (mandatory) (4 bytes)

**FrameTooLongs:** This attribute provides a count of frames received on a particular interface that exceed the maximum permitted frame size. The count is incremented when the MAC service returns the frameTooLong status to the LLC. Default value is 0x00. (R) (mandatory) (4 bytes)

**BufferOverflows on Receive:** This attribute provides a count of the number of times that the buffer overflows on receive. Default value is 0x00. (R) (mandatory) (4 bytes)

**BufferOverflows on Transmit:** This attribute provides a count of the number of times that the buffer overflows on transmit. Default value is 0x00. (R) (mandatory) (4 bytes)

**Single Collision Frame Counter:** This attribute provides a count of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision. Default value is 0x00. (R) (mandatory) (4 bytes)

**Multiple Collisions Frame Counter:** This attribute provides a count of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision. Default value is 0x00. (R) (mandatory) (4 bytes)

**SQECOUNTER:** This attribute provides a count of times that the SQE TEST ERROR message is generated by the PLS sublayer for a particular interface. Default value is 0x00. (R) (mandatory) (4 bytes)

**Deferred Transmission Counter:** This attribute provides a count of frames for which the first transmission attempt on a particular interface is delayed because the medium is busy. The count represented by an instance of this object does not include frames involved in collisions. Default value is 0x00. (R) (mandatory) (4 bytes)

**InternalMACTransmit ErrorCounter:** This attribute provides a count of frames for which transmission on a particular interface fails due to an internal MAC sublayer transmit error. Default value is 0x00. (R) (mandatory) (4 bytes)

**CarrierSenseError Counter:** This attribute indicates the number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame on a particular interface. Default value is 0x00. (R) (mandatory) (4 bytes)

**AlignmentError Counter:** This attribute provides a count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. Default value is 0x00. (R) (mandatory) (4 bytes)

**InternalMACReceive ErrorCounter:** This attribute provides a count of frames for which reception on a particular interface fails due to an internal MAC sublayer receive error. Default value is 0x00. (R) (mandatory) (4 bytes)

### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

### *Notifications*

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 13a.



**Table 13a/G.983.2 – Alarm list for Ethernet performance monitoring history data**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	FCS Errors	Exceeds threshold	1
1	Excessive Collision Counter	Exceeds threshold	2
2	Late Collision Counter	Exceeds threshold	3
3	FrameTooLongs	Exceeds threshold	4
4	Buffer Overflows on Receive	Exceeds threshold	5
5	Buffer Overflows on Transmit	Exceeds threshold	6
6	Single Collision Frame Counter	Exceeds threshold	7
7	Multiple Collisions Frame Counter	Exceeds threshold	8
8	SQE Counter	Exceeds threshold	9
9	Deferred Transmission Counter	Exceeds threshold	10
10	Internal MAC Transmit Error Counter	Exceeds threshold	11
11	Carrier Sense Error Counter	Exceeds threshold	12
12	Alignment Error Counter	Exceeds threshold	13
13	Internal MAC Receive Error Counter	Exceeds threshold	14
14-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

**7.3.15 CES physical interface monitoring history data**

This managed entity contains the last completed 15-minute interval collected statistic data for a physical interface (e.g., DS1/E1/J1/J2) of the CES UNI.

Instances of this managed entity are created/deleted by the OLT after an instance of the Physical Path Termination Point CES UNI managed entity is created/deleted.

The performance management of the physical interfaces used by the CES UNI shall be supported. Possible interfaces include DS1/DS3/E1/E3/J1/J2. The performance management requirements of particular interfaces are described in the corresponding ITU-T Recommendation or other standard document (e.g., ITU-T Rec. G.784 [1]). Failure/notifications should include threshold alerts for unacceptable performance (error) rates. Performance data should include transmission counts of Errored Seconds (ES), Severely Errored Seconds (SES) and Unavailable Seconds (UAS).

Notice that, because of the various operators' requirements and cost advantages, each vendor's ONT may support different levels of performance management of the physical interfaces. It is not stated here that the errored seconds stated below have to be generated for all the possible combinations such as near-end path, far-end path, near-end line, far-end line, etc. Each vendor may use vendor-specific combinations for its implemented features.

*Relationships*

One instance of this managed entity shall exist for each instance of the Physical Path Termination Point CES UNI.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is the same as the id of the Physical Path Termination Point CES UNI. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Error Seconds:** The number of Errored Seconds encountered by a physical interface in the last completed 15-minute interval. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (2 bytes)

**Severely Error Seconds:** The number of Severely Errored Seconds encountered by a physical interface in the last completed 15-minute interval. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (2 bytes)

**Bursty Error Seconds:** The number of Bursty Errored Seconds encountered by a physical interface in the last completed 15-minute interval. A BES is any second that is not a UAS that contains between 2 and 319 error events but no LOS, AIS, or OOF condition. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (Optional) (2 bytes)

**Unavailable Seconds:** The number of Unavailable Seconds encountered by a physical interface in the last completed 15-minute interval. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (2 bytes)

**Controlled Slip Seconds:** The number of Controlled Slip Seconds encountered by a physical interface in the last completed 15-minute interval. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (2 bytes)

## Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

## Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. Both ONT and OLT should know the event list used by this entity. The list of TCAs for this entity is given in Table 14.

**Table 14/G.983.2 – Alarm list for CES physical interface monitoring history data**

Number	Event	Description	Threshold Data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	ES	Exceeds threshold	1
1	SES	Exceeds threshold	2
2	BES	Exceeds threshold	3
3	UAS	Exceeds threshold	4
4	CSS	Exceeds threshold	5
5-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.16 TC adapter protocol monitoring history data

This managed entity contains the last completed 15-minute interval collected performance monitoring as a result of performing Transmission Convergence level protocol monitoring. All the attribute counters, e.g., the discarded cells due to HEC violations, are only updated at the end of each period.

Instances of this managed entity are created/deleted by the OLT after an instance of the corresponding TC Adapter<sub>B-PON</sub> managed entity is created/deleted.

## Relationships

One instance of this managed entity can exist for each instance of TC Adapter<sub>B-PON</sub> or PON TC Adapter.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is the same as the id of the corresponding TC Adapter<sub>B-PON</sub> or PON TC Adapter. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Discarded Cells due to HEC violations:** This read-only attribute provides a raw, thresholded count of the number of ATM cells that were discarded (per interface) due to an HEC violation. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**Errored Cells due to HEC violations:** This read-only attribute provides a raw, thresholded count of the number of ATM cells that were errored (per interface) due to an HEC violation. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. Both ONT and OLT should know the event list, given in Table 15, used by this entity.

**Table 15/G.983.2 – Alarm list for TC adapter protocol monitoring history data**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	Discarded Cells due to HEC violations	Exceeds threshold	1
1	Errored cells due to HEC violations	Exceeds threshold	2
2-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data B-PON managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.17 Threshold Data<sub>B-PON</sub>

An instance of this managed entity contains threshold values for the performance monitoring parameters maintained in one or more instances of other managed entities.

Instances of this managed entity are created and deleted by request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall be contained in the ONT<sub>B-PON</sub> managed entity. This managed entity may be related to multiple instances of History Data type managed entities, which have a Threshold Data<sub>B-PON</sub> id attribute that points to an instance of this managed entity.

#### Related Managed Entities:

- AAL 1 Protocol Monitoring History Data<sub>B-PON</sub>;
- AAL 5 Protocol Monitoring History Data<sub>B-PON</sub>;
- CES Physical Interface Monitoring History Data;
- Ethernet Performance Monitoring History Data;
- TC Adapter Protocol Monitoring History Data;
- UPC Disagreement Monitoring History Data<sub>B-PON</sub>;
- AAL 2 CPS Protocol Monitoring History Data<sub>B-PON</sub>;
- AAL 2 SSCS Protocol Monitoring History Data<sub>B-PON</sub>;
- MAC Bridge PM History Data;
- MAC Bridge Port PM History Data;
- Voice PM History Data;
- VP PM History Data;
- IP Router PM History Data 1;
- IP Router PM History Data 2;
- ICMP PM History Data 1;
- ICMP PM History Data 2;
- VC PM History Data;
- Ethernet Performance Monitoring History Data 2;
- 802.11 Counters;
- ADSL ATU-C Channel Performance Monitoring History Data;
- ADSL ATU-C Performance Monitoring History Data;
- ADSL ATU-R Channel Performance Monitoring History Data;
- ADSL ATU-R Performance Monitoring History Data;
- TC Adaptor Performance Monitoring History Data ADSL;
- VDSL VTU-O Channel Performance Monitoring History Data;
- VDSL VTU-O Physical Interface Monitoring History Data;
- VDSL VTU-R Channel Performance Monitoring History Data;
- VDSL VTU-R Physical Interface Monitoring History Data.

## *Attributes*

**Managed Entity id:** This attribute provides a unique number for the instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**Threshold Value 1:** This attribute provides the associated threshold value for the 1st thresholded counter in the History Data type managed entity. (R, W, Set-by-create) (mandatory) (4 bytes)

**Threshold Value 2:** This attribute provides the associated threshold value for the 2nd thresholded counter in the History Data type managed entity. (R, W, Set-by-create) (mandatory) (4 bytes)

**Threshold Value 3:** This attribute provides the associated threshold value for the 3rd thresholded counter in the History Data type managed entity. (R, W, Set-by-create) (mandatory) (4 bytes)

**Threshold Value 4:** This attribute provides the associated threshold value for the 4th thresholded counter in the History Data type managed entity. (R, W, Set-by-create) (mandatory) (4 bytes)

**Threshold Value 5:** This attribute provides the associated threshold value for the 5th thresholded counter in the History Data type managed entity. (R, W, Set-by-create) (mandatory) (4 bytes)

**Threshold Value 6:** This attribute provides the associated threshold value for the 6th thresholded counter in the History Data type managed entity. (R, W, Set-by-create) (mandatory) (4 bytes)

**Threshold Value 7:** This attribute provides the associated threshold value for the 7th thresholded counter in the History Data type managed entity. (R, W, Set-by-create) (mandatory) (4 bytes)

**Threshold Value 8:** This attribute provides the associated threshold value for the 8th thresholded counter in the History Data type managed entity. The default value is 0. (R, W) (mandatory) (4 bytes)

**Threshold Value 9:** This attribute provides the associated threshold value for the 9th thresholded counter in the History Data type managed entity. The default value is 0. (R, W) (mandatory) (4 bytes)

**Threshold Value 10:** This attribute provides the associated threshold value for the 10th thresholded counter in the History Data type managed entity. The default value is 0. (R, W) (mandatory) (4 bytes)

**Threshold Value 11:** This attribute provides the associated threshold value for the 11th thresholded counter in the History Data type managed entity. The default value is 0. (R, W) (mandatory) (4 bytes)

**Threshold Value 12:** This attribute provides the associated threshold value for the 12th thresholded counter in the History Data type managed entity. The default value is 0. (R, W) (mandatory) (4 bytes)

**Threshold Value 13:** This attribute provides the associated threshold value for the 13th thresholded counter in the History Data type managed entity. The default value is 0. (R, W) (mandatory) (4 bytes)

**Threshold Value 14:** This attribute provides the associated threshold value for the 14th thresholded counter in the History Data type managed entity. The default value is 0. (R, W) (mandatory) (4 bytes)

### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

### *Notifications*

None.

## **7.3.18 AAL 2 Profile<sub>B-PON</sub>**

This managed entity organizes data that describe the AAL Type 2 processing functions of the ONT. It is used with the Interworking VCC Termination Point managed entity. In an ATM environment, AAL Type 2 configuration parameters are associated with an Interworking VCC Termination Point managed entity through a pointer relationship. Each instance of the managed entity defines a combination of parameter values that may be associated with multiple Interworking VCC Termination Point instances. This managed entity is instantiated/deleted on request of the OLT. These attributes must be provisioned for both PVC and SVC VCCs.

### *Relationships*

One instance of this managed entity shall exist for each combination of AAL 2 parameter values used within an ONT associated with a VCC that is either an SVC or a PVC. One instance of this managed entity may be associated with one or more instances of an Interworking VCC Termination Point.

### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**SSCSPParameterProfile1Ptr:** This attribute points to the SSCSPParameterProfile1 instance containing the default values for the Service Specific Convergence Sublayer parameters associated with channels carrying control and management plane traffic (e.g., CCS, ELCP, ISDN D-channels, and LES-EOC). (R, Set-by-create) (mandatory) (2 bytes)

**SSCSPParameterProfile2Ptr:** This attribute points to the SSCSPParameterProfile2 instance containing the default values for the Service Specific Convergence Sublayer parameters associated with channels carrying media streams (e.g., POTS or ISDN B-channels). (R, Set-by-create) (mandatory) (2 bytes)

### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

### *Notifications*

None.

## **7.3.19 AAL 2 PVC Profile<sub>B-PON</sub>**

This managed entity organizes data that describe the AAL Type 2 processing functions of the ONT. It is used with the Interworking VCC Termination Point managed entity. In an ATM environment, AAL Type 2 configuration parameters are associated with an Interworking VCC Termination Point managed entity through a pointer relationship. Each instance of the managed entity defines a

combination of parameter values that may be associated with multiple Interworking VCC Termination Point instances. This managed entity is instantiated/deleted on request of the OLT. These attributes must be provisioned for PVCs (including soft-PVCs).

### *Relationships*

One instance of this managed entity shall exist for each combination of AAL 2 parameter values used within an ONT associated with a VCC that is a PVC. One instance of this managed entity may be associated with one or more instances of an Interworking VCC Termination Point.

### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the AAL 2 Profile<sub>B-PON</sub> with which this AAL 2 PVC Profile<sub>B-PON</sub> is associated. (R, Set-by-create) (mandatory) (2 bytes)

**AppId:** This attribute specifies the protocol combinations used between the Interworking Functions found in the Voice Gateway and the ONT. Valid values include those provided in Section 4.1.1 of ATM Forum Well-Known Addresses and Assigned Codes. (R, Set-by-create) (mandatory) (1 byte)

**MaximumNumChan:** This attribute provides the maximum number of AAL 2 channels that can be carried by the VC Trail associated with the Interworking VCCTP. It ranges from 0x01 to 0xFF (1 to 255). (R, Set-by-create) (mandatory) (1 byte)

**MinimumChanIdVal:** This attribute provides the minimum value for the Channel Id allowed for any AAL 2 channel within the connection. (R, Set-by-create) (mandatory) (1 byte).

NOTE 1 – Values from 0 to 15 are reserved.

**MaximumChanIdVal:** This attribute provides the maximum value for the Channel Id allowed for the AAL 2 channel within the connection (R, Set-by-create) (mandatory) (1 byte).

NOTE 2 – Values from 224 to 255 are reserved.

**MaxCPS\_SDULen:** This attribute provides the maximum allowed length of the Common Part Sublayer Service Data Unit (or CPS SDU) that will be allowed over the connection in either the upstream or downstream direction of transmission. The value is 0x2d or 0x40 (45 or 64 octets). (R, Set-by-create) (mandatory) (1 byte)

**TimerCULen:** This attribute provides the value (in 10ths of a millisecond) for the "combined use" timer Timer\_CU on the ITU-T Rec. I.363.2. (R, Set-by-create) (mandatory) (2 bytes)

### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

### *Notifications*

None.

## **7.3.20 AAL 2 CPS Protocol Monitoring History Data<sub>B-PON</sub>**

This managed entity contains the last completed 15-minute interval performance monitoring data collected as a result of AAL 2 protocol conversion monitoring. All the attribute counters, e.g., the CPSInPkts, are only updated at the end of each period. Instances of this managed entity are created automatically by the OLT whenever an instance of the Interworking VCC Termination Point managed entity is created that represents the AAL 2 functions. Instances of this managed entity are deleted by the OLT.



## Relationships

One instance of this managed entity can exist for each instance of the Interworking VCC Termination Point managed entity that represents AAL 2 functions.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the Managed Entity id of the corresponding Interworking VCC Termination Point. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**CPSInPkts:** This attribute records the number of CPS packets received by the port group associated with the Interworking VCC Termination Point. (R) (mandatory) (4 bytes)

**CPSOutPkts:** This attribute records the number of CPS packets transmitted by the port group associated with the Interworking VCC Termination Point. (R) (mandatory) (4 bytes)

**ParityErrors:** This attribute records the number of CPS PDUs discarded because of incorrect parity value in the STF field. (See errnum 0 in Table 6/I.363.2 [14].) If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**SeqNumErrors:** This attribute records the number of CPS PDUs received with incorrect sequence number in the STF. (See errnum 1 in Table 6/I.363.2 [14].) If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**CPS\_OSFMismatchErrors:** This attribute records the number of CPS PDUs received for which the number of octets expected for a CPS Packet that overlaps into the next CPS PDU does not match the information contained in the STF field. (See errnum 2 in Table 6/I.363.2 [14].) If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**CPS\_OSFErrors:** This attribute records the number of CPS PDUs discarded because of an incorrect Offset Field (OSF) value in the STF field. (See errnum 3 in Table 6/I.363.2 [14].) If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**CPS\_HECErrors:** This attribute records the number of CPS packets having a header value indicating transmission errors in the header. (See errnum 4 in the Table 6/I.363.2 [14].) If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**OversizedSDUErrors:** This attribute records the number of times the received CPS packet payload exceeds the maximum length indicated in MaxCPS\_SDULen attribute. (See errnum 5 in Table 6/I.363.2 [14].) If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**ReassemblyErrors:** This attribute records the number of times that partial CPS packets are discarded because errors were detected before reassembly could be completed. (See errnum 6 in Table 6/I.363.2 [14].) If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**HECOverlapErrors:** This attribute records the number of times that a CPS packet is received with a HEC that overlaps a CPS PDS boundary. (See errnum 7 in Table 6/I.363.2 [14].) If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**UIErrors:** This attribute records the number of times that a UUI is received with a value that is reserved for future use. (See errnum 8 in Table 6/I.363.2 [14].) If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**CIDErrors:** This attribute records the number of times that a CPS PDU is received with an incorrect CID value. (See errnum 9 in Table 6/I.363.2 [14].) If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since then the actual counters are reset to 0x00. The event list for this entity is given in Table 15a.

**Table 15a/G.983.2 – Alarm list for AAL 2 CPS protocol monitoring history data<sub>B-PON</sub>**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	Reserved		
1	Reserved		
2	ParityErrors	Exceeds threshold	1
3	SeqNumErrors	Exceeds threshold	2
4	CPS_OSFMismatchErrors	Exceeds threshold	3
5	CPS_OSFErrors	Exceeds threshold	4
6	CPS_HECErrors	Exceeds threshold	5

**Table 15a/G.983.2 – Alarm list for AAL 2 CPS protocol monitoring history data<sub>B-PON</sub>**

Number	Event	Description	Threshold data counter # (Note)
7	OversizedSDUErrors	Exceeds threshold	6
8	ReassemblyErrors	Exceeds threshold	7
9	HECOverlapErrors	Exceeds threshold	8
10	UUIErrors	Exceeds threshold	9
11	CIDErrors	Exceeds threshold	10
12-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.21 AAL 2 SSCS Protocol Monitoring History Data<sub>B-PON</sub>

This managed entity contains the last completed 15-minute interval performance monitoring data collected as a result of AAL 2 protocol conversion monitoring. All of the attribute counters are updated only at the end of each period. Instances of this managed entity are created automatically by the OLT whenever an instance of the Interworking VCC Termination Point managed entity is created that represents AAL 2 functions. Instances of this managed entity are deleted by the OLT.

#### *Relationships*

One instance of this managed entity can exist for each instance of the Interworking VCC Termination Point managed entity that represents AAL 2 functions.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the Managed Entity id of the corresponding Interworking VCC Termination Point. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**OversizedSSSARSDU Errors:** This attribute records the number of times that an SSSAR SDU exceeds the maximum length allowed for an SSSAR-SDU of the Segmentation and Reassembly Service Specific Convergence sublayer. See "MaxSSSARSDULen" attribute of AAL 2 SSCS Parameter Profile1 managed entity. (See errnum 10 in Table 3/I.366.1 [15].) If the actual counter saturates, it remains on its maximum value. (R) (optional – used when LES EOC is carried all the way to the ONT) (4 bytes)

**RASTimerExpiry Errors:** This attribute records the number of times that the reassembly timer has expired. See "RASTimer" attribute of AAL 2 SSCS Parameter Profile1 managed entity. (See errnum 11 in Table 3/I.366.1 [15].) If the actual counter saturates, it remains on its maximum value. (R) (optional – used when LES EOC is carried all the way to the ONT) (4 bytes)

**UndersizedSSTEDPDUErrors:** This attribute records the number of times that an SSTED-PDU of length 8 or less has been received. (See errnum 20 in Table 5/I.366.1 [15].) If the actual counter saturates, it remains on its maximum value. (R) (optional – used when LES EOC is carried all the way to the ONT) (4 bytes)

**PDULengthMismatchErrors:** This attribute records the number of times that the value of the Length field in the SSTED-PDU does not match the length of the received SSTED-PDU. (See errnum 21 in Table 5/I.366.1 [15].) If the actual counter saturates, it remains on its maximum value. (R) (optional – used when LES EOC is carried all the way to the ONT) (4 bytes)

**CRCMismatchErrors:** This attribute records the number of times that the value of the CRC field is not equal to the CRC calculated over the received information. If the actual counter saturates, it remains on its maximum value. (R) (optional – used when LES EOC is carried all the way to the ONT) (4 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since then the actual counters are reset to 0x00. The event list for this entity is given in Table 15b.

**Table 15b/G.983.2 – Alarm list for AAL 2 SSCS protocol monitoring history data<sub>B-PON</sub>**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	OversizedSSARSDErrors	Exceeds threshold	1
1	RASTimerExpiryErrors	Exceeds threshold	2
2	UndersizedSSTEDPDUErrors	Exceeds threshold	3
3	PDULengthMismatchErrors	Exceeds threshold	4
4	CRCMismatchErrors	Exceeds threshold	5

**Table 15b/G.983.2 – Alarm list for AAL 2 SCS protocol monitoring history data<sub>B-PON</sub>**

Number	Event	Description	Threshold data counter # (Note)
5-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

**7.3.22 AAL 2 SCS Parameter Profile1**

This managed entity groups default values for Service Specific Convergence Sublayer parameters for channels carried in an AAL 2 VCC that provide control and management plane traffic. These parameters are defined in ITU-T Rec. I.366.1 [15]. Instances of this managed entity are created and deleted by request of the OLT.

*Relationships*

Zero or more instances of this managed entity shall exist for each instance of the AAL 2 Profile<sub>B-PON</sub> used within an ONT. One instance of this managed entity may be associated with one or more instances of an Interworking VCC Termination Point.

*Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**SegmentLength:** This attribute provides the segment length for the Segmentation and Reassembly Service Specific Convergence sublayer. It ranges from 0 to the maximum value provided by MaxCPS\_SDULen attribute. (R, Set-by-create) (mandatory) (1 byte)

**RASTimer:** This attribute provides the reassembly time (in seconds) of the Segmentation and Reassembly Service Specific Convergence sublayer for ITU-T Rec. I.366.1 [15]. (R, Set-by-create) (mandatory) (1 byte)

**MaxSSARSDULen:** This attribute provides the maximum length allowed for an SSSAR-SDU of the Segmentation and Reassembly Service Specific Convergence sublayer. It ranges from 0x01 to 0x010020 (1 to 65 568). (R, Set-by-create) (mandatory) (3 bytes)

**SSTEDInd:** This Boolean attribute indicates whether or not the transmission error detection mechanisms have been selected, with value TRUE indicating selection. (R, Set-by-create) (mandatory) (1 byte)

**SSADTInd:** This Boolean attribute indicates whether or not the assured data transfer mechanism has been selected, with value TRUE indicating selection. (R, Set-by-create) (mandatory) (1 byte)

*Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

*Notifications*

None.

### 7.3.23 AAL 2 SCS Parameter Profile2

This managed entity groups default values for Service Specific Convergence Sublayer parameters for channels carried in an AAL 2 VCC that provide media streams. These parameters are defined in ITU-T Rec. I.366.2 [17]. Instances of this managed entity are created and deleted by request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall exist for each instance of the AAL 2 Profile<sub>B-PON</sub> used within an ONT. One instance of this managed entity may be associated with one or more instances of an Interworking VCC Termination Point.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**ServiceCatType:** This attribute indicates the type of service category provided by AAL 2. Valid values include but are not limited to "Audio" (value is 0x01) and "Multirate" (value is 0x02). (R, Set-by-create) (mandatory) (1 byte)

**EncSrcType:** This attribute indicates the source for the encoding profile format. Valid values include but are not limited to "ITU-T" predefined (value 0x01) and "ATM Forum" predefined (value 0x02). (R, Set-by-create) (mandatory) (1 byte)

**EncProfileIndex:** This attribute indicates the specific predefined encoding profile used. Table 15c provides a list of possible values. (R, Set-by-create) (mandatory) (1 byte)

**AudioServInd:** This Boolean attribute indicates whether or not audio service is transported, where the value TRUE implies the presence of this service. (R, Set-by-create) (mandatory) (1 byte)

**PCMEncType:** This attribute indicates the type of PCM coding. Valid values include but are not limited to "mu-law PCM coding" (value 0x01) and "alpha-law PCM coding" (value 0x02). (R, Set-by-create) (mandatory) (1 byte)

**CMDataInd:** This Boolean attribute indicates whether or not Circuit Mode Data is carried on this connection, where the value TRUE implies its presence. (R, Set-by-create) (mandatory) (1 byte)

**CMMultiplierNum:** This attribute provides the N value in  $N \times 64$  kbit/s circuit mode data. (R, Set-by-create) (mandatory) (1 byte)

**FMDataInd:** This Boolean attribute indicates whether or not Frame Mode Data is carried on this connection, where the value TRUE implies its presence. (R, Set-by-create) (mandatory) (1 byte)

**FMMaxFrameLen:** This attribute indicates the maximum length of a frame mode data unit. It ranges from 0x01 to 0xFFFF (1 to 65535). (R, Set-by-create) (mandatory) (2 bytes)

**CASInd:** This Boolean attribute indicates whether or not Channel Associated Signalling is enabled on the connection, where the value TRUE implies it is enabled. (R, Set-by-create) (mandatory) (1 byte)

**DTMFInd:** This Boolean attribute indicates whether or not Dual Tone Multi-Frequency dialed digits are transported on the connection, where the value TRUE implies their presence. (R, Set-by-create) (mandatory) (1 byte)

**MFR1Ind:** This Boolean attribute indicates whether or not Multi-Frequency R1 dialed digits are transported on the connection, where the value TRUE implies their presence. (R, Set-by-create) (mandatory) (1 byte)

**MFR2Ind:** This Boolean attribute indicates whether or not Multi-Frequency R2 dialed digits are transported on the connection, where the value TRUE implies their presence. (R, Set-by-create) (mandatory) (1 byte)

**RateControlInd:** This Boolean attribute indicates whether or not rate control is transported on the connection, where the value TRUE implies its presence. (R, Set-by-create) (mandatory) (1 byte)

**SynchChangeInd:** This Boolean attribute indicates whether or not synchronization of change in SSCS operation is transported on the connection, where the value TRUE implies its presence. (R, Set-by-create) (mandatory) (1 byte)

**FaxDemodulationInd:** This Boolean attribute indicates whether fax demodulation is enabled or disabled on the connection, where the value TRUE implies it is enabled. (R, Set-by-create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

#### *Notifications*

None.

**Table 15c/G.983.2 – Coding of the EncProfileIndex attribute**

EncSrcType	EncProfileIndex	
1: ITU-T predefined	0:	Not used.
	1:	PCM-64
	2:	PCM-64 and silence
	3:	ADPCM and silence
	4:	G.728 with higher efficiency
	5:	G.728 with lower delay
	6:	G.729 with higher efficiency and G.726 for voiceband data
	7:	G.729 with lower delay
	8:	G.729 with lower delay and G.726-32 for voiceband data at lower rates.
	9:	G.729 with lower delay and G.726-40 for voiceband data at higher rates.
	10:	G.729 with full variable bit rates
	11:	AMR
	12:	G.723
	13:	PCM 64 kbits/s and ADPCM 32 kbits/s
	14-255:	Reserved for future ITU-T assignment

**Table 15c/G.983.2 – Coding of the EncProfileIndex attribute**

<b>EncSrcType</b>	<b>EncProfileIndex</b>	
2: ATM Forum predefined	0:	Not used.
	1:	LPC-10 (High efficiency)
	2:	LPC-10 (Low delay)
	3:	CVSD-32
	4:	CVSD-16
	5:	CVSD-12
	6:	G.723.1
	7:	PCM-64, ADPCM-32, 44 octet packets, and silence.
	8:	PCM-64, 44 octet packets, and silence.
	9:	PCM-64, 44 octet packets, without silence.
	10:	PCM-64 and ADPCM-32, 44 octet packets, without silence.
	11:	PCM-64, ADPCM-32, 40 octet packets, without silence.
	12:	PCM-64, ADPCM-32, 40 octet packets, with silence.
	13-255:	Reserved for future ATM Forum assignment.

### 7.3.24 Voice service profile AAL

This managed entity is used to organize data that describes the Voice Service functions of the ONT if supported by AAL 2 or AAL 1. Instances of this managed entity are created and deleted by request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall be contained in the ONT<sub>B-PON</sub> managed entity. One instance of this managed entity may be associated with zero or more instances of the Interworking VCC Termination Point carrying voice services.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for the instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**AnnouncementType:** This attribute provides the announcement to the customer going off-hook when no call has been attempted. Valid values include but are not limited to "silence" (0x01), "reorderTone" (0x02), "fastBusy" (0x03), "voiceAnnouncement" (0x04), and "N/A" (0xFF). (R, Set-by-create) (mandatory) (1 byte)

**JitterTarget:** This attribute provides the target value of the jitter buffer. The system will try to maintain the jitter buffer at the target value. Units are in milliseconds. (R, W, Set-by-create) (mandatory for AAL 2) (2 bytes)

**JitterBufferMax:** This attribute provides the maximum depth of the jitter buffer associated with this service. Units are in milliseconds. (R, W, Set-by-create) (mandatory for AAL 2) (2 bytes)



**EchoCancelInd:** This Boolean attribute indicates whether echo cancellation is on or off, where the value TRUE implies that it is on. (R, Set-by-create) (mandatory) (1 byte)

**PSTNProtocolVariant:** This attribute controls which variant of POTS signalling shall be used on the associated UNIs. The value used is equal to the 'country code'. (R, Set-by-Create) (optional) (2 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### **7.3.25 LES service profile**

This managed entity is used to organize data that describes voice grade Loop Emulation Service functions of the ONT associated with AAL 2 interworking. Instances of this managed entity shall be created and deleted by the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall be contained in the ONT<sub>B-PON</sub> managed entity. One instance of this managed entity may be associated with zero or more instances of the Interworking VCC Termination Point.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the Voice Service Profile AAL with which this LES Service Profile is associated. (R, Set-by-create) (mandatory) (2 bytes)

**ELCPInd:** This Boolean attribute indicates whether or not Emulated Loop Control Protocol is in use. The value TRUE means enabled. (R, Set-by-create) (mandatory) (1 byte)

**POTSSignalling:** This attribute selects which signalling format should be used for POTS service. Valid values include but are not limited to CCS (value 0x01), CAS (value 0x02), and other (0xFF). (R, Set-by-create) (mandatory) (1 byte)

**BRISignalling:** This attribute selects which signalling format should be used for Basic Rate ISDN. Valid values include but are not limited to DSS1 (0x01), and other (0xFF). The default value is 0x01. (R, W) (mandatory) (1 byte)

**MaxNumCIDs:** This attribute specifies the maximum number of channels within the VCC that can be active. (R, Set-by-create) (mandatory) (1 byte)

**MaxPacketLength:** This attribute specifies the maximum packet length (in bytes). (R, Set-by-create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

## Notifications

None.

### 7.3.26 Physical path termination point POTS UNI

This managed entity represents the point at the POTS UNI in the ONT where physical paths terminate and physical path level functions (e.g., analog telephony, facsimile function) are performed. An instance of this managed entity shall be automatically created/deleted by the ONT upon the creation/deletion of a Subscriber Line Card with POTS type.

## Relationships

One or more instances of this managed entity shall be contained in an instance of the ONT<sub>B-PON</sub> or a Subscriber Line Card managed entity classified as POTS type.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot id (defined in 7.1.3). If the UNI is integrated, this value is 0x00. The second byte is the port id with value range from 0x01 to 0xFF (1 to 255), 0x01 is used for the leftmost/lowest port on a Subscriber Line Card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) the functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Interworking VCC Pointer:** This attribute provides a pointer to the instance of the Interworking VCC managed entity to which this instance is connected. The value 0x0000 is interpreted as a Null pointer. (R, W) (optional) (2 bytes)


**ARC:** This attribute is used to control alarm reporting from this managed entity. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ARCInterval:** This attribute provides a provisionable length of time. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**Impedance:** This attribute allows the impedance for the Physical Path Termination Point POTS UNI to be configured by the user. Valid values include 600 Ohm Impedance (value 0x00) and 900 Ohm Impedance (value 0x01). In addition, the following parameter sets from ETSI TS 101 270-1 (1999-10), Annex C, are valid:

- value 0x02: C1=150 nF, R1=750 Ohm, R2=270 Ohm;
- value 0x03: C1=115 nF, R1=820 Ohm, R2=220 Ohm;
- value 0x04: C1=230 nF, R1=1050 Ohm, R2=320 Ohm,

where C1, R1, and R2 are related as shown below. Upon autonomous instantiation, the value 0x00 is used. (R,W) (optional) (1 byte)



**Transmission Path:** This attribute allows for setting the Physical Path Termination Point POTS UNI to be put in either full-time or part-time on-hook transmission mode. Valid values include full-time on-hook transmission (value 0x00) and part-time on-hook transmission (value 0x01) Upon autonomous instantiation, the value 0x00 is used. (R,W) (optional) (1 byte)

**Rx Gain:** This attribute provides a gain value for the received signal. Valid values are –12 dB to +6 dB in 0.1 dB increments. (value –120 to +60, 0 = 0 dB gain, –120 = –12.0 dB, etc.) Upon autonomous instantiation, the value 0x00 is used. (R,W) (optional) (1 byte)

**Tx Gain:** This attribute provides a gain value for the transmit signal. Valid values are –6 dB to +12 dB in 0.1 dB increments. (value –60 to +120, 0 = 0 dB gain, 60 = +6.0 dB, etc.). Upon autonomous instantiation, the value 0x00 is used. (R,W) (optional) (1 byte)

#### Actions

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Test:** Request that the ONT perform one or more MLT tests or a dial tone make/break test. See "Test" and "Test result" message layouts in II.2.27 and II.2.45 respectively.

#### Notifications

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 15d. See also Appendix III.

**Table 15d/G.983.2 – Alarm list for physical path termination point POTS UNI**

Number	Alarm	Description
0-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.27 Voice CTP

This managed entity is used to represent the point in the ONT where the voice channel is terminated/originated. Instances of this managed entity are created and deleted by request of the OLT.

#### Relationships

Zero or more instances of this managed entity shall be contained in an instance of the ONT<sub>B-PON</sub> or Subscriber Line Card managed entity classified as a POTS type.

#### Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**InterworkingVCCTPPtr:** This attribute points to the instance of the Interworking VCC Termination Point carrying this voice channel. (R, Set-by-create) (mandatory) (2 bytes)

**InterworkingPPTPptr:** This attribute provides a pointer to the associated instance of the Termination Point managed entity for the case of POTS or ISDN services. When this Voice CTP is associated with a Subscriber Line Card managed entity classified as a POTS type, this attribute points to the instance of the Physical Path Termination Point POTS UNI. When this Voice CTP is associated with a Subscriber Line Card managed entity classified as ISDN type, this attribute points to the instance of the Physical Path Termination Point ISDN UNI. (R, Set-by-create) (mandatory) (2 bytes)

**ChannelId:** This attribute identifies the logical Channel Id for this service if AAL 2 is employed. This attribute is null (not used) if another type of adaptation is employed. (R, Set-by-create) (mandatory) (1 byte)

**SignallingCode:** This attribute specifies whether "loop start" (0x01), "ground start" (0x02), "loop reverse battery" (0x03), "coin first" (0x04), "dial tone first" (0x05), or "multi-party" (0x06) signalling is employed. (R, Set-by-create) (mandatory) (1 byte)

**RobbedBitSignalling:** This attribute describes the robbed bit signalling in use on the telephony port. Valid values include "a" (value 0x01), "ab" (value 0x02), "abcd" (value 0x03), "transparent" (value 0x04), and "other" (value 0xFF). (R, Set-by-create) (mandatory) (1 byte)

**SilenceSuppression Ind:** This Boolean attribute indicates whether silence suppression is on or off. The value TRUE means on. (R, Set-by-create) (mandatory) (1 byte)

**VoiceCompression Type:** This attribute identifies the voice compression applied to the voice channel. Valid values include but are not limited to the following: PCM-64 (value 0x01), ADPCM-32 (value 0x02), LD-CELP16 (value 0x03), CS-ACELP8 (value 0x04), and unknown (value 0xFF). (R, Set-by-create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

#### *Notifications*

None.

### **7.3.28 Voice PM history data**

This managed entity contains the last completed 15-minute interval performance monitoring data collected as a result of monitoring a voice port on an ONT. The statistic data value is only updated at the end of each period. Instances of this managed entity are created/deleted by the OLT after an instance of a Physical Path Termination Point POTS UNI or Physical Path Termination Point ISDN UNI managed entity is created/deleted.

#### *Relationships*

One instance of this managed entity can exist for each instance of a Physical Path Termination Point POTS UNI or Physical Path Termination Point ISDN UNI.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is the same as the id of a Physical Path Termination Point POTS UNI or Physical Path Termination Point ISDN UNI. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute

interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**VoicePortBufferOverflows:** This attribute provides the total number of payload octets dropped due to buffer overflow at this port (NOTE – this number does not include octets that are dropped because they arrived late and had already been substituted by a filler octet). If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**VoicePortBufferUnderflows:** This attribute provides the total number of filler octets injected into the active media stream on this port due to playout buffer underflow. If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**ActiveSeconds:** This attribute provides the total length of time, in seconds, that the AAL 2 channel associated with this port has been active. If the counter saturates, it remains on its maximum value. (R) (mandatory) (4 bytes)

**DchannelBufferOverflows:** This attribute provides the total number of payload octets for the D channel that are dropped due to buffer overflow at this port (NOTE – this number does not include octets that are dropped because they arrived late and had already been substituted by a filler octet). If the actual counter saturates, it remains on its maximum value. (R) (mandatory, if this voice port carries ISDN traffic) (4 bytes)

**B1ChannelBufferOverflows:** This attribute provides the total number of payload octets for the B1 channel that are dropped due to buffer overflow at this port (NOTE – this number does not include octets that are dropped because they arrived late and had already been substituted by a filler octet). If the actual counter saturates, it remains on its maximum value. (R) (mandatory, if this voice port carries ISDN traffic) (4 bytes)

**B2ChannelBufferOverflows:** This attribute provides the total number of payload octets for the B2 channel that are dropped due to buffer overflow at this port (NOTE – this number does not include octets that are dropped because they arrived late and had already been substituted by a filler octet). If the actual counter saturates, it remains on its maximum value. (R) (mandatory, if this voice port carries ISDN traffic) (4 bytes)

**DchannelBufferUnderflows:** This attribute provides the total number of filler octets injected into the D channel of the active media stream on this port due to playout buffer underflow. If the actual counter saturates, it remains on its maximum value. (R) (mandatory, if this voice port carries ISDN traffic) (4 bytes)

**B1ChannelBufferUnderflows:** This attribute provides the total number of filler octets injected into the B1 channel of the active media stream on this port due to playout buffer underflow. If the actual counter saturates, it remains on its maximum value. (R) (mandatory, if this voice port carries ISDN traffic) (4 bytes)

**B2ChannelBufferUnderflows:** This attribute provides the total number of filler octets injected into the B2 channel of the active media stream on this port due to playout buffer underflow. If the actual counter saturates, it remains on its maximum value. (R) (mandatory, if this voice port carries ISDN traffic) (4 bytes)

**DchannelActiveSeconds:** This attribute provides the total length of time, in seconds, that the D channel associated with this port has been active. If the counter saturates, it remains on its maximum value. (R) (mandatory, if this voice port carries ISDN traffic) (4 bytes)

**B1ChannelActiveSeconds:** This attribute provides the total length of time, in seconds, that the B1 channel associated with this port has been active. If the counter saturates, it remains on its maximum value. (R) (mandatory, if this voice port carries ISDN traffic) (4 bytes)

**B2ChannelActiveSeconds:** This attribute provides the total length of time, in seconds, that the B2 channel associated with this port has been active. If the counter saturates, it remains on its maximum value. (R) (mandatory, if this voice port carries ISDN traffic) (4 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 15e.

**Table 15e/G.983.2 – Alarm list for voice PM history data**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	Reserved		
1	Reserved		
2	VoicePortBufferOverflows	Exceeds threshold	1
3	VoicePortBufferUnderflows	Exceeds threshold	2
4	B1ChannelBufferOverflows	Exceeds threshold	3
5	B2ChannelBufferOverflows	Exceeds threshold	4
6	DchannelBufferUnderflows	Exceeds threshold	5
7	B1ChannelBufferUnderflows	Exceeds threshold	6
8	B2ChannelBufferUnderflows	Exceeds threshold	7
9-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.29 MAC Bridge service profile

This managed entity is used to organize data that affects all ports on a MAC Bridge at a bridged LAN Ethernet UNI interface on the ONT. Instances of this managed entity are created and deleted by request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall be referred to by the Physical Path Termination Point Ethernet UNI managed entity.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The first byte is the slot id (defined in 7.1.3). If the UNI is integrated, this value is 0x00. The second byte is the bridge group id. (R) (mandatory) (2 bytes)

**SpanningTreeInd:** This Boolean attribute indicates whether or not a spanning tree algorithm is enabled. The value TRUE means enabled. (R, W, Set-by-create) (mandatory) (1 byte)

**LearningInd:** This Boolean attribute indicates whether or not the learning functions of the bridge are enabled. The value TRUE means enabled. (R, W, Set-by-create) (mandatory) (1 byte)

**ATMPortBridgingInd:** This Boolean attribute indicates whether or not bridging between ATM ports on this bridge service is enabled. The value TRUE means enabled. (R, W, Set-by-create) (mandatory) (1 byte)

**Priority:** This attribute indicates the bridge priority set on the LAN card. The range is 0x00 to 0xFFFF (0 to 65535). The value of this attribute is copied to the BridgePriority attribute of the MAC Bridge Configuration Data managed entity. (R, W, Set-by-create) (mandatory) (2 bytes)

**MaxAge:** This attribute indicates the maximum age (in 256ths of a second) for an entry in the spanning tree listing. It indicates the maximum age in 256ths of a second for received protocol information before it is discarded. The range is 0x0600 to 0x2800 (6 s to 40 s) in accordance with IEEE 802.1D [13]. (R, W, Set-by-create) (mandatory) (2 bytes)

**HelloTime:** This attribute provides the time interval (in 256ths of a second) between hello packets. It is the time interval, in 256ths of a second, that a bridge advertises its presence while as a root or attempting to become a root. The range is 0x0100 to 0x0a00 (1 s to 10 s) in accordance with IEEE 802.1D [13]. (R, W, Set-by-create) (mandatory) (2 bytes)

**ForwardDelay:** This attribute gives the time (in 256ths of a second) that the bridge on the Ethernet card in the ONT retains a packet before forwarding it. (It indicates the value in 256ths of a second that the bridge uses for Forward Delay when the bridge acts as the root.) The range is 0x0400 to 0x1e00 (4 s to 30 s) in accordance with IEEE 802.1D [13]. (R, W, Set-by-create) (mandatory) (2 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### 7.3.30 MAC Bridge configuration data

This managed entity is used to organize and record data that is associated with bridged LAN configurations. Some of the data is volatile. Instances of this managed entity shall be automatically created/deleted by the ONT upon the creation/deletion of a MACBridgeServiceProfile.

#### *Relationships*

This managed entity is associated with one instance of a MACBridgeServiceProfile.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the MACBridgeServiceProfile with which this MACBridgeConfigurationData is associated. (R) (mandatory) (2 bytes)

**BridgeMACAddress:** This attribute indicates the MAC address used by the bridge. Upon autonomous instantiation, this attribute consists of all 0x00. (R) (mandatory) (6 bytes)

**BridgePriority:** This attribute denotes the priority of the bridge and is positive integer-valued. Upon autonomous instantiation, the value 0x8000 is used. The value of this attribute follows the value of the associated MAC Bridge Service Profile: Priority attribute, if present. (R) (mandatory) (2 bytes)

**DesignatedRoot:** This attribute provides the bridge identifier for the root of the spanning tree. This attribute consists of Bridge Priority (2 bytes) and MAC address (6 bytes). (R) (mandatory) (8 bytes)

**RootPathCost:** This attribute provides the cost of the best path to the root as seen from the bridge. Upon autonomous instantiation, the value 0x00 is used. (R) (mandatory) (4 bytes)

**BridgePortCount:** This attribute provides the number of existing ports controlled by this bridge. (R) (mandatory) (1 byte)

**RootPortNum:** This attribute provides the port number that has the lowest cost from the bridge to the root bridge. The value 0x00 means that the bridge itself is the root. Upon autonomous instantiation, the value 0x00 is used. (R) (mandatory) (2 bytes)

**HelloTime:** This attribute provides the time interval (in 256ths of a second) between hello packets. It is the "HelloTime" received from the designated root. The range is 0x0100 to 0x0a00 (1 s to 10 s) in accordance with IEEE 802.1D [13]. (R) (optional) (2 bytes)

**ForwardDelay:** This attribute gives the time (in 256ths of a second) that the bridge on the Ethernet card in the ONT retains a packet before forwarding it. It is the "ForwardDelay" time received from the designated root. The range is 0x0400 to 0x1e00 (4 s to 30 s) in accordance with IEEE 802.1D [13]. (R) (optional) (2 bytes)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.



### 7.3.31 MAC Bridge port configuration data

This managed entity is used to organize and record data that is associated with a bridge port. Some of the data is volatile. Instances of this managed entity are created and deleted by request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall be contained in an instance of the MACBridgeServiceProfile.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**BridgeIdPointer:** This attribute identifies the MAC bridge controlling the port. This attribute points to the instance of the MACBridgeServiceProfile. (R, Set-by-create) (mandatory) (2 bytes)

**PortNum:** This attribute provides the port number. (R, Set-by-create) (mandatory) (1 byte)

**TPTType:** This attribute identifies the type of the termination point associated with this MAC bridge port. The value is set to 0x01 if this bridge port is associated with the LAN side's termination point. The value is set to 0x02 if this bridge port is associated with the ATM side's termination point. The value is set to 0x03 if this bridge port is associated with an ATM side 802.1p mapper service profile. (R, Set-by-create) (mandatory) (1 byte)

**TPPointer:** This attribute points to the termination point associated with this MAC bridge port. If the TPTType = 0x01, the value of this attribute is the same as the id of the Physical Path Termination Point Ethernet UNI associated with this MAC bridge port. If the TPTType = 0x02, the value of this attribute is the same as the id of the Interworking VCC Termination Point associated with this MAC bridge port. If the TPTType = 0x03, the value of this attribute is the same as the id of the 802.1p mapper service profile associated with this MAC bridge port. (R, Set-by-create) (mandatory) (2 bytes)

**PortPriority:** This attribute denotes the priority of the port. The range is 0x00 to 0x00FF (0 to 255). (R, W, Set-by-create) (mandatory) (2 bytes)

**PortPathCost:** This attribute provides the cost contribution of the port to the path cost towards the spanning tree root bridge. The range is 0x0001 to 0xFFFF (1 to 65535). (R, W, Set-by-create) (mandatory) (2 bytes)

**PortSpanningTreeInd:** This Boolean attribute indicates whether or not STP LAN topology change detection is enabled at this port. The value TRUE means enabled. (R, W, Set-by-create) (mandatory) (1 byte)

**EncapsulationMethod:** This attribute identifies the frame encapsulation method that is used. Value 0x00: identification by ATM VC; value 0x01: LLC encapsulation. This attribute is effective only for ports towards the ANI side of the MAC bridge. Upon autonomous instantiation, the value 0x00 is used. (R,W, Set-By-Create) (mandatory) (1 byte)

**LANFCSInd:** This attribute indicates whether LAN FCS (Frame Check Sequence) bytes are forwarded (value 0x00) or discarded (value 0x01). This applies in both directions of transmission, and applies regardless of EncapsulationMethod. This attribute is effective only for ports towards the ANI side of the MAC bridge. Upon autonomous instantiation, the value 0x00 is used. (R, W, Set-By-Create) (optional) (1 byte)

### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

### *Notifications*

None.

## **7.3.32 MAC Bridge port designation data**

This managed entity is used to organize and record data that is associated with a bridge port. Some of the data is volatile. Instances of this managed entity shall be automatically created/deleted by the ONT upon the creation/deletion of a MACBridgePortConfigurationData.

### *Relationships*

This managed entity is associated with one instance of a MACBridgePortConfigurationData.

### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the MACBridgePortConfigurationData with which this MACBridgePortDesignationData is associated. (R) (mandatory) (2 bytes)

**DesignatedBridgeRootCostPort:** This attribute provides the Designated Root, Designated Cost, Designated Bridge, and Designated Port outputs of the "Read port parameters" operation defined in 14.8.2.1 of IEEE 802.1D [13], i.e.,

- bridge identifier of the designated bridge for the port's segment (8 bytes);
- bridge identifier of the root transmitted by the designated bridge for the segment (8 bytes);
- port number of the designated port on the designated bridge considered to be part of this port's segment (4 bytes);
- path cost contribution of the designated port to this port's segment (4 bytes).

Upon autonomous instantiation, this attribute consists of all 0x00. (R) (mandatory) (24 bytes).

**PortState:** This attribute provides status information on the port. Valid values include "disabled" (value 0x00), "listening" (value 0x01), "learning" (value 0x02), "forwarding" (0x03), "blocking" (value 0x04), "linkdown" (value 0x05), and "stp\_off" (value 0x06) in accordance with IEEE 802.1D [13].

NOTE – The value "linkdown" is introduced to denote the port status where the Ethernet link state is down. This value is necessary to distinguish the case where Ethernet is physically down and the case where Ethernet is administratively down, which can be denoted by "disabled." The value "stp\_off" is introduced to denote the port status where Spanning Tree Protocol is disabled, by setting "PortSpanningTreeInd" of "MAC Bridge Port Configuration Data" to FALSE, and Ethernet link state is up. This value is used to distinguish whether or not a bridge port forwarding frames is under control of STP.

Upon autonomous instantiation, the value 0x00 is used. (R) (mandatory) (1 byte)

### *Actions*

**Get:** Get one or more attributes.

### *Notifications*

None.

### 7.3.33 MAC Bridge port filter table data

This managed entity is used to organize and record data that is associated with a bridge port. Some of the data is volatile. Instances of this managed entity shall be automatically created/deleted by the ONT upon the creation/deletion of a MACBridgePortConfigurationData managed entity.

NOTE – Alternative schemes for this managed entity may be included in future Recommendations. Caution must be exercised when writing to the table attribute when learning is active, as the contents of the table is volatile. If OLT plans to write to the table, learning mode should be off at that time.

#### Relationships

This managed entity is associated with one instance of a MACBridgePortConfigurationData managed entity.

#### Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the MACBridgePortConfigurationData with which this MACBridgePortFilterTableData is associated. (R) (mandatory) (2 bytes)

**MACFilterTable:** This attribute lists destination MAC Addresses associated with the bridge port and an allow/disallow forwarding indicator for each of inbound traffic (towards the LAN physical port) and outbound (towards the ATM side) traffic. One entry provides the Entry number (1 byte) which is an index in this attribute list, Filter byte (1 byte), and MAC address (6 bytes). Moreover, the bits of the Filter byte are assigned as described in Table 15f. Upon autonomous instantiation, this attribute is a null list. An OMCI set message can carry a maximum of 3 entries at the same time. (R, W) (mandatory) ( $N \times 8$  bytes, N is the number of entries in the list.)

**Table 15f/G.983.2 – Coding of filter byte in the MACFilterTable attribute**

Bit	Name	Setting
8	Add/remove	0: remove this entry 1: add this entry
7-2	Reserved	(0)
1	Filter/forward	0: forward 1: filter

#### Actions

**Get:** Get one or more attributes. Latch a snapshot (i.e., copy) of the current MACFilterTable and respond with the size of data (4 bytes), which should be obtained using the "Get next" command.

**Get next:** Get the latched attribute values of the managed entity within the current snapshot.

**Set:** Generally, this action is used to set one or more entire attribute values. When used on the "MACFilterTable" attribute, the "Set" action either adds or deletes table entries from "MACFilterTable". A maximum of 3 table entries can be added/deleted by a single "Set" action.

#### Notifications

None.

### 7.3.34 MAC Bridge port bridge table data

This managed entity is used to organize and record data that is associated with a bridge port. Some of the data is volatile. Instances of this managed entity shall be automatically created/deleted by the ONT upon the creation/deletion of a MACBridgePortConfigurationData.

### Relationships

This managed entity is associated with one instance of a MACBridgePortConfigurationData.

### Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the MACBridgePortConfigurationData with which this MACBridgePortBridgeTableData is associated. (R) (mandatory) (2 bytes).

**BridgeTable:** This attribute lists the destination MAC Addresses, whether they are learned or statically assigned, whether packets having them as destination addresses are filtered or forwarded, and their ages. One entry provides Information (2 bytes) and MAC address (6 bytes). Moreover, the Information bits are assigned as described in Table 15g. Upon autonomous instantiation, this attribute is a null list. (R) (mandatory) ( $M \times 8$  bytes, M is the number of entries in the list.)

**Table 15g/G.983.2 – Coding of information in the BridgeTable attribute**

Bit	Name	Setting
16-5	Age	Age in seconds (1 s to 4095 s)
4	Reserved	(0)
3	Dynamic/static	0: this entry is statically assigned. 1: this entry is dynamically learned.
2	Reserved	(0)
1	Filter/forward	0: forward 1: filter

### Actions

**Get:** Get one or more attributes. Latch a snapshot (i.e., copy) of the current MACFilterTable and respond with the size of the data (4 bytes) that should be obtained using the "Get next" command.

**Get next:** Get the latched attribute values of the managed entity within the current snapshot.

### Notifications

None.

### 7.3.35 MAC Bridge PM history data

This managed entity contains the past performance monitoring data collected at a MAC bridging function supporting bridging interfaces on the ONT. Instances of this managed entity are created/deleted by the OLT after/before an instance of the MACBridgeServiceProfile managed entity is created/deleted.

### Relationships

This managed entity is associated with one instance of a MACBridgeServiceProfile.

### Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the MACBridgeServiceProfile with which this MACBridgePMHistoryData is associated. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and

the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**BridgeLearningEntryDiscardCount:** This attribute records the number of forwarding database entries that have been or would have been learned but were discarded or replaced due to lack of space in the database table. (R) (mandatory) (4 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this managed entity is given in Table 15g1.

**Table 15g1/G.983.2 – Alarm list for MAC Bridge PM history data**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	BridgeLearningEntryDiscard	BridgeLearningEntryDiscard threshold crossing	1
1-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.36 MAC Bridge port PM history data

This is a managed entity that contains the past performance monitoring data collected at the port bridging function on the ONT. Instances of this managed entity are created/deleted by the OLT after an instance of the MACBridgePortConfigurationData managed entity is created/deleted.

#### *Relationships*

This managed entity is associated with one instance of a MACBridgePortConfigurationData.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the MACBridgePortConfigurationData with which this MACBridgePortPMHistoryData is associated. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**ForwardedFrameCounter:** This attribute provides a count of successfully transmitted frames on this port. (R) (mandatory) (4 bytes)

**DelayExceededDiscardCounter:** This attribute provides a count of frames discarded on this port because transmission is delayed. (R) (mandatory) (4 bytes)

**MTUExceededDiscardCounter:** This attribute provides a count of frames discarded on this port because MTU is exceeded. (R) (mandatory) (4 bytes)

**ReceivedFrameCounter:** This attribute provides a count of frames received on this port. (R) (mandatory) (4 bytes)

**ReceivedAndDiscardedCounter:** This attribute provides a count of frames received on this port that have been discarded due to errors. (R) (mandatory) (4 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this managed entity is given in Table 15g2.

**Table 15g2/G.983.2 – Alarm list for MAC Bridge port PM history data**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	Reserved		
1	DelayExceededDiscard	DelayExceededDiscard threshold crossing	1
2	MTUExceededDiscard	MTUExceededDiscard threshold crossing	2
3	Reserved		
4	ReceivedAndDiscarded	ReceivedAndDiscarded threshold crossing	3
5-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.37 IP Port configuration data

This managed entity is used to organize data that is associated with IP address and IP port provisioning. Instances of this managed entity are created and deleted by request of the OLT.

### Relationship

Zero or one instances of this managed entity may exist for each instance of the Interworking VCC Termination Point managed entity and a Subscriber Line Card managed entity classified as a native LAN type (e.g., Ethernet).

### Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**PortNum:** This attribute identifies the port at which IP provisioning takes place. (R, Set-by-create) (mandatory) (1 byte)

**TPType:** This attribute identifies the type of the termination point associated with this IP port. The value is set to 0x01 if this IP port is associated with the LAN side's TP. The value is set to 0x02 if this IP port is associated with the ATM side's TP. (R, Set-by-create) (mandatory) (1 byte)

**TPPointer:** This attribute points to the instance of the TP associated with this port. When this IP port is associated with the LAN side's TP, this attribute points to the instance of the PPTP Ethernet UNI. When this IP port is associated with the ATM side's TP, this attribute points to the instance of the Interworking VCC Termination Point. (R, Set-by-create) (mandatory) (2 bytes)

**PortAddress:** This attribute identifies the provisioned IP address. When an IP address is not assigned, this attribute consists of all 0x00. (R, Set-by-create) (mandatory) (4 bytes)

**PortMask:** This attribute identifies the address mask associated with the provisioned IP address. When an IP address mask is not assigned, this attribute consists of all 0x00. (R, Set-by-create) (mandatory) (4 bytes)

**Unnumbered:** This boolean attribute indicates whether or not this IP port has an IP address. The value TRUE means unnumbered. (For future use by IP router function.) (R, Set-by-create) (mandatory) (1 byte)

**AdministrativeState:** This boolean attribute is used to activate (unlock, value 0x00) and deactivate (lock, value 0x01) the functions performed by instances of this managed entity. (R, W, Set-by-create) (1 byte)

**PortState:** This boolean attribute provides status information on the port. Valid values include "up" (value 0x00) and "down" (value 0x01). (R, Set-by-create) (mandatory) (1 byte)

**AllowRemoteAccess:** This boolean attribute indicates whether or not this IP port may be accessed remotely. The value TRUE means remote access is enabled. (R, Set-by-create) (mandatory) (1 byte)

**Router Id Pointer:** This attribute identifies the IP router controlling the port, if it exists. This attribute points to the instance of the IP Router Service Profile. If no IP router controls the port, this attribute consists of a null pointer (0xFFFF). (R, Set-by-create) (mandatory) (2 bytes)

**ARP Pointer:** This attribute identifies the instance of ARP Service Profile associated with the IP port. (R, Set-by-create) (mandatory) (2 bytes)

**EncapsulationMethod:** This attribute identifies the frame encapsulation method that is used. Value 0x00: identification by ATM VC; value 0x01: LLC encapsulation. Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### **7.3.38 IP router service profile**

This managed entity is used to organize data that affects all ports on an IP router on a routed LAN UNI interface on the ONT. Instances of this managed entity are created and deleted by request of the OLT.

#### *Relationship*

Zero or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as a native LAN type (e.g., Ethernet).

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The first byte is the slot id (defined in 7.1.3). If the UNI is integrated, this value is 0x00. The second byte is the router group id. (R, Set-by-create) (mandatory) (2 bytes)



**ForwardingInd:** This boolean attribute indicates whether or not forwarding of IP packets as a whole is enabled. The value TRUE means enabled. The initial value is enabled. (R, W, Set-by-create) (mandatory) (1 byte)

**ProxyARPInd:** This boolean attribute indicates whether or not proxy ARP is enabled. The value TRUE means enabled. The initial value is enabled. (R, W, Set-by-create) (mandatory) (1 byte)

**DirectedBroadcastInd:** This boolean attribute indicates whether or not relaying of directed broadcast packets is enabled. The value TRUE means enabled. The initial value is disabled. (R, W, Set-by-create) (mandatory) (1 byte)

**UpstreamMulticastFiltering:** This attribute indicates whether upstream IP multicast packets are forwarded (value 0x00) or filtered (value 0x01). The initial value is 0x01. (R,W, Set-by-create) (mandatory) (1 byte)

**DownstreamMulticastFiltering:** This attribute indicates whether downstream IP multicast packets are forwarded (value 0x00) or filtered (value 0x01). The initial value is 0x01. (R,W, Set-by-create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### **7.3.39 IP router configuration data**

This managed entity is used to record data that is associated with IP router configurations. An instance of this managed entity shall be automatically created/deleted by the ONT upon creation/deletion of the associated instance of IP Router Service Profile.

#### *Relationship*

An instance of this managed entity is associated with one instance of IP Router Service Profile.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the IP Router Service Profile with which this IP Router Configuration Data is associated. (R) (mandatory) (2 bytes)

**IpReasmTimeout:** This attribute indicates the maximum number of seconds that received fragments are held while they are awaiting reassembly at this router. (R) (mandatory) (4 bytes)

#### *Actions*

**Get:** Get one or more attributes.

#### *Notifications*

None.

### **7.3.40 IP router PM history data 1**

This managed entity contains some IP-related past performance monitoring data collected at IP router function. Instances of this managed entity are created/deleted by the OLT after/before an instance of IP Router Service Profile is created/deleted.

## Relationship

An instance of this managed entity is associated with one instance of IP Router Service Profile.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the IP Router Service Profile with which this IP Router PM History Data 1 is associated. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**IpInReceivesCounter:** This attribute provides a count of packets received from interfaces, including those with errors. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpInHdrErrorsCounter:** This attribute provides a count of packets discarded due to errors in their IP headers, including bad checksums, version number mismatch, other format errors, time-to-live exceeded, errors discovered in processing their IP options, etc. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpInAddrErrorsCounter:** This attribute provides a count of packets discarded because the IP address in their IP header's destination field was not a valid address to be received at this router. This counter includes invalid addresses (e.g., 0.0.0.0) and addresses of unsupported Classes (e.g., Class E). If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpForwPacketsCounter:** This attribute provides a count of packets for which this router was not their final IP destination, as a result of which an attempt was made to find a route to forward them to that final destination. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpInUnknownProtosCounter:** This attribute provides a count of packets which were locally-addressed and received successfully but discarded because of an unknown or unsupported protocol. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpInDiscardsCounter:** This attribute provides a count of input packets for which no problems were encountered to prevent their continued processing, but which were discarded (e.g., for lack of buffer space). Note that this counter does not include any packets discarded while awaiting reassembly. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpInDeliversCounter:** This attribute provides a count of input packets successfully delivered to IP user-protocols (including ICMP). If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpOutRequestsCounter:** This attribute provides a count of packets that local IP user-protocols (including ICMP) supplied to IP in requests for transmission. Note that this counter does not include any packets counted in ipForwPacketsCounter. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpOutDiscardsCounter:** This attribute provides a count of output packets for which no problem was encountered to prevent their transmission to their destination, but which were discarded (e.g., for lack of buffer space). Note that this counter would include packets counted in ipForwPacketsCounter if any such packets met this (discretionary) discard criterion. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpOutNoRoutesCounter:** This attribute provides a count of packets discarded because no route could be found to transmit them to their destination. Note that this counter includes any packets counted in ipForwPacketsCounter which meet this 'no-route' criterion. Note that this includes any packets that a host cannot route because all of its default gateways are down. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 15h/G.983.2.

**Table 15h/G.983.2 – Alarm list for IP router PM history data 1**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	IpInReceives	Exceeds threshold	1
1	IpInHdr	Exceeds threshold	2
2	IpInAddr	Exceeds threshold	3
3	IpForwPackets	Exceeds threshold	4
4	IpInUnknownProtos	Exceeds threshold	5

**Table 15h/G.983.2 – Alarm list for IP router PM history data 1**

Number	Event	Description	Threshold data counter # (Note)
5	IpInDiscards	Exceeds threshold	6
6	IpInDelivers	Exceeds threshold	7
7	IpOutRequests	Exceeds threshold	8
8	IpOutDiscards	Exceeds threshold	9
9	IpOutNoRoutes	Exceeds threshold	10
10-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.41 IP router PM history data 2

This managed entity contains other IP-related past performance monitoring data collected at IP router function. Instances of this managed entity are created/deleted by the OLT after/before an instance of IP Router Service Profile is created/deleted.

#### *Relationship*

An instance of this managed entity is associated with one instance of IP Router Service Profile.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the IP Router Service Profile with which this IP Router PM History Data 2 is associated. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**IpReasmReqdsCounter:** This attribute provides a count of received packets that needed to be reassembled at this entity. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpReasmOKsCounter:** This attribute provides a count of packets successfully reassembled. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpReasmFailsCounter:** This attribute provides a count of failures detected by the IP reassembly algorithm (for whatever reason: timed out, errors, etc.). Note that this is not necessarily a count of discarded IP fragments since some algorithms (notably the algorithm in RFC 815) can lose track of the number of fragments by combining them as they are received. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpFragOKsCounter:** This attribute provides a count of packets that have been successfully fragmented at this entity. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpFragFailsCounter:** This attribute provides a count of packets that have been discarded because they needed to be fragmented at this router but could not be, e.g., because their Don't Fragment flag was set. Default value is 0x00. (R) (mandatory) (4 bytes)

**IpFragCreatesCounter:** This attribute provides a count of IP fragments that have been generated as a result of fragmentation at this entity. Default value is 0x00. (R) (mandatory) (4 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 15i.

**Table 15i/G.983.2 – Alarm list for IP router PM history data 2**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	IpReasmReqds	Exceeds threshold	1
1	IpReasmOKs	Exceeds threshold	2
2	IpReasmFails	Exceeds threshold	3
3	IpFragOKs	Exceeds threshold	4
4	IpFragFails	Exceeds threshold	5
5	IpFragCreates	Exceeds threshold	6
6-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.42 ICMP PM history data 1

This managed entity contains some ICMP-related past performance monitoring data collected at IP router function. Instances of this managed entity are created/deleted by the OLT after/before an instance of IP Router Service Profile is created/deleted.

#### *Relationship*

An instance of this managed entity is associated with one instance of IP Router Service Profile.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the IP Router Service Profile with which this ICMP PM History Data 1 is associated. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**IcmpInMsgsCounter:** This attribute provides a count of received ICMP messages. Note that this counter includes all those counted by IcmpInErrorsCounter. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInErrorsCounter:** This attribute provides a count of ICMP messages that were received but determined as having ICMP-specific errors (bad ICMP checksums, bad length, etc.). Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInDestUnreachsCounter:** This attribute provides a count of received ICMP Destination Unreachable messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInTimeExcdsCounter:** This attribute provides a count of received ICMP Time Exceeded messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInParmProbsCounter:** This attribute provides a count of received ICMP Parameter Problem messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInSrcQuenchsCounter:** This attribute provides a count of received ICMP Source Quench messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInRedirectsCounter:** This attribute provides a count of received ICMP Redirect messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInEchosCounter:** This attribute provides a count of received ICMP Echo (request) messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInEchoRepsCounter:** This attribute provides a count of received ICMP Echo Reply messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInTimestampsCounter:** This attribute provides a count of received ICMP Timestamp (request) messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInTimestampRepsCounter:** This attribute provides a count of received ICMP Timestamp Reply messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInAddrMasksCounter:** This attribute provides a count of received ICMP Address Mask (request) messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpInAddrMaskRepsCounter:** This attribute provides a count of received ICMP Address Mask Reply messages. Default value is 0x00. (R) (mandatory) (4 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 15j.

**Table 15j/G.983.2 – Alarm list for ICMP PM history data 1**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	IcmpInMsgs	Exceeds threshold	1
1	IcmpInErrors	Exceeds threshold	2
2	IcmpInDestUnreachs	Exceeds threshold	3
3	IcmpInTimeExcds	Exceeds threshold	4
4	IcmpInParmProbs	Exceeds threshold	5
5	IcmpInSrcQuenchs	Exceeds threshold	6
6	IcmpInRedirects	Exceeds threshold	7
7	IcmpInEchos	Exceeds threshold	8
8	IcmpInTimestamps	Exceeds threshold	9
9	IcmpInTimestampReps	Exceeds threshold	10
10	IcmpInAddrMasks	Exceeds threshold	11
11	IcmpInAddrMaskReps	Exceeds threshold	12
12-223	Reserved		

**Table 15j/G.983.2 – Alarm list for ICMP PM history data 1**

Number	Event	Description	Threshold data counter # (Note)
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.43 ICMP PM history data 2

This managed entity contains other ICMP-related past performance monitoring data collected at IP router function. Instances of this managed entity are created/deleted by the OLT after/before an instance of IP Router Service Profile is created/deleted.

#### *Relationship*

An instance of this managed entity is associated with one instance of IP Router Service Profile.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the IP Router Service Profile with which this ICMP PM History Data 2 is associated. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**IcmpOutMsgsCounter:** This attribute provides a count of ICMP messages that this router attempted to send. Note that this counter includes all those counted by IcmpOutErrorsCounter. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutErrorsCounter:** This attribute provides a count of ICMP messages that this router did not send due to problems discovered within ICMP such as a lack of buffers. This value should not include errors discovered outside the ICMP layer such as the inability of IP to route the resultant packet. In some implementations, there may be no types of error that contribute to this counter's value. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutDestUnreachsCounter:** This attribute provides a count of sent ICMP Destination Unreachable messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutTimeExcdsCounter:** This attribute provides a count of sent ICMP Time Exceeded messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutParmProbsCounter:** This attribute provides a count of sent ICMP Parameter Problem messages. Default value is 0x00. (R) (mandatory) (4 bytes)



**IcmpOutSrcQuenchesCounter:** This attribute provides a count of sent ICMP Source Quench messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutRedirectsCounter:** This attribute provides a count of sent ICMP Redirect messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutEchosCounter:** This attribute provides a count of sent ICMP Echo (request) messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutEchoRepsCounter:** This attribute provides a count of sent ICMP Echo Reply messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutTimestampsCounter:** This attribute provides a count of sent ICMP Timestamp (request) messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutTimestampRepsCounter:** This attribute provides a count of sent ICMP Timestamp Reply messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutAddrMasksCounter:** This attribute provides a count of sent ICMP Address Mask (request) messages. Default value is 0x00. (R) (mandatory) (4 bytes)

**IcmpOutAddrMaskRepsCounter:** This attribute provides a count of sent ICMP Address Mask Reply messages. Default value is 0x00. (R) (mandatory) (4 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### *Notifications*

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 15k.

**Table 15k/G.983.2 – Alarm list for ICMP PM history data 2**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	IcmpOutMsgs	Exceeds threshold	1
1	IcmpOutErrors	Exceeds threshold	2
2	IcmpOutDestUnreachs	Exceeds threshold	3

**Table 15k/G.983.2 – Alarm list for ICMP PM history data 2**

Number	Event	Description	Threshold data counter # (Note)
3	IcmpOutTimeExcds	Exceeds threshold	4
4	IcmpOutParmProbs	Exceeds threshold	5
5	IcmpOutSrcQuenchs	Exceeds threshold	6
6	IcmpOutRedirects	Exceeds threshold	7
7	IcmpOutEchos	Exceeds threshold	8
8	IcmpOutTimestamps	Exceeds threshold	9
9	IcmpOutTimestampReps	Exceeds threshold	10
10	IcmpOutAddrMasks	Exceeds threshold	11
11	IcmpOutAddrMaskReps	Exceeds threshold	12
12-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

#### 7.3.44 IP route table

This managed entity is used to record data that is associated with IP routes. Some of the data is volatile. Instances of this managed entity shall be automatically created/deleted by the ONT upon creation/deletion of the associated instances of IP Router Service Profile.

##### *Relationship*

An instance of this managed entity is associated with one instance of IP Router Service Profile.

##### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the IP Router Service Profile with which this IP Route Table is associated. (R) (mandatory) (2 bytes)

**IpRouteNumber:** This attribute indicates the number of current routes in the route table. Default value is 0x00. (R) (mandatory) (2 bytes)

**IpRouteTableMaxSize:** This attribute indicates the maximum number of routes that can be stored in the route table. (R) (mandatory) (2 bytes)

**IpRouteTable:** This attribute lists current routes in the route table. A route consists of route-id, destination-address, destination-address-mask, tos, next-hop, output-port, route-type, route-protocol, route-age, and metric, which are further described below. (R) (mandatory) (N × 30 bytes. N is the number of routes.)

- route-id: a unique identifier of a route within the route table (2 bytes);
- destination-address: the destination IP address of this route (4 bytes);
- destination-address-mask: the address mask associated with the destination address (4 bytes);
- tos: TOS value defined in RFC 2096 [17] (ipCidrRouteTos) for use with policy routing; otherwise, 0; (1 byte)
- next-hop: the address of the next router on remote routes (4 bytes);

- output-port: the port number of the IP port through which the next hop of this route should be reached (1 byte);
- route-type: the type of route as defined in RFC 2096 [17] (ipCidrRouteType) (1 byte);
- route-protocol: the routing mechanism via which this route was learned, as defined in RFC 2096 [17] (ipCidrRouteProto). For example, static route is 3 (1 byte);
- route-age: the number of seconds since this route was last updated or otherwise determined to be correct. Static routes can return the maximum value (4 bytes);
- metric: the primary (first 4 bytes) and secondary (second 4 bytes) routing metrics for this route. The semantics of this metric are determined by the routing-protocol specified in the route's route-protocol value. If part of this metric is not used, its value should be set to –1 ( $2 \times 4$  bytes).

#### *Actions*

**Get:** Get one or more attributes. Latch a snapshot (i.e., copy) of the current ipRouteTable and respond with the size of data (4 bytes) that should be obtained using the Get next command.

**Get next:** Get the latched attribute values of the managed entity within the current snapshot.

#### *Notifications*

None.

### **7.3.45 IP static routes**

This managed entity is used to set or delete IP static routes. Instances of this managed entity shall be automatically created/deleted by the ONT upon creation/deletion of the associated instances of IP Router Service Profile.

#### *Relationship*

An instance of this managed entity is associated with one instance of IP Router Service Profile.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the IP Router Service Profile with which this IP Static Routes is associated. (R) (mandatory) (2 bytes)

**IpStaticRouteTableMaxSize:** This attribute indicates the maximum number of routes that can be set as static routes. (R) (mandatory) (2 bytes)

**IpStaticRouteTable:** This attribute is used to set or delete static routes in the route table. A route consists of route-id, action, destination-address, destination-address-mask, next-hop, output-port, and metric, which are further described below. (The same scenario is used for the MAC Filter Table attribute of the MAC Bridge Port Filter Table Data managed entity. See I.1.3 and I.1.4.) When this attribute is used to set a static route through the parameter action:add(1), the route table is searched for the route-id parameter associated with the static route that is to be added. If the same route-id is found, the route is overwritten. (R, W) (mandatory) ( $N \times 21$  bytes. N is the number of routes.)

- route-id: a unique identifier of a route within the static route table (1 byte);
- action: remove (0) or add (1) this route. When a static route is being removed, only static-route-id field is used to identify the route (1 byte);
- destination-address: the destination IP address of this route. This field may be set at the default route address (0.0.0.0) (4 bytes);
- destination-address-mask: the address mask associated with the destination address (4 bytes);

- next-hop: the address of the next router on remote routes. This field is not used when the next-hop is reached through an unnumbered link (4 bytes, 0xFFFFFFFF when not used);
- output-port: the port number of the IP port through which the next hop of this route should be reached. This field is used when the next-hop is reached through an unnumbered link and when a static route is set to support a fully meshed network over ATM (1 byte, 0xFF when not used);
- iVCCTPointer: the pointer to the instance of Interworking VCC Termination Point which identifies one of the ATM links of the fully meshed network which is being set by this attribute. The value 0x0000 is interpreted as a Null pointer. (optional, 2 bytes);
- metric: the routing metric for this route (4 bytes).

#### *Actions*

**Get:** Get one or more attributes. Latch a snapshot (i.e., copy) of the current IpStaticRouteTable and respond with the size of data (4 bytes) that should be obtained using the Get next command.

**Set:** Generally, this action is used to set one or more entire attribute values. When used on the "IpStaticRouteTable" attribute, the "Set" action either adds or deletes table entries from "IpStaticRouteTable". Only one entry can be added/deleted by a single "Set" action.

**Get next:** Get the latched attribute values of the managed entity within the current snapshot.

#### *Notifications*

None.

### **7.3.46 ARP service profile**

This managed entity is used to organize data that is associated with the ARP function used by an IP router function that contains an IP port of native LAN type. Instances of this managed entity are created/deleted by the OLT after/before an instance of IPPortConfigurationData is created/deleted.

#### *Relationship*

An instance of this managed entity is associated with one instance of IP Port Configuration Data of native LAN type.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The first byte is the slot id (defined in 7.1.3). If the UNI is integrated, this value is 0x00. The second byte is the ARP group id. (R, Set-by-create) (mandatory) (2 bytes)

**ARP Timer:** This attribute indicates the maximum number of seconds that IP packets are held while they are awaiting address resolution by ARP at this router. (R) (mandatory) (4 bytes)

**ARP Cache Clear:** This boolean attribute is used by the management system to initialize the ARP cache associated with an instance of this entity. This attribute is used only to trigger the "Cache Clear" action. The value TRUE means clear, and the value FALSE has no significance. As the value of this attribute has no physical meaning, the action "Get" will always return the value FALSE for this attribute. (R, W, Set-by-create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

## *Notifications*

None.

### **7.3.47 ARP configuration data**

This managed entity is used to organize data that is associated with the ARP function related to an IP router that contains an IP port of native LAN type. Some of the data is volatile. Instances of this managed entity shall be automatically created/deleted by the ONT upon creation/deletion of the associated instance of ARP Service Profile.

## *Relationship*

An instance of this managed entity is associated with one instance of ARP Service Profile.

## *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the ARP Service Profile with which this ARP Configuration Data is associated. (R) (mandatory) (2 bytes)

**ARPTableMaxSize:** This attribute indicates the maximum number of ARP entries that can be set in the ARP table. (R) (mandatory) (2 bytes)

**ARP Table:** This attribute lists current entries in the ARP cache. An ARP cache entry consists of port, IP-address, MAC-address, and type, which are further described below. (R) (mandatory) ( $N \times 12$  bytes. N is the number of entries.)

- port: the port number of the IP port associated with the entry (1 byte);
- IP-address: an IP address (4 bytes);
- MAC-address: an equivalent MAC-address resolved by the ARP procedure (6 bytes);
- type: the entry type such as dynamic (3) or static (4) (1 byte).

## *Actions*

**Get:** Get one or more attributes. Latch a snapshot (i.e., copy) of the current ARP Table and respond with the size of data (4 bytes) that should be obtained using the Get next command.

**Get next:** Get the latched attribute values of the managed entity within the current snapshot.

## *Notifications*

None.

### **7.3.48 Physical path termination point ISDN UNI**

This managed entity represents the point at the ISDN UNI in the ONT where physical paths terminate and physical path level functions (e.g., analog telephony, facsimile function) are performed. An instance of this managed entity shall be automatically created/deleted by the ONT upon the creation/deletion of a Subscriber Line Card with ISDN type.

## *Relationships*

One or more instances of this managed entity shall be contained in an instance of the ONT<sub>B-PON</sub> or a Subscriber Line Card managed entity classified as ISDN type.

## *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot id (defined in 7.1.3). If the UNI is integrated, this value is 0x00. The second byte is the port id with value range from 0x01 to 0xFF (1 to 255), 0x01 is used for the leftmost/lowest

port on a Subscriber Line Card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) the functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Interworking VCC Pointer:** This attribute provides a pointer to the instance of the Interworking VCC Termination Point managed entity to which this instance is connected. The value 0x0000 is interpreted as a Null pointer. (R, W) (optional) (2 bytes)

**DchannelID:** This attribute provides the channel identifier of the AAL 2 connection transporting the D channel associated with this ISDN BRI port. (R, W) (mandatory) (1 byte)

**B1ChannelID:** This attribute provides the channel identifier of the AAL 2 connection transporting the B1 channel associated with this ISDN BRI port. (R, W) (mandatory) (1 byte)

**B2ChannelID:** This attribute provides the channel identifier of the AAL 2 connection transporting the B2 channel associated with this ISDN BRI port. (R, W) (mandatory) (1 byte)

**ARC:** This attribute is used to control alarm reporting from this managed entity. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ARCInterval:** This attribute provides a provisionable length of time. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ISDN Loopback Configuration:** This attribute represents the loopback configuration of this physical interface. Value 0x00: no loopback; value 0x01: simultaneous loopback of all channels; value 0x01: loopback of D channel only; value 0x02: loopback of B1 channel only; value 0x03: loopback of B2 channel only. Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Test:** Request that the ONT perform one or more MLT tests. See "Test" and "Test result" message layouts in II.2.27 and II.2.45.

#### *Notifications*

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 151.

**Table 151/G.983.2 – Alarm list for physical path termination point ISDN UNI**

Number	Alarm	Description
0	AIS	Alarm indication signal
1	RDI	Remote defect indication
2-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.49 VLAN tagging operation configuration data

This managed entity is used to organize data associated with VLAN tagging. Instances of this managed entity are created/deleted at the request of the OLT.

#### *Relationship*

Zero or one instance of this managed entity may exist for each instance of Physical Path Termination Point Ethernet UNI.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the Physical Path Termination Point Ethernet UNI with which this VLAN Tagging Operation Configuration Data instance is associated. (R, Set-by-create) (mandatory) (2 bytes)

**Upstream VLAN Tagging Operation Mode:** This attribute selects whether or not upstream VLAN tagging is sent. Valid values are 0x00 (upstream frame is sent "as is", regardless of whether or not the received frame is tagged) and 0x01 (The upstream frame is sent as tagged whether or not the received frame is tagged. TCI, consisting of VID, CFI and user priority, is attached or overwritten by using the Upstream VLAN Tag TCI Value.). (R, W, Set-by-create) (mandatory) (1 byte)

**Upstream VLAN Tag TCI Value:** This attribute indicates the TCI value for upstream VLAN tagging. It is used when the Upstream VLAN Tagging Operation Mode is 0x01. Any 2-byte value is acceptable. (R, W, Set-by-create) (mandatory) (2 bytes)

**Downstream VLAN Tagging Operation Mode:** This attribute selects whether or not downstream VLAN tagging is sent. Valid values are 0x00 (downstream frame is sent "as is", regardless of whether or not the received frame is tagged) and 0x01 (The downstream frame is sent as untagged whether or not the received frame is tagged). (R, W, Set-by-create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### 7.3.50 VLAN tagging filter data

This managed entity is used to organize data associated with VLAN tagging. Instances of this managed entity are created/deleted at the request of the OLT.

#### *Relationships*

Zero or one instance of this managed entity may exist for each instance of MAC Bridge Port Configuration Data which is associated with Interworking VCC Termination Point (PON side) or Physical Path Termination Point Ethernet UNI.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the MACBridgePortConfigurationData with

which this VLAN Tagging Filter Data instance is associated. (R, Set-by-create) (mandatory) (2 bytes)

**VLAN Filter Table:** This attribute lists TCI values which are provisioned at a bridging port. Since a TCI value (consisting of user priority, CFI and VID) is represented by 16 bits, 2 bytes are reserved for this attribute per VLAN. Twelve separate VLAN entries are supported. The first N are valid, where N is given by the NumberOfEntries attribute. (R, W, Set-by-create) (mandatory) (24 bytes)

**Forward Operation:** When a frame is received, the frame is processed according to the following Forward Operations. The operations are invoked based on the value of VID, user priority, or the entire TCI or whether or not the TCI field exists. This attribute indicates the received frame is treated as indicated below. (R,W, set-by-create) (mandatory) (1 byte)

**NumberOfEntries:** This attribute provides the number of entries in the VLAN Filter Table that are valid. (R, W, Set-by-Create) (mandatory) (1 byte)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.


#### Notifications

None.

#### Supplementary explanation

##### 1) *Ethernet frame and fields format for VLAN services*

The detailed format of Ethernet frame for VLAN services is described in IEEE 802.1Q [18] and is depicted in Figure 37.




**Figure 37/G.983.2 – Detailed format for Ethernet frame with VLAN tag**

##### 2) *Operations*

Operations specified in the attribute "Forward Operation" are explained. Forward Operations are specified by a combination of the basic actions mentioned.


- a) **Basic MAC bridge operation:** As shown in Figure 38, if DA (Destination MAC Address) in the received frame is listed in one or more ports with MAC Bridge Port Bridge Table Data, this frame is forwarded to the indicated ports. Otherwise, it is broadcasted to all of the ports excepting for its receiving port.






**Figure 38/G.983.2 – Basic MAC Bridge operation**

- b) **Unconditional forwarding for Tagged frame:** If a tagged frame is received, it is forwarded without investigation of TCI.
- c) **Unconditional discarding for Tagged frame:** If a tagged frame is received, it is discarded without investigation of TCI.
- d) **Unconditional forwarding for Untagged frame:** If an untagged frame is received, it is forwarded without investigation of TCI.
- e) **Unconditional discarding for Untagged frame:** If an untagged frame is received, it is discarded without investigation of TCI.
- f) **Positive filtering by TCI:** If a part or all of the fields in the TCI of the received frame are included in VLAN Tag Filter Data, it is forwarded according to Action a) to the indicated ports as shown in Figure 39. Otherwise, its TCI is ignored and it is controlled by Action a).



**Figure 39/G.983.2 – Positive filtering by TCI operation**

- g) **Negative filtering by TCI:** If a part or all of the fields in the TCI of the received frame are included in VLAN Tag Filter Data, it is discarded. Otherwise, it is forwarded according to Action a) as shown in Figure 40.



**Figure 40/G.983.2 – Negative filtering by TCI operation**

The Forwarding Operation is specified by a combination of these actions.

	The type of received frame	
	Tagged	Untagged
0x00	Action a)	Action a)
0x01	Action c)	Action a)
0x02	Action a)	Action e)
0x03	Action f) (VID investigation)	Action a)
0x04	Action f) (VID investigation)	Action e)
0x05	Action g) (VID investigation)	Action a)
0x06	Action g) (VID investigation)	Action e)
0x07	Action f) (user priority investigation)	Action a)
0x08	Action f) (user priority investigation)	Action e)
0x09	Action g) (user priority investigation)	Action a)
0x0A	Action g) (user priority investigation)	Action e)
0x0B	Action f) (TCI investigation)	Action a)
0x0C	Action f) (TCI priority investigation)	Action e)
0x0D	Action g) (TCI investigation)	Action a)
0x0E	Action g) (TCI investigation)	Action e)

### 7.3.51 MAC Bridge port filter preassign table

This managed entity provides an alternate approach to address filtering than that supported through MACBridgePortFilterTableData. This alternate approach is useful when all the groups of addresses are stored beforehand in the line card, and this managed entity is used to designate which groups are valid or invalid for filtering. The MAC addresses and Ether types for various protocols are provided in Appendix VI. Instances of this managed entity are created/deleted autonomously after creation/deletion of a Subscriber Line Card ME of Ethernet type in which all groups of addresses are preassigned and stored in the card.

## Relationships

This managed entity is associated with one instance of a MACBridgePortConfigurationData managed entity.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the id of the MACBridgePortConfigurationData with which this MAC Bridge Port Filter Preassign Table instance is associated. (R) (mandatory) (2 bytes)

**IPv4MulticastFiltering:** This attribute indicates whether IPv4Multicast Ether types are forwarded (value 0x00) or filtered (value 0x01). Initial value is 0x00. (R,W) (mandatory) (1 byte)

**IPv6MulticastFiltering:** This attribute indicates whether Ipv6Multicast Ether types are forwarded (value 0x00) or filtered (value 0x01). Initial value is 0x00. (R,W) (mandatory) (1 byte)

**IPv4BroadcastFiltering:** This attribute indicates whether IPv4Broadcast Ether types are forwarded (value 0x00) or filtered (value 0x01). Initial value is 0x00. (R,W) (mandatory) (1 byte)

**RARPFfiltering:** This attribute indicates whether RARP Ether types are forwarded (value 0x00) or filtered (value 0x01). Initial value is 0x00. (R,W) (mandatory) (1 byte)

**IPXFiltering:** This attribute indicates whether IPX Ether types are forwarded (value 0x00) or filtered (value 0x01). Initial value is 0x00. (R,W) (mandatory) (1 byte)

**NetBEUIFiltering:** This attribute indicates whether NetBEUI Ether types are forwarded (value 0x00) or filtered (value 0x01). Initial value is 0x00. (R,W) (mandatory) (1 byte)

**AppleTalkFiltering:** This attribute indicates whether AppleTalk Ether types are forwarded (value 0x00) or filtered (value 0x01). Initial value is 0x00. (R,W) (mandatory) (1 byte)

**BridgeManagementInformationFiltering:** This attribute indicates whether BridgeManagementInformation Ether types are forwarded (value 0x00) or filtered (value 0x01). Initial value is 0x00. (R,W) (mandatory) (1 byte)

Note that some MAC addresses should not be handled, considering the following rules of IEEE 802.1D [13]:

- 1) Addresses from 0x0180C2000000 to 0x0180C200000F are reserved;
- 2) Addresses from 0x0180C2000020 to 0x0180C200002F are used for GARP Application Address.

**ARPFfiltering:** This attribute indicates whether ARP Ether types are forwarded (value 0x00) or filtered (value 0x01). Initial value is 0x00. (R,W) (mandatory) (1 byte)

**PPPoEFiltering:** This attribute indicates whether PPPoE Ether types are forwarded (value 0x00) or filtered (value 0x01). Initial value is 0x00. (R,W) (mandatory) (1 byte)

## Actions

**Set:** Set one or more attributes.

## Notifications

None.

### 7.3.52 Physical path termination point video UNI

This managed entity represents the point at the video UNI in the ONT where physical paths terminate and physical path level functions are performed.

An instance of this managed entity shall be automatically created/deleted by the ONT upon creation/deletion of a Subscriber Line Card of Video type.

#### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as Video type.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot id (defined in 7.1.3). If the UNI is integrated, this value is 0x00. The second byte is the port id with value range from 0x01 to 0xFF (1 to 255); 0x01 is used for the leftmost/lowest port on a Subscriber Line Card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation, as it is normally handled through supplier-operator negotiations. (R,W) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**ARC:** This attribute is used to control alarm reporting from this managed entity. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ARCInterval:** This attribute provides a provisionable length of time. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**Power control:** This attribute controls whether power is provided to an external equipment over the video PPTP. Value 0x01 enables power over co-ax. The default value 0x00 disables power feed. (R, W) (optional) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify its new value. The AVC list is given in Table 15m.

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm is used by this entity. The alarm list for this entity is given in Table 15n.

**Table 15m/G.983.2 – AVC list for physical path termination point video UNI**

Number	Attribute value change	Description
1	N/A	
2	OpState	Operational state of video UNI
3-16	Reserved	Reserved for AVCs of vendor-specific attributes

**Table 15n/G.983.2 – Alarm list for physical path termination point video UNI**

Number	Event	Description
0	Video-LOS	No signal at the video UNI
1-223	Reserved	Reserved for vendor-specific alarms
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.53 Physical path termination point video ANI

This managed entity represents the point at the video ANI in the ONT where physical paths terminate and physical path level functions are performed.

An instance of this managed entity shall be automatically created/deleted by the ONT upon creation/deletion of a Subscriber Line Card of Video type.

#### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as Video type.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. There is only one instance, and it has the number 0x0000. (R) (mandatory) (2 bytes)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation, as it is normally handled through supplier-operator negotiations. (R,W) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**ARC:** This attribute is used to control alarm reporting from this managed entity. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ARCInterval:** This attribute provides a provisionable length of time. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**FrequencyRangeLow:** This attribute indicates the lower of the possibly two frequency ranges supported. Different frequency ranges are indicated by code points, as given below:

- 0 indicates no low band is supported;
- 1 indicates 50-550 MHz is supported;
- 2 indicates 50-750 MHz is supported;
- 3 indicates 50-870 MHz is supported;
- 4..255 are reserved for future use.

(R) (mandatory) (1 byte)

**FrequencyRangeHigh:** This attribute indicates the higher of the two frequency ranges supported. Different frequency ranges are indicated by code points, as given below:

- 0 indicates no high band is supported;
- 1 indicates 550-750 MHz is supported;
- 2 indicates 550-870 MHz is supported;
- 3 indicates 950-2050 MHz is supported;
- 4 indicates 2150-3250 MHz is supported;
- 5 indicates 950-3250 MHz is supported;
- 6..255 are reserved for future use.

(R) (mandatory) (1 byte)

**SignalCapability:** This attribute indicates the capability of the ONT to measure the video signal level. Different capabilities are indicated by code points, as given below:

- 0 indicates no signal level capability is supported;
- 1 indicates total optical power level is supported;
- 2 indicates fixed frequency pilot tone power level is supported;
- 3 indicates total optical power level and fixed frequency pilot tone power level are supported;
- 4 indicates variable frequency pilot tone power level is supported;
- 5 indicates total optical power level and variable frequency pilot tone power level are supported;
- 6 indicates broadband RF power level is supported;
- 7 indicates total optical power level and broadband RF power level is supported;
- 8..255 are reserved for future use.

(R) (mandatory) (1 byte)

**OpticalSignalLevel:** This attribute indicates the current measurement of the total optical signal level. The unit of this attribute is dB $\mu$ W optical.

If SignalCapability = 0, 2, or 4 then this attribute is undefined.

If SignalCapability = 1, 3, 5, or 7, then this attribute describes the total optical power that is generating photocurrent on the receiver.

(R) (optional) (1 byte)

**PilotSignalLevel:** This attribute indicates the current measurement of the pilot signal level or broadband RF level. The unit of this attribute is dB $\mu$ V at the RF video service port.

If SignalCapability = 0 or 1, then this attribute is undefined.

If SignalCapability = 2, 3, 4, or 5, then this attribute describes the pilot signal level at the output of the video UNI.

If SignalCapability = 6, or 7, then this attribute describes the total RF power level at the output of the video UNI.

(R) (optional) (1 byte)

**SignalLevelMin:** This attribute indicates the minimum optical RF power per channel that will result in a CNR of 47 dBc for a channel of 4.5 MHz in bandwidth at a receive optical power of –5 dBm. The unit of this attribute is dBμW optical.

(R) (mandatory) (1 byte)

**SignalLevelMax:** This attribute indicates the maximum optical RF power per channel that will result in a CTB of –57 dBc for an 80-channel ensemble of carriers at a per-channel optical modulation index of 3.5%. The units of the attributes are in dBμW optical.

(R) (mandatory) (1 byte)

**PilotFrequency:** This attribute indicates the frequency of the pilot channel receiver. This unit of this attribute is Hz.

If SignalCapability = 0 or 1, this attribute is undefined;

If SignalCapability = 2 or 3, this attribute is functionally read only;

If SignalCapability = 4 or 5, this attribute is read-write.

(R, W) (optional) (4 bytes)

**AGCmode:** This attribute allows the discovery and configuration of the ONT's AGC capabilities. The attribute contains a codepoints for the several AGC types. The ONT displays the currently used AGC mode. The OLT can discover new modes via the set command. The code points are:

- 0, no AGC is used;
- 1, broadband RF AGC is used;
- 2, optical AGC is used;
- 3-255, reserved for future use.

(R, W) (optional) (1 byte)

**AGCsetting** This attribute indicates the measurement offset that the ONT should use if using broadband RF signal level or total optical power as a basis for AGC. The theoretical nominal RF signal is 80-channels of NTSC video, each having a per-channel optical modulation index of 3.5%. An ONT presented with such a signal should produce its specified output when this attribute is set to zero. The attribute will have a step-size of 0.1 dB, represented as a signed integer. The usage of the attribute depends on the signal capability used for the AGC.

If total optical power is used for AGC, then this attribute provides the ONT with the OMI offset for any NTSC carriers present from the theoretical 3.5% value. So, if the actual signal uses an OMI of 7.0% per channel (3 dB higher), then the ONT should be given an AGC setting of 30. (Coded 0x1E).

If broadband RF power is used for AGC, then this attribute provides the ONT with the total power offset for any NTSC carriers present from the theoretical 80 channel value. So, if an actual signal contains 40 NTSC channels (3 dB lower), then the ONT should be given an AGC setting of –30. (Coded 0xE2).

(R, W) (optional) (1 byte)

### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

## Notifications

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify its new value. The AVC list is given in Table 15o.

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 15p.

**Table 15o/G.983.2 – AVC list for physical path termination point video ANI**

Number	Attribute value change	Description
1	N/A	
2	OpState	Operational state of video ANI
3-16	Reserved	Reserved for AVCs of vendor-specific attributes

**Table 15p/G.983.2 – Alarm list for physical path termination point video ANI**

Number	Event	Description
0	Video-LOS	No signal at the video ANI
1-223	Reserved	Reserved for vendor-specific alarms
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.54 Physical path termination point LCT UNI

This managed entity represents the point at the local craft terminal UNI in the ONT where physical paths terminate and physical path level functions are performed.

An instance of this managed entity shall be automatically created/deleted by the ONT upon creation/deletion of a Subscriber Line Card of LCT type. However, this instance will not be reported during a MIB upload.

## Relationships

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as LCT type.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot id (defined in 7.1.3). If the UNI is integrated, this value is 0x00. The second byte is the port id with value range from 0x01 to 0xFF (1 to 255); 0x01 is used for the leftmost/lowest port on a Subscriber Line Card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation, as it is normally handled through supplier-operator negotiations. (R,W) (mandatory) (1 byte)

## Actions

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.



## Notifications

None.

### 7.3.55 Ethernet performance monitoring history data 2

This managed entity contains the last completed 15-minute interval collected statistic data for an Ethernet interface. The statistic data value is only updated at the end of each period.

Instances of this managed entity are created/deleted by the OLT after an instance of Physical Path Termination Point Ethernet UNI managed entity is created/deleted.

## Relationships

One instance of this Ethernet Performance Monitoring History Data 2 managed entity can exist for each instance of the Physical Path Termination Point Ethernet UNI.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is the same as the id of the Physical Path Termination Point Ethernet UNI. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the statistic data values are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The statistic data value is updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**PPPoEFilteredFrame Counter:** This attribute provides a count of the number of frames that have been discarded due to PPPoE filtering. Default value is 0x00. (R) (mandatory) (4 bytes)

## Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Get Current Data:** This action returns the current value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters would be reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

**Set:** Set one or more attributes.

## Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be

sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 15q.

**Table 15q/G.983.2 – Alarm list for Ethernet performance monitoring history data 2**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	PPPoEFilteredFrameCounter	Exceeds threshold	1
1-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.56 Physical path termination point 802.11 UNI

#### *Relationships*

One instance of this managed entity may exist for each instance of an IEEE 802.11 interface. An instance of this entity is created/deleted by the ONU whenever an IEEE 802.11 UNI card is inserted/removed from the ONU.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot id (defined in 7.1.3). If the UNI is integrated, this value is 0x00. The second byte is the port id with value range from 0x01 to 0xFF (1 to 255), 0x01 is used for the leftmost/lowest port on a Subscriber Line Card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) the functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**dot11SupportedDataRatesTx:** This attribute shall specify the set of data rates (maximum of 8 data rates) at which the station is capable of transmitting data. Each octet contains a value representing a rate. Each rate shall be within the range from 2 to 127, corresponding to data rates in increments of 500 kbit/s from 1 Mbit/s to 63.5 Mbit/s, and shall be supported (as indicated in the supported rates table) for transmitting data. If fewer than 8 data rates are specified, each of the remaining bytes shall use the value 0x00. (R) (mandatory) (8 bytes)

**dot11SupportedDataRatesRx:** This attribute shall specify the set of data rates (maximum of 8 data rates) at which the station is capable of receiving data. Each octet contains a value representing a rate. Each rate shall be within the range from 2 to 127, corresponding to data rates in increments of 500 kbit/s from 1 Mbit/s to 63.5 Mbit/s, and shall be supported (as indicated in the supported rates table) for receiving data. If fewer than 8 data rates are specified, each of the remaining bytes shall use the value 0x00. (R) (mandatory) (8 bytes)

**dot11TxPowerLevels:** This attribute shall specify the set of transmit power levels (maximum of 8 power levels) which the station is capable of using. Each 16 bit word contains an integer representation of the power setting, in units of mW. If fewer than 8 power levels are specified, each of the remaining words shall use the value 0x0000. (R) (mandatory) (16 bytes)

**ARC:** This attribute is used to control alarm reporting from this managed entity. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ARCInterval:** This attribute provides a provisionable length of time. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Attribute Value Change:** This notification is used to report autonomous changes to the attributes of this managed entity. The attribute value change notification shall identify the attribute changed and its new value. The list of AVCs for this managed entity is given in Table 16.

**Table 16/G.983.2 – AVC list for physical path termination point 802.11 UNI  
(reproduced from Table 2/G.983.9)**

Number	Attribute value change	Description
1	N/A	
2	OpState	Operational state of Physical Path Termination Point 802.11 UNI
3-9	N/A	
10-16	Reserved	

### **7.3.57 UNI 802.11 station management data 1**

#### *Relationships*

One instance of this managed entity may exist for each instance of an IEEE 802.11 interface. The ONU automatically creates an instance of this entity whenever a PPTP 802.11 UNI instance is created.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This ME id shall be the same as that of the related instance of Physical Path Termination Point 802.11 UNI. (R) (mandatory) (2 bytes)

**dot11MediumOccupancyLimit:** This attribute shall indicate the maximum amount of time, in TU, that a point coordinator may control the usage of the wireless medium without relinquishing control for long enough to allow at least one instance of DCF access to the medium. The default value of this attribute shall be 100, and the maximum value shall be 1000. (R, W) (mandatory) (2 bytes)

**dot11CFPollable:** When this Boolean attribute is true, it shall indicate that the STA is able to respond to a CF-Poll with a data frame within a SIFS time. This attribute shall be false if the STA is not able to respond to a CF-Poll with a data frame within a SIFS time. (R) (mandatory) (1 byte)

**dot11CFPPeriod:** This attribute shall describe the number of DTIM intervals between the start of CFPs. (R,W) (mandatory) (1 byte)

**dot11CFPMaxDuration:** This attribute shall describe the maximum duration of the CFP in TU that may be generated by the PCF. (R, W) (mandatory) (2 bytes)

**dot11AuthenticationResponseTimeout:** This attribute shall specify the number of TU that a responding STA should wait for the next frame in the authentication sequence. (R, W) (mandatory) (4 bytes)

**dot11PrivacyOptionImplemented:** This Boolean attribute, when true, shall indicate that the IEEE 802.11 WEP option is implemented. The default value of this attribute shall be false. (R) (mandatory) (1 byte)

**dot11PowerManagementMode:** This attribute shall specify the power management mode of the STA. When set to active (0x00), it shall indicate that the station is not in power-save mode. When set to powersave (0x01), it shall indicate that the station is in power-save mode. (R, W) (mandatory) (1 byte)

**dot11DesiredSSID1:** This attribute contains the first half of the Service Set ID used in the DesiredSSID parameter of the most recent MLME\_Scan.request. This value may be modified by an external management entity and used by the local SME to make decisions about the scanning process. (R, W) (mandatory) (16 bytes)

**dot11DesiredSSID2:** This attribute contains the second half of the Service Set ID used in the DesiredSSID parameter of the most recent MLME\_Scan.request. This value may be modified by an external management entity and used by the local SME to make decisions about the scanning process. (R, W) (mandatory) (16 bytes)

**dot11DesiredBSSType:** This attribute shall specify the type of BSS the station shall use when scanning for a BSS with which to synchronize. This value is used to filter Probe Response frames and Beacons. When set to infrastructure (0x00), the station shall only synchronize with a BSS whose Capability Information field has the ESS subfield set to 1. When set to independent (0x01), the station shall only synchronize with a BSS whose Capability Information field has the IBSS subfield set to 1. When set to any (0x02), the station may synchronize to either type of BSS. (R, W) (mandatory) (1 byte)

**dot11OperationalRateSet:** This attribute shall specify the set of data rates (maximum of 8 data rates) at which the station may transmit data. Each octet contains a value representing a rate. Each rate shall be within the range from 2 to 127, corresponding to data rates in increments of 500 kbit/s from 1 Mbit/s to 63.5 Mbit/s, and shall be supported (as indicated in the supported rates table) for receiving data. If fewer than 8 data rates are specified, each of the remaining bytes shall use the value 0x00. This value is reported in transmitted Beacon, Probe Request, Probe Response, Association Request, Association Response, Reassociation Request, and Reassociation Response frames, and is used to determine whether a BSS with which the station desires to synchronize is suitable. (R, W) (mandatory) (8 bytes)

**dot11BeaconPeriod:** This attribute shall specify the number of TU that a station shall use for scheduling Beacon transmissions. This value is transmitted in Beacon and Probe Response frames. (R, W) (mandatory) (2 bytes)

**dot11DTIMPeriod:** This attribute shall specify the number of beacon intervals that shall elapse between transmission of Beacons frames containing a TIM element whose DTIM Count field is 0. This value is transmitted in the DTIM Period field of Beacon frames. (R, W) (mandatory) (1 byte)

**dot11AssociationResponseTimeOut:** This attribute shall specify the number of TU that a requesting STA should wait for a response to a transmitted association-request MMPDU. (R, W) (mandatory) (4 bytes)

**dot11AuthenticationAlgorithm:** This attribute shall indicate all of the authentication algorithms supported by the STAs. The attribute is a bit-mapped coding, formatted as follows:

0000 0000 0000 0000 0000 0000 0000 00yx,

where

0 = reserved, must be set to zero

x = Open System (1=Supported, 0=Not supported)

y = Shared Key Supported (1=Supported, 0=Not supported)

(R) (mandatory) (4 bytes)

**dot11AuthenticationAlgorithmsEnable:** This attribute shall indicate the enable status of the authentication algorithms supported by the STAs. The attribute is a bit-mapped coding, formatted as follows:

0000 0000 0000 0000 0000 0000 0000 00yx,

where

0 = reserved, must be set to zero

x = Open System (1=Enabled, 0=Not Enabled)

y = Shared Key (1=Enabled, 0=Not Enabled)

(R, W) (mandatory) (4 bytes)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### **7.3.58 802.11 station management data 2**

#### *Relationships*

One instance of this managed entity may exist for each instance of an IEEE 802.11 interface. The ONU automatically creates an instance of this entity whenever a PPTP 802.11 UNI instance is created.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This ME id shall be the same as that of the related instance of Physical Path Termination Point 802.11 UNI. (R) (mandatory) (2 bytes)

**dot11DisassociateReason:** This attribute holds the most recently transmitted Reason Code in a disassociation frame. If no Disassociation frame has been transmitted, the value of this attribute shall be 0. (R) (mandatory) (2 bytes)

**dot11DisassociateStation:** This attribute holds the MAC address from the Address 1 field of the most recently transmitted Disassociation frame. If no Disassociation frame has been transmitted, the value of this attribute shall be 0. (R) (mandatory) (6 bytes)

**dot11DeauthenticateReason:** This attribute holds the most recently transmitted Reason Code in a Deauthentication frame. If no Deauthentication frame has been transmitted, the value of this attribute shall be 0. (R) (mandatory) (2 bytes)

**dot11DeauthenticateStation:** This attribute holds the MAC address from the Address 1 field of the most recently transmitted Deauthentication frame. If no Deauthentication frame has been transmitted, the value of this attribute shall be 0. (R) (mandatory) (6 bytes)

**dot11AuthenticateFailStatus:** This attribute holds the most recently transmitted Status Code in a failed Authentication frame. If no failed Authentication frame has been transmitted, the value of this attribute shall be 0. (R) (mandatory) (2 bytes)

**dot11AuthenticateFailStation:** This attribute holds the MAC address from the Address 1 field of the most recently transmitted failed Authentication frame. If no failed Authentication frame has been transmitted, the value of this attribute shall be 0. (R) (mandatory) (6 bytes)

**dot11WEPDefaultKeyValue1:** This attribute holds WEP Default Key #1. The WEP default secret keys are logically WRITE-ONLY. Attempts to read the entries in this table shall return unsuccessful status and values of null or zero. The default value of each WEP default key shall be null. (W) (mandatory) (5 bytes)

**dot11WEPDefaultKeyValue2:** This attribute holds WEP Default Key #2. (W) (mandatory) (5 bytes)

**dot11WEPDefaultKeyValue3:** This attribute holds WEP Default Key #3. (W) (mandatory) (5 bytes)

**dot11WEPDefaultKeyValue4:** This attribute holds WEP Default Key #4. (W) (mandatory) (5 bytes)

**dot11PrivacyInvoked&dot11ExcludeUnencrypted:** This attribute holds two truth values. It is coded 0000 00yx, where x indicates the dot11PrivacyInvoked value, and y indicates the dot11ExcludeUnencrypted value. When dot11PrivacyInvoked is true, it shall indicate that the IEEE 802.11 WEP mechanism is used for transmitting frames of type Data. The default value of this attribute shall be false. When dot11ExcludeUnencrypted is true, the STA shall not indicate at the MAC service interface received MSDUs that have the WEP subfield of the Frame Control field equal to zero. When this attribute is false, the STA may accept MSDUs that have the WEP subfield of the Frame Control field equal to zero. The default value of this attribute shall be false. (R, W) (mandatory) (1 byte)

**dot11WEPDefaultKeyID:** This attribute shall indicate the use of the first, second, third, or fourth WEPDefaultKey when set to values of zero, one, two, or three. The default value of this attribute shall be 0. (R, W) (mandatory) (1 byte)

**dot11WEPKeyMappingLength:** The maximum number of tuples that dot11WEPKeyMappings can hold. (R, W) (mandatory) (4 bytes)

**dot11WEPICVErrorCount:** This counter shall increment when a frame is received with the WEP subfield of the Frame Control field set to one and the value of the ICV as received in the frame does not match the ICV value that is calculated for the contents of the received frame. (R) (mandatory) (4 bytes)

**dot11WEPExcludedCount:** This counter shall increment when a frame is received with the WEP subfield of the Frame Control field set to zero and the value of dot11ExcludeUnencrypted causes that frame to be discarded. (R) (mandatory) (4 bytes)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

## Notifications

**Attribute Value Change:** This notification is used to report autonomous changes to the attributes of this managed entity. The attribute value change notification shall identify the attribute changed and its new value. The list of AVCs for this managed entity is given in Table 17. Notifications should be sent when a Disassociate, Deauthenticate, or AuthenticationFail event occurs. These events will normally coincide with a change in the DisassociateStation, DeauthenticateStation, or AuthenticationFailStation attributes.

**Table 17/G.983.2 – AVC list for 802.11 station management data 2  
(reproduced from Table 3/G.983.9)**

Number	Attribute value change	Description
1	N/A	
2	dot11DisassociateStation	MAC address from the Address 1 field of the most recently transmitted Disassociation frame
3	N/A	
4	dot11DeauthenticateStation	MAC address from the Address 1 field of the most recently transmitted Deauthentication frame
5	N/A	
6	dot11AuthenticateFailStation	MAC address from the Address 1 field of the most recently transmitted failed Authentication frame
7-15	N/A	
16	Reserved	

## 7.3.59 802.11 general purpose object

### Relationships

Many instances of this managed entity may exist for each instance of an IEEE 802.11 interface. This object is used to contain the following IEEE 802.11 data: WEP Key Mappings, Group Addresses, Reg Domain Supported, and Antennas List. Each of these uses has its own attributes defined, and a type attribute indicates which subset of attributes is active for each instance. Regardless of which attributes are active, each attribute shall be numbered (in attribute mask) according to the ordering of the full attribute set indicated below.

For object types 0 and 1, the OLT may create and delete instances of this object. For object types 2 and 3, the ONU instantiates as many instances as required to model the UNI's capabilities.

### Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**ObjectType:** This attribute indicates how this entity is to be used, defined as:

- 0: WEP Key Mapping;
- 1: Group Addresses;
- 2: Reg Domain Supported;
- 3: Antennas List.

For any given type, only the relevant attributes have valid contents. The other attributes are unspecified. (R, Set-by-create) (mandatory) (1 byte)

**PhysicalPathTerminationPoint802.11Pointer:** This attribute indicates the specific Physical Path Termination Point to which this object corresponds. (R, Set-by-create) (mandatory) (2 bytes)

**dot11WEPPKeyMappingAddress:** Valid if ObjectType = 0. The MAC address of the STA for which the values from this key mapping entry are to be used. (R, W, Set-by-create) (mandatory) (6 bytes)

**dot11WEPPKeyMappingWEPOn:** Valid if ObjectType = 0. Boolean as to whether WEP is to be used when communicating with the dot11WEPPKeyMappingAddress STA (R, W, Set-by-create) (mandatory) (1 byte)

**dot11WEPPKeyMappingValue:** Valid if ObjectType = 0. A WEP secret key value. (W, Set-by-create) (mandatory) (5 bytes)

**dot11Address:** Valid if ObjectType = 1. MAC address identifying a multicast addresses from which this STA will receive frames (R, Set-by-create) (mandatory) (6 bytes)

**dot11RegDomainsSupportValue:** Valid if ObjectType = 2. There are different operational requirements dependent on the regulatory domain. This attribute list describes the regulatory domains the PLCP and PMD support in this implementation. Currently defined values and their corresponding Regulatory Domains are: FCC (USA) = X'10', DOC (Canada) = X'20', ETSI (most of Europe) = X'30', Spain = X'31', France = X'32', MKK (Japan) = X'40' (R) (mandatory) (1 byte)

**dot11SupportedTxAntenna:** Valid if ObjectType = 3. When true, this Boolean object indicates that the antenna represented by this managed entity id can be used as a transmit antenna. (R) (mandatory) (1 byte)

**dot11SupportedRxAntenna:** Valid if ObjectType = 3. When true, this Boolean object indicates that the antenna represented by this managed entity id can be used as a receive antenna. (R) (mandatory) (1 byte)

**dot11DiversitySelection Rx:** Valid if ObjectType = 3. When true, this Boolean object indicates that the antenna represented by managed entity id can be used for receive diversity. This object may only be true if the antenna can be used as a receive antenna, as indicated by dot11SupportedRxAntenna (R, W) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### **7.3.60 802.11 MAC&PHY operation and antenna data**

#### *Relationships*

One instance of this managed entity may exist for each instance of an IEEE 802.11 interface. The ONU automatically creates an instance of this entity whenever a PPTP 802.11 UNI instance is created.



## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This ME id shall be the same as that of the related instance of Physical Path Termination Point 802.11 UNI. (R) (mandatory) (2 bytes)

**dot11MACAddress:** Unique MAC Address assigned to the STA. (R) (mandatory) (6 bytes)

**dot11RTSThreshold:** This attribute shall indicate the number of octets in an MPDU, below which an RTS/CTS handshake shall not be performed. An RTS/CTS handshake shall be performed at the beginning of any frame exchange sequence where the PDU is of type Data or Management, the MPDU has an individual address in the address1 field, and the length of the MPDU is greater than this threshold. Setting this attribute to be larger than the maximum MSDU size shall have the effect of turning off the RTS/CTS handshake for frames of Data or Management type transmitted by this STA. Setting this attribute to zero shall have the effect of turning on the RTS/CTS handshake for all frames of Data or Management type transmitted by this STA. The default value of this attribute shall be 2347. (R, W) (mandatory) (2 bytes)

**dot11ShortRetryLimit:** This attribute shall indicate the maximum number of transmission attempts of a frame, the length of which is less than or equal to dot11RTSThreshold, that shall be made before a failure condition is indicated. The default value of this attribute shall be 7. (R, W) (mandatory) (1 byte)

**dot11LongRetryLimit:** This attribute shall indicate the maximum number of transmission attempts of a frame, the length of which is greater than dot11RTSThreshold, that shall be made before a failure condition is indicated. The default value of this attribute shall be 4. (R, W) (mandatory) (1 byte)

**dot11FragmentationThreshold:** This attribute shall specify the current maximum size, in octets, of the MPDU that may be delivered to the PHY. An MSDU shall be broken into fragments if its size exceeds the value of this attribute after adding MAC headers and trailers. An MSDU or MMPDU shall be fragmented when the resulting frame has an individual address in the Address1 field, and the length of the frame is larger than this threshold. The default value for this attribute shall be the lesser of 2346 or the aMPDUMaxLength of the attached PHY and shall never exceed the lesser of 2346 or the aMPDUMaxLength of the attached PHY. The value of this attribute shall never be less than 256. (R, W) (mandatory) (2 bytes)

**dot11MaxTransmitMSDULifetime:** The MaxTransmitMSDULifetime shall be the elapsed time in TU, after the initial transmission of an MSDU, after which further attempts to transmit the MSDU shall be terminated. The default value of this attribute shall be 512. (R, W) (mandatory) (4 bytes)

**dot11MaxReceiveLifetime:** The MaxReceiveLifetime shall be the elapsed time in TU, after the initial reception of a fragmented MMPDU or MSDU, after which further attempts to reassemble the MMPDU or MSDU shall be terminated. The default value shall be 512. (R, W) (mandatory) (4 bytes)

**dot11PHYType:** This is an 8-bit integer value that identifies the PHY type supported by the attached PLCP and PMD. Currently defined values and their corresponding PHY types are: FHSS 2.4 GHz = 0x01, DSSS 2.4 GHz = 0x02, IR Baseband = 0x03. (R) (mandatory) (1 byte)

**dot11CurrentRegDomain:** The current regulatory domain this instance of the PMD is supporting. This object corresponds to one of the RegDomains listed in dot11RegDomainsSupported. (R, W) (mandatory) (4 bytes)

**dot11TempType:** There are different operating temperature requirements dependent on the anticipated environmental conditions. This attribute describes the current PHY's operating temperature range capability. Currently defined values and their corresponding temperature

ranges are: Type 1 = 0x01: Commercial range of 0 to 40 degrees C, Type 2 = 0x02: Industrial range of –30 to 70 degrees C. (R) (mandatory) (1 byte)

**dot11CurrentTxAntennaPointer:** The current antenna being used to transmit. This value is one of the values appearing in the dot11SupportedTxAntenna attribute of a General Purpose Object ME instance of ObjectType = 3. This may be used by a management agent to control which antenna is used for transmission. The value 0x0000 is interpreted as a Null pointer. (R, W) (mandatory) (2 bytes)

**dot11DiversitySupport:** This implementation's support for diversity, encoded as: 0x01: diversity is available and is performed over the fixed list of antennas defined by the dot11DiversitySelectionRx attribute values of the set of General Purpose Object ME instances of ObjectType = 3. 0x02: diversity is not supported. 0x03: diversity is supported and control of diversity is also available, in which case the attribute dot11DiversitySelectionRx can be dynamically modified by the LME. (R) (mandatory) (1 byte)

**dot11CurrentRxAntennaPointer:** The current antenna being used to receive, if the dot11DiversitySupport indicates that diversity is not supported. The selected antenna shall be one of the antennae marked for receive via the dot11SupportedRxAntenna attribute of a General Purpose Object ME instance of ObjectType = 3. The value 0x0000 is interpreted as a Null pointer. (R, W) (mandatory) (2 bytes)

**dot11CurrentTxPowerLevel:** The TxPowerLevel currently being used to transmit data. Some PHYs also use this value to determine the receiver sensitivity requirements for CCA. Valid values range from 0 to 7 and indicate which word in the dot11TxPowerLevels attribute of the Physical Path Termination Point 802.11 UNI object shall be the current power level. (R, W) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### **7.3.61 802.11 counters**

#### *Relationships*

One instance of this managed entity may exist for each instance of an IEEE 802.11 interface. An instance of this managed entity is created/deleted by the OLT after an instance of a Physical Path Termination Point 802.11 UNI managed entity is created/deleted.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0x0100 (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of

the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**dot11TransmittedFragmentCount:** This counter shall be incremented for an acknowledged MPDU with an individual address in the address 1 field or an MPDU with a multicast address in the address 1 field of type Data or Management. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11MulticastTransmittedFrame Count:** This counter shall increment only when the multicast bit is set in the destination MAC address of a successfully transmitted MSDU. When operating as a STA in an ESS, where these frames are directed to the AP, this implies having received an acknowledgment to all associated MPDUs. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11FailedCount:** This counter shall increment when an MSDU is not transmitted successfully due to the number of transmit attempts exceeding either the dot11ShortRetryLimit or dot11LongRetryLimit (specified in the corresponding attributes of the associated 802.11 MAC&PHY Operation and Antenna Data managed entity). If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11RetryCount:** This counter shall increment when an MSDU is successfully transmitted after one or more retransmissions. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11MultipleRetryCount:** This counter shall increment when an MSDU is successfully transmitted after more than one retransmission. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11FrameDuplicateCount:** This counter shall increment when a frame is received that the Sequence Control field indicates is a duplicate. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11RTSSuccessCount:** This counter shall increment when a CTS is received in response to an RTS. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11RTSFailureCount:** This counter shall increment when a CTS is not received in response to an RTS. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11ACKFailureCount:** This counter shall increment when an ACK is not received when expected. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11ReceivedFragmentCount:** This counter shall be incremented for each successfully received MPDU of type Data or Management. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11MulticastReceivedFrameCount:** This counter shall increment when a MSDU is received with the multicast bit set in the destination MAC address. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11FCSErrorCount:** This counter shall increment when an FCS error is detected in a received MPDU. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11TransmittedFrameCount:** This counter shall increment for each successfully transmitted MSDU. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

**dot11WEPUndecryptableCount:** This counter shall increment when a frame is received with the WEP subfield of the Frame Control field set to one and the WEPOn value for the key mapped to the TA's MAC address indicates that the frame should not have been encrypted or that frame is discarded due to the receiving STA not implementing the privacy option. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (4 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the current value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval. Support of this action is optional.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 18.

**Table 18/G.983.2 – Alarm list for 802.11 counters (reproduced from Table 4/G.983.9)**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold crossing alert</b>		
0	dot11Failed	MSDU transmit failure threshold crossing	1
1	dot11RTSFailure	RTS failure count threshold crossing	2
2	dot11ACKFailure	ACK failure count threshold crossing	3
3	dot11FCSError	FCS error count threshold crossing	4
4	dot11WEPUndecryptable	WEP undecryptable count threshold crossing	5
5-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data managed entity. Threshold Data counter 1 indicates the 1st thresholded counter that is associated with the Threshold Value 1 attribute of the Threshold Data <sub>B-PON</sub> managed entity.			

### 7.3.62 802.11 PHY FHSS DSSS IR tables

#### *Relationships*

One instance of this managed entity may exist for each instance of an IEEE 802.11 interface. The ONU automatically creates an instance of this entity whenever a PPTP 802.11 UNI instance is created.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This ME id shall be the same as that of the related instance of Physical Path Termination Point 802.11 UNI. (R) (mandatory) (2 bytes)

**dot11HopTime:** The time in microseconds for the PMD to change from channel 2 to channel 80. (R) (mandatory) (1 byte)

**dot11CurrentChannelNumber:** The current channel number of the frequency output by the RF synthesizer. (R, W) (mandatory) (1 byte)

**dot11MaxDwellTime:** The maximum time in TU that the transmitter is permitted to operate on a single channel. (R) (mandatory) (2 bytes)

**dot11CurrentDwellTime:** The current time in TU that the transmitter shall operate on a single channel, as set by the MAC. Default is 19 TU. (R, W) (mandatory) (2 bytes)

**dot11CurrentSet:** The current set of patterns the PHY LME is using to determine the hopping sequence. (R, W) (mandatory) (1 byte)

**dot11CurrentPattern:** The current pattern the PHY LME is using to determine the hop sequence. (R, W) (mandatory) (1 byte)

**dot11CurrentIndex:** The current index value the PHY LME is using to determine the CurrentChannelNumber. (R, W) (mandatory) (1 byte)

**dot11CurrentChannel:** The current operating frequency channel of the DSSS PHY. Valid channel numbers are as defined in [B-13] Section 15.4.6.2. (R, W) (mandatory) (1 byte)

**dot11CCAModeSupported:** dot11CCAModeSupported is a bit-significant value, representing all of the CCA modes supported by the PHY. Valid values are: energy detect only (ED\_ONLY) = 0x01, carrier sense only (CS\_ONLY) = 0x02, carrier sense and energy detect (ED\_and\_CS) = 0x04 or the logical sum of any of these values. (R) (mandatory) (1 byte)

**dot11CurrentCCAMode:** The current CCA method in operation. Valid values are: energy detect only (edonly) = 0x01, carrier sense only (csonly) = 0x02, carrier sense and energy detect (edandcs) = 0x04. (R, W) (mandatory) (1 byte)

**dot11EDThreshold:** The current Energy Detect Threshold being used by the DSSS PHY. (R, W) (mandatory) (4 bytes)

**dot11CCAWatchdogTimerMax:** This parameter, together with CCAWatchdogCountMax, determines when energy detected in the channel can be ignored. Units are in time ticks. (R, W) (mandatory) (4 bytes)

**dot11CCAWatchdogCountMax:** This parameter, together with CCAWatchdogTimerMax, determines when energy detected in the channel can be ignored. Units are in time ticks. (R, W) (mandatory) (4 bytes)

**dot11CCAWatchdogTimerMin:** The minimum value to which CCAWatchdogTimerMax can be set. Units are in time ticks. (R, W) (mandatory) (4 bytes)

**dot11CCAWatchdogCountMin:** The minimum value to which CCAWatchdogCount can be set. Units are in time ticks. (R, W) (mandatory) (4 bytes)

## *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

## **Notifications**

None.

### **7.3.63 Physical path termination point ADSL UNI part 1**

This managed entity represents the point at an ATM UNI in the ONU where physical paths terminate to an ADSL CO Modem.

One or more instances of this managed entity shall be automatically created/deleted by the ONU upon the creation/deletion of a Subscriber Line Card of ADSL type.

#### **Establishment of a "Physical Path Termination Point ADSL UNI"**

The Physical Path Termination Point ADSL UNI is auto created when the Subscriber Line Card of type ADSL is created. On auto creation, the 5 profile pointers within the Managed Entity are set to their default values of 0x00. However, the PPTP ADSL UNI Part 1 must refer to 5 valid profiles before it can be operational.

## *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as ADSL type.

## *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot ID (defined in 7.1.3). The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a subscriber line card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Loopback Configuration:** This attribute represents the loopback configuration of this physical interface. Value 0x00: no loopback; value 0x01: loopback2 ("Loopback2") refers to a loopback at the ONU to the OLT. The OLT can execute a physical level loopback test after loopback2 is set. Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) the functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**ADSL Line Configuration Profile:** This attribute contains the Managed Entity ID of the ADSL Line Configuration Profiles (parts 1, 2, and 3) managed entities that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Line Configuration Profile. The value 0x00 is the default value, which is set when this ME is auto-created. (R, W) (mandatory) (2 bytes)

**ADSL Subcarrier Masking Downstream Profile:** This attribute provides a pointer to an instance of the ADSL Subcarrier Masking Downstream Profile managed entity that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Subcarrier Masking Downstream Profile. The value 0x00 is the default value, which is set when this ME is auto-created. (R, W) (mandatory) (2 bytes)

**ADSL Subcarrier Masking Upstream Profile:** This attribute provides a pointer to an instance of the ADSL Subcarrier Masking Upstream Profile managed entity that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Subcarrier Masking Upstream Profile. The value 0x00 is the default value, which is set when this ME is auto-created. (R, W) (mandatory) (2 bytes)

**ADSL Downstream PSD Mask Profile:** This attribute provides a pointer to an instance of the ADSL Downstream PSD Mask Profile managed entity that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Downstream PSD Mask Profile. The value 0x00 is the default value, which is set when this ME is auto-created. (R, W) (mandatory) (2 bytes)

**ADSL Downstream RFI Bands Profile:** This attribute provides a pointer to an instance of the ADSL Downstream RFI Bands Profile managed entity that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Downstream RFI Bands Profile. The value 0x00 is the default value, which is set when this ME is auto-created. (R, W) (mandatory) (2 bytes)

**ARC:** This attribute is used to control alarm reporting from this managed entity. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ARCInterval:** This attribute provides a provisionable length of time. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify the attribute and its new value. The AVCs for this managed entity are given in Table 19.

**Table 19/G.983.2 – AVC list for physical path termination point ADSL UNI  
(reproduced from Table 2/G.983.10)**

Number	AVC	Description
1-2	N/A	
3	OpState	Operational state
4-10	N/A	
11-16	Reserved	

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONU and OLT should know the alarm list used by this entity. The alarms for this entity are given in Table 20.

**Table 20/G.983.2 – Alarm list for physical path termination point ADSL UNI  
(reproduced from Table 3/G.983.10)**

Number	Event	Description
	<b>Alarm</b>	
0	NE_LOF	Near End Loss of Frame
1	NE_LOS	Near End Loss of Signal
2	NE_LOL	Near End Loss of Link
3	NE_LPR	Near End Loss of Power
4	CARD_ALM	Card in Alarm
5	FE_LOF	Far End Loss of Frame
6	FE_LOS	Far End Loss of Signal
7	FE_LOL	Far End Loss of Link
8	FE_LPR	Far End Loss of Power
9	DRT_UP	Data Rate Threshold Up-shift alarm
10	DRT_DOWN	Data Rate Threshold Down-shift alarm
11-223	reserved	
224-239	Vendor-specific alarms	Not to be standardized

#### **7.3.64 Physical path termination point ADSL UNI part 2**

This managed entity represents the point at an ATM UNI in the ONU where physical paths terminate to an ADSL CO Modem.

One or more instances of this managed entity shall be automatically created/deleted by the ONU upon the creation/deletion of a Subscriber Line Card of ADSL type.

##### **Establishment of a "Physical Path Termination Point ADSL UNI"**

The Physical Path Termination Point ADSL UNI is auto created when the Subscriber Line Card of type ADSL is created. On auto creation the 8 profile pointers within the Managed Entity are set to their default values of 0x00. However, the PPTP ADSL UNI Part 2 must refer to at least 2 valid profiles before it can be operational.

##### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as ADSL type.

##### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot ID (defined in 7.1.3). The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a subscriber line card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**ADSL Channel Configuration Profile (For Bearer Channel 0 Downstream):** This attribute provides a pointer to an instance of the ADSL Channel Configuration Profile managed entity for Bearer Channel 0 Downstream that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Channel Configuration Profile. The value 0x00 is the default value, which is set when this ME is auto created. (R, W) (optional) (2 bytes)



**ADSL Channel Configuration Profile (For Bearer Channel 1 Downstream):** This attribute provides a pointer to an instance of the ADSL Channel Configuration Profile managed entity for Bearer Channel 1 Downstream that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Channel Configuration Profile. The value 0x00 is the default value, which is set when this ME is auto created. (R, W) (optional) (2 bytes)

**ADSL Channel Configuration Profile (For Bearer Channel 2 Downstream):** This attribute provides a pointer to an instance of the ADSL Channel Configuration Profile managed entity for Bearer Channel 2 Downstream that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Channel Configuration Profile. The value 0x00 is the default value, which is set when this ME is auto created. (R, W) (optional) (2 bytes)

**ADSL Channel Configuration Profile (For Bearer Channel 3 Downstream):** This attribute provides a pointer to an instance of the ADSL Channel Configuration Profile managed entity for Bearer Channel 3 Downstream that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Channel Configuration Profile. The value 0x00 is the default value, which is set when this ME is auto created. (R, W) (optional) (2 bytes)

**ADSL Channel Configuration Profile (For Bearer Channel 0 Upstream):** This attribute provides a pointer to an instance of the ADSL Channel Configuration Profile managed entity for Bearer Channel 0 Upstream that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Channel Configuration Profile. The value 0x00 is the default value, which is set when this ME is auto created. (R, W) (optional) (2 bytes)

**ADSL Channel Configuration Profile (For Bearer Channel 1 Upstream):** This attribute provides a pointer to an instance of the ADSL Channel Configuration Profile managed entity for Bearer Channel 1 Upstream that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Channel Configuration Profile. The value 0x00 is the default value, which is set when this ME is auto created. (R, W) (optional) (2 bytes)

**ADSL Channel Configuration Profile (For Bearer Channel 2 Upstream):** This attribute provides a pointer to an instance of the ADSL Channel Configuration Profile managed entity for Bearer Channel 2 Upstream that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Channel Configuration Profile. The value 0x00 is the default value, which is set when this ME is auto created. (R, W) (optional) (2 bytes)

**ADSL Channel Configuration Profile (For Bearer Channel 3 Upstream):** This attribute provides a pointer to an instance of the ADSL Channel Configuration Profile managed entity for Bearer Channel 3 Upstream that contains the data necessary for initializing an ADSL MODEM. The value 0x00 is used to indicate that this ME does not point to an ADSL Channel Configuration Profile. The value 0x00 is the default value, which is set when this ME is auto created. (R, W) (optional) (2 bytes)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Actions*

None.

### 7.3.65 ADSL line inventory and status data part 1

This managed entity contains Part 1 of the Line Inventory and Status Data for an ADSL line. One or more instances of this managed entity shall be automatically created/deleted by the ONU upon the creation/deletion of a Subscriber Line Card of ADSL type.

#### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as ADSL type. All attributes other than Managed Entity ID will default to zero.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the ID of the Physical Path Termination Point ADSL UNI with which this ADSL Line Inventory Data is associated. (R) (mandatory) (2 bytes)

**ATU-C G.994.1 Vendor ID:** The ATU-C G.994.1 Vendor ID is the Vendor ID as inserted by the ATU-C in the G.994.1 CL message. It consists of 8 binary octets, including a country code followed by a (regionally allocated) provider code, as defined in ITU-T Rec. T.35. (R) (mandatory) (8 bytes)

**ATU-R G.994.1 Vendor ID:** The ATU-R G.994.1 Vendor ID is the Vendor ID as inserted by the ATU-R in the G.994.1 CLR message. It consists of 8 binary octets, with same format as the ATU-C G.994.1 Vendor ID (R) (mandatory) (8 bytes)

**ATU-C System Vendor ID:** The ATU-C System Vendor ID is the Vendor ID as inserted by the ATU-C in the Overhead Messages (ITU-T Recs G.992.3 and G.992.4). It consists of 8 binary octets, with same format as the ATU-C G.994.1 Vendor ID. (R) (mandatory) (8 bytes)

**ATU-R System Vendor ID:** The ATU-R System Vendor ID is the Vendor ID as inserted by the ATU-R in the Embedded Operations Channel (ITU-T Recs G.992.1 and G.992.2) and the Overhead Messages (ITU-T Recs G.992.3 and G.992.4). It consists of 8 binary octets, with same format as the ATU-C G.994.1 Vendor ID. (R) (mandatory) (8 bytes)

**ATU-C Version Number:** The ATU-C version number is the version number as inserted by the ATU-C in the Overhead Messages (ITU-T Recs G.992.3 and G.992.4). It is for version control and is vendor-specific information. It consists of up to 16 binary octets. (R) (mandatory) (16 bytes)

**ATU-R Version Number:** The ATU-R version number is the version number as inserted by the ATU-R in the Embedded Operations Channel (ITU-T Recs G.992.1 and G.992.2) or Overhead Messages (ITU-T Recs G.992.3 and G.992.4). It is for version control and is vendor-specific information. It consists of up to 16 binary octets. (R) (mandatory) (16 bytes)

**ATU-C Serial Number Part 1:** The ATU-C serial number is the serial number as inserted by the ATU-C in the Overhead Messages (ITU-T Recs G.992.3 and G.992.4). It is vendor-specific information. It consists of up to 32 ASCII characters. This attribute contains the first 16 characters. (R) (mandatory) (16 bytes)

**ATU-C Serial Number Part 2:** The ATU-C serial number is the serial number as inserted by the ATU-C in the Overhead Messages (ITU-T Recs G.992.3 and G.992.4). It is vendor-specific information. It consists of up to 32 ASCII characters. This attribute contains the second 16 characters. (R) (mandatory) (16 bytes)

**ATU-R Serial Number Part 1:** The ATU-R version number is the version number as inserted by the ATU-R in the Embedded Operations Channel (ITU-T Recs G.992.1 and G.992.2) or Overhead Messages (ITU-T Recs G.992.3 and G.992.4). It is vendor-specific information. It

consists of up to 32 ASCII characters. This attribute contains the first 16 characters. (R) (mandatory) (16 bytes)

**ATU-R Serial Number Part 2:** The ATU-R version number is the version number as inserted by the ATU-R in the Embedded Operations Channel (ITU-T Recs G.992.1 and G.992.2) or Overhead Messages (ITU-T Recs G.992.3 and G.992.4). It is vendor-specific information. It consists of up to 32 ASCII characters. This attribute contains the second 16 characters. (R) (mandatory) (16 bytes)

**ATU-C Self Test Results:** This parameter defines the ATU-C self-test result. It is coded as a 32-bit integer. The most significant octet of the self-test result is 00hex if the self-test passed and 01hex if the self-test failed. The interpretation of the other octets is vendor-discretionary and can be interpreted in combination with ITU-T Rec. G.994.1 and system Vendor IDs. (R) (mandatory) (4 bytes)

**ATU-R Self Test Results:** This parameter defines the ATU-R self-test result. It is coded as a 32-bit integer. The most significant octet of the self-test result is 00hex if the self-test passed and 01hex if the self-test failed. The interpretation of the other octets is vendor-discretionary and can be interpreted in combination with ITU-T Rec. G.994.1 and system Vendor IDs. (R) (mandatory) (4 bytes)

**ATU-C Transmission System Capability:** This parameter defines the ATU-C transmission system capability list of the different coding types. It is coded in a bit-map representation with the bits defined in Table 21. (R) (mandatory) (7 bytes)

**ATU-R Transmission System Capability:** This parameter defines the ATU-R transmission system capability list of the different coding types. It is coded in a bit-map representation with the bits defined in Table 21. (R) (mandatory) (7 bytes)

**Initialization – Success/Failure Cause:** This parameter represents the success or failure cause of the last full initialization performed on the line. It is coded as an integer in the 0 to 5 range, coded as follows:

- 0 Successful
- 1 Configuration error  
This error occurs with inconsistencies in configuration parameters, e.g., when the line is initialized in an ADSL Transmission system where an ATU does not support the configured Maximum Delay or the configured Minimum or Maximum Data Rate for one or more bearer channels.
- 2 Configuration not feasible on the line  
This error occurs if the Minimum Data Rate cannot be reached on the line with the Minimum Noise Margin, Maximum PSD level, Maximum Delay and Maximum Bit Error Ratio for one or more bearer channels.
- 3 Communication problem  
This error occurs e.g., due to corrupted messages or bad syntax messages or if no common mode can be selected in the G.994.1 handshaking procedure or due to a timeout.
- 4 No peer ATU detected  
This error occurs if the peer ATU is not powered or not connected or if the line is too long to allow detection of a peer ATU.
- 5 Any other or unknown Initialization Failure cause.

(R) (mandatory) (1 byte)

## Actions

**Get:** Get one or more attributes.

## Notifications

None.

The following is an explanation of the ATU Transmission System Capability Attributes in the ADSL Managed entity. It is coded in a bit-map representation (0 if not allowed, 1 if allowed) with following definition:

**Table 21/G.983.2 – ATU transmission system table (reproduced from Table 4/G.983.10)**

Bit	Representation
<b>Octet 1</b>	
1	ANSI T1.413
2	Annex C of TS 101 388 v1.3.1
3	G.992.1 operation over POTS non-overlapped spectrum (Annex A/G.992.1)
4	G.992.1 operation over POTS overlapped spectrum (Annex A/G.992.1)
5	G.992.1 operation over ISDN non-overlapped spectrum (Annex B/G.992.1)
6	G.992.1 operation over ISDN overlapped spectrum (Annex B/G.992.1)
7	G.992.1 operation in conjunction with TCM-ISDN non-overlapped spectrum (Annex C/G.992.1)
8	G.992.1 operation in conjunction with TCM-ISDN overlapped spectrum (Annex C/G.992.1)
<b>Octet 2</b>	
9	G.992.2 operation over POTS non-overlapped spectrum (Annex A/G.992.2)
10	G.992.2 operation over POTS overlapped spectrum (Annex B/G.992.2)
11	G.992.2 operation in conjunction with TCM-ISDN non-overlapped spectrum (Annex C/G.992.2)
12	G.992.2 operation in conjunction with TCM-ISDN overlapped spectrum (Annex C/G.992.2)
13	Reserved
14	Reserved
15	Reserved
16	Reserved
<b>Octet 3</b>	
17	Reserved
18	Reserved
19	G.992.3 operation over POTS non-overlapped spectrum (Annex A/G.992.3)
20	G.992.3 operation over POTS overlapped spectrum (Annex A/G.992.3)
21	G.992.3 operation over ISDN non-overlapped spectrum (Annex B/G.992.3)
22	G.992.3 operation over ISDN overlapped spectrum (Annex B/G.992.3)
23	Reserved
24	Reserved

**Table 21/G.983.2 – ATU transmission system table (reproduced from Table 4/G.983.10)**

Bit	Representation
<b>Octet 4</b>	
25	G.992.4 operation over POTS non-overlapped spectrum (Annex A/G.992.4)
26	G.992.4 operation over POTS overlapped spectrum (Annex A/G.992.4)
27	Reserved
28	Reserved
29	G.992.3 All Digital Mode operation with non-overlapped spectrum (Annex I/G.992.3)
30	G.992.3 All Digital Mode operation with overlapped spectrum (Annex I/G.992.3)
31	G.992.3 All Digital Mode operation with non-overlapped spectrum (Annex J/G.992.3)
32	G.992.3 All Digital Mode operation with overlapped spectrum (Annex J/G.992.3)
<b>Octet 5</b>	
33	G.992.4 All Digital Mode operation with non-overlapped spectrum (Annex I/G.992.4)
34	G.992.4 All Digital Mode operation with overlapped spectrum (Annex I/G.992.4)
35	G.992.3 Reach Extended operation over POTS, Mode 1 (non-overlapped, wide upstream) (Annex L/G.992.3)
36	G.992.3 Reach Extended operation over POTS, Mode 2 (non-overlapped, narrow upstream) (Annex L/G.992.3)
37	G.992.3 Reach Extended operation over POTS, Mode 3 (overlapped, wide upstream) (Annex L/G.992.3)
38	G.992.3 Reach Extended operation over POTS, Mode 4 (overlapped, narrow upstream) (Annex L/G.992.3)
39	G.992.3 Extended upstream operation over POTS non-overlapped spectrum (Annex M/G.992.3)
40	G.992.3 Extended upstream operation over POTS overlapped spectrum (Annex M/G.992.3)
<b>Octet 6</b>	
41	G.992.5 operation over POTS non-overlapped spectrum (Annex A/G.992.5)
42	G.992.5 operation over POTS overlapped spectrum (Annex A/G.992.5)
43	G.992.5 operation over ISDN non-overlapped spectrum (Annex B/G.992.5)
44	G.992.5 operation over ISDN overlapped spectrum (Annex B/G.992.5)
45	Reserved
46	Reserved
47	G.992.5 All Digital Mode operation with non-overlapped spectrum (Annex I/G.992.5)
48	G.992.5 All Digital Mode operation with overlapped spectrum (Annex I/G.992.5)
<b>Octet 7</b>	
49	G.992.5 All Digital Mode operation with non-overlapped spectrum (Annex J/G.992.5)
50	G.992.5 All Digital Mode operation with overlapped spectrum (Annex J/G.992.5)
51	G.992.5 Extended upstream operation over POTS non-overlapped spectrum (Annex M/G.992.5)
52	G.992.5 Extended upstream operation over POTS overlapped spectrum (Annex M/G.992.5)
53	Reserved

**Table 21/G.983.2 – ATU transmission system table (reproduced from Table 4/G.983.10)**

Bit	Representation
54	Reserved
55	Reserved
56	Reserved

### **7.3.66 ADSL line inventory and status data part 2**

This managed entity contains Part 2 of the Line Inventory and Status Data for an ADSL line. One or more instances of this managed entity shall be automatically created/deleted by the ONU upon the creation/deletion of a Subscriber Line Card of ADSL type.

#### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as ADSL type.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the ID of the Physical Path Termination Point ADSL UNI with which this ATU-R Physical Data is associated. (R) (mandatory) (2 bytes)

**ADSL Transmission System:** This parameter defines the transmission system in use. It is coded in bitmap representation with the bits defined in Table 21. (R) (mandatory) (7 bytes)

**Line Power Management State:** The Line has four possible power management states, numbered 0 to 3 and corresponding to respectively:

- 0 = L0 – Synchronized – This Line state (L0) is when the Line has full transmission (i.e., showtime).
- 1 = L1 – Power Down Data transmission – This line state (L1) is when there is transmission on the line but the net data rate is reduced (e.g., only for OAM and higher layer connection and session control). This state applies to ITU-T Rec. G.992.2 only.
- 2 = L2 – Power Down Data transmission – This line state (L2) is when there is transmission on the line but the net data rate is reduced (e.g., only for OAM and higher layer connection and session control). This state applies to ITU-T Recs G.992.3 and G.992.4 only.
- 3 = L3 – No-power – This Line state (L3) is when there is No Power transmitted on the line at all.

(R) (mandatory) (1 byte)

**Downstream Line Attenuation:** This parameter is the measured difference in the total power transmitted by the ATU-C and the total power received by the ATU-R over all subcarriers during diagnostics mode and initialization. The downstream line attenuation ranges from 0 (0) to +127 (1270) dB with 0.1 dB steps. A special value (0xFFFF) indicates the line attenuation is out of range to be represented. (R) (mandatory) (2 bytes)

**Upstream Line Attenuation:** This parameter is the measured difference in dB in the total power transmitted by the ATU-R and the total power received by the ATU-C over all subcarriers during diagnostics mode and initialization. The upstream line attenuation ranges from 0 (0) to +127 (1270) dB with 0.1 dB steps. A special value (0xFFFF) indicates the line attenuation is out of range to be represented. (R) (mandatory) (2 bytes)

**Downstream Signal Attenuation:** This parameter is the measured difference in the total power transmitted by the ATU-C and the total power received by the ATU-R over all subcarriers during showtime. The downstream line attenuation ranges from 0 (0) to +127 (1270) dB with 0.1 dB steps. A special value (0xFFFF) indicates the line attenuation is out of range to be represented. (R) (mandatory) (2 bytes)

**Upstream Signal Attenuation:** This parameter is the measured difference in dB in the total power transmitted by the ATU-R and the total power received by the ATU-C over all subcarriers during showtime. The upstream line attenuation ranges from 0 (0) to +127 (1270) dB with 0.1 dB steps. A special value (0xFFFF) indicates the line attenuation is out of range to be represented. (R) (mandatory) (2 bytes)

**Downstream Signal-to-Noise Ratio Margin:** The downstream signal-to-noise ratio margin is the maximum increase in dB of the noise power received at the ATU-R, such that the BER requirements are met for all downstream bearer channels. The downstream SNR margin ranges from –64 (0) dB to +63 (1280) dB with 0.1 dB steps. A special value (0xFFFF) indicates the parameter is out of range to be represented. (R) (mandatory) (2 bytes)

**Upstream Signal-to-Noise Ratio Margin:** The upstream signal-to-noise ratio margin is the maximum increase in dB of the noise power received at the ATU-C, such that the BER requirements are met for all upstream bearer channels. The upstream SNR margin ranges from –64 (0) dB to +63 (1280) dB with 0.1 dB steps. A special value (0xFFFF) indicates the parameter is out of range to be represented. (R) (mandatory) (2 bytes)

**Downstream Maximum Attainable Data Rate:** This parameter indicates the maximum downstream net data rate currently attainable by the ATU-C transmitter and the ATU-R receiver. The rate is coded in bit/s. (R) (mandatory) (4 bytes)

**Upstream Maximum Attainable Data Rate:** This parameter indicates the maximum upstream net data rate currently attainable by the ATU-R transmitter and the ATU-C receiver. The rate is coded in bit/s. (R) (mandatory) (4 bytes)

**Downstream Actual Power Spectrum Density:** This parameter is the average downstream transmit power spectrum density over the used subcarriers (subcarriers to which downstream user data are allocated) delivered by the ATU-C at the U-C reference point, at the instant of measurement. The power spectrum density level ranges from –90 (0) dBm/Hz to 0 (900) dBm/Hz with 0.1 dB steps. A special value (0xFFFF) indicates the parameter is out of range to be represented. (R) (mandatory) (2 bytes)

**Upstream Actual Power Spectrum Density:** This parameter is the average upstream transmit power spectrum density over the used subcarriers (subcarriers to which upstream user data are allocated) delivered by the ATU-C at the U-C reference point, at the instant of measurement. The power spectrum density level ranges from –90 (0) dBm/Hz to 0 (900) dBm/Hz with 0.1 dB steps. A special value (0xFFFF) indicates the parameter is out of range to be represented. (R) (mandatory) (2 bytes)

**Downstream Actual Aggregate Transmit Power:** This parameter is the total amount of transmit power delivered by the ATU-C at the U-C reference point, at the instant of measurement. The total output power level ranges from –31 (0) dBm to +31 (620) dBm with 0.1 dB steps. A special value (0xFFFF) indicates the parameter is out of range to be represented.

NOTE – The downstream nominal aggregate transmit power may be taken as a best estimate of the parameter.

(R) (mandatory) (2 bytes)

**Upstream Actual Aggregate Transmit Power:** This parameter is the total amount of transmit power delivered by the ATU-R at the U-R reference point, at the instant of measurement. The

total output power level ranges from –31 (0) dBm to +31 (620) dBm with 0.1 dB steps. A special value (0xFFFF) indicates the parameter is out of range to be represented.

NOTE – The upstream nominal aggregate transmit power may be taken as a best estimate of the parameter.

(R) (mandatory) (2 bytes)

**Initialization – Last State Transmitted Downstream:** This parameter represents the last successful transmitted initialization state in the downstream direction in the last full initialization performed on the line. Initialization states are defined in the individual ADSL Recommendations and are counted from 0 (if ITU-T Rec. G.994.1 is used) or 1 (if ITU-T Rec. G.994.1 is not used) up to Showtime. This parameter must be interpreted along with the ADSL Transmission System.

This parameter is available only when, after a failed full initialization, the line diagnostics procedures are activated on the line. Line diagnostics procedures can be activated by the operator of the system (through the Line State Forced line configuration parameter) or autonomously by the ATU-C or ATU-R. (R) (mandatory) (1 byte)

**Initialization – Last State Transmitted Upstream:** This parameter represents the last successful transmitted initialization state in the upstream direction in the last full initialization performed on the line. Initialization states are defined in the individual ADSL Recommendations and are counted from 0 (if ITU-T Rec. G.994.1 is used) or 1 (if ITU-T Rec. G.994.1 is not used) up to Showtime. This parameter must be interpreted along with the ADSL Transmission System.

This parameter is available only when, after a failed full initialization, the line diagnostics procedures are activated on the line. Line diagnostics procedures can be activated by the operator of the system (through the Line State Forced line configuration parameter) or autonomously by the ATU-C or ATU-R. (R) (mandatory) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

#### *Notifications*

None.

### **7.3.67 ADSL channel downstream status data**

This managed entity contains the ADSL Channel Downstream Status Data. One or more instances of this managed entity shall be automatically created/deleted by the ONU upon the creation/deletion of a Subscriber Line Card of ADSL type.

#### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as ADSL type.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The two most significant bits of the first byte is the Bearer Channel ID. The six least significant bits of the first byte is the slot ID (defined in 7.1.3). The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a subscriber line card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Actual Interleaving Delay:** This parameter is the actual one-way interleaving delay introduced by the PMS-TC between the alpha and beta reference points excluding delay in L1 and L2 state. In L1 and L2 state, the parameter contains the interleaving delay in the previous L0 state. This



parameter is derived from the S and D parameters as  $\lceil S \cdot D \rceil / 4$  ms, where "S" is the Symbols per codeword, and "D" is the "Interleaving Depth" and  $\lceil x \rceil$  denotes rounding to the higher integer. The Actual Interleaving Delay is coded in ms rounded to the nearest ms. 0-255 ms. (R) (mandatory) (1 byte)

**Actual Data Rate:** This parameter reports the actual net data rate the bearer channel is operating at excluding rate in L1 and L2 states. In L1 or L2 states, the parameter contains the net data rate in the previous L0 state. The data rate is coded in bit/s. (R) (mandatory) (4 bytes)

**Previous Data Rate:** This parameter reports the previous net data rate the bearer channel was operating at just before the latest rate change event occurred excluding all transitions between L0 state and L1 or L2 states. A rate change can occur at a power management state transition, e.g., at full or short initialization, fast retrain, or power down or at a dynamic rate adaptation. The rate is coded in bit/s. (R) (mandatory) (4 bytes)

#### *Actions*

**Get:** Get one or more attributes.

#### *Notifications*

None.

### **7.3.68 ADSL channel upstream status data**

This managed entity contains the ADSL Channel Upstream Status Data.

One or more instances of this managed entity shall be automatically created/deleted by the ONU upon the creation/deletion of a Subscriber Line Card of ADSL type.

#### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as ADSL type.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The two most significant bits of the first byte is the Bearer Channel ID. The six least significant bits of the first byte is the slot ID (defined in 7.1.3). The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a subscriber line card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Actual Interleaving Delay:** This parameter is the actual one-way interleaving delay introduced by the PMS-TC between the alpha and beta reference points excluding delay in L1 and L2 state. In L1 and L2 state, the parameter contains the interleaving delay in the previous L0 state. This parameter is derived from the S and D parameters as  $\lceil S \cdot D \rceil / 4$  ms, where "S" is the Symbols per codeword, and "D" is the "Interleaving Depth" and  $\lceil x \rceil$  denotes rounding to the higher integer. The Actual Interleaving Delay is coded in ms (rounded to the nearest ms). (R) (mandatory) (1 byte)

**Actual Data Rate:** This parameter reports the actual net data rate the bearer channel is operating at excluding rate in L1 and L2 states. In L1 or L2 states, the parameter contains the net data rate in the previous L0 state. The data rate is coded in bit/s. (R) (mandatory) (4 bytes)

**Previous Data Rate:** This parameter reports the previous net data rate the bearer channel was operating at just before the latest rate change event occurred excluding all transitions between L0 state and L1 or L2 states. A rate change can occur at a power management state transition,

e.g., at full or short initialization, fast retrain, or power down or at a dynamic rate adaptation. The rate is coded in bit/s. (R) (mandatory) (4 bytes)

#### *Actions*

**Get:** Get one or more attributes.

#### *Notifications*

None.

### **7.3.69 ADSL line configuration profile part 1**

This managed entity contains part 1 of the Line Configuration Profile for an ADSL line. An instance of this managed entity is created/deleted on request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall exist and may be associated with zero or more instances of the Physical Path Termination Point ADSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**ATU Transmission System Enabling:** This configuration parameter defines the transmission system coding types to be allowed by the near-end ATU on this line. This parameter only applies to the Q-interface. It is coded in a bit-map representation with the bits defined in Table 21. (R, W, Set-by-create) (mandatory) (7 bytes)

**Power Management State Forced:** This configuration parameter defines the line states to be forced by the near-end ATU on this line. It is coded as an integer value with following definition:

- 0 Force the line to transition from the L3 idle state to the L0 full-on state. This transition requires the (short) initialization procedures. After reaching the L0 state, the line may transition into or exit from the L2 low power state (if L2 state is enabled). If the L0 state is not reached (after a vendor discretionary number of retries and/or within a vendor-discretionary timeout), then an Initialization Failure occurs. Whenever the line is in the L3 state, attempts shall be made to transition to the L0 state until it is forced into another state through this configuration parameter.
- 2 Force the line to transition from L0 full on to L2 low power state. This transition requires the entry into L2 mode. This is an out-of-service test value for triggering the L2 mode.
- 3 Force the line to transition from the L0 full-on or L2 low power state to the L3 idle state. This transition requires the (orderly) shutdown procedure. After reaching the L3 state, the line shall remain in the L3 idle state until it is forced into another state through this configuration parameter.

(R, W, Set-by-create) (mandatory) (1 byte)

**Power Management State Enabling:** This configuration parameter defines the line states the ATU-C or ATU-R may autonomously transition to on this line. It is coded in a bit-map representation (0 if not allowed, 1 if allowed) with following definition:

Bit 0: L3 state (Idle state);

Bit 1: L1/L2 state (Low power state).

(R, W, Set-by-create) (mandatory) (1 byte)

**Downstream Target Noise Margin:** This is the Noise Margin the ATU-R receiver shall achieve, relative to the BER requirement for each of the downstream bearer channels, or better, to successfully complete initialization. The target noise margin ranges from 0 (0) to 31 (310) dB with 0.1 dB steps. (R, W, Set-by-create) (mandatory) (2 bytes)

**Upstream Target Noise Margin:** This is the Noise Margin the ATU-C receiver shall achieve, relative to the BER requirement for each of the upstream bearer channels, or better, to successfully complete initialization. The target noise margin ranges from 0 (0) to 31 (310) dB with 0.1 dB steps. (R, W, Set-by-create) (mandatory) (2 bytes)

**Downstream Maximum Noise Margin:** This is the maximum noise margin the ATU-R receiver shall try to sustain. If the Noise Margin is above this level, the ATU-R shall request the ATU-C to reduce the ATU-C transmit power to get a noise margin below this limit (if this functionality is supported). The maximum noise margin ranges from 0 (0) to 31 (310) dB with 0.1 dB steps. A special value of 0xFFFF is used to indicate that no Maximum Noise Margin limit is to be applied. (R, W, Set-by-create) (mandatory) (2 bytes)

**Upstream Maximum Noise Margin:** This is the maximum noise margin the ATU-C receiver shall try to sustain. If the Noise Margin is above this level, the ATU-C shall request the ATU-R to reduce the ATU-R transmit power to get a noise margin that is below this limit (if this functionality is supported). The maximum noise margin ranges from 0 (0) to 31 (310) dB with 0.1 dB steps. A special value of 0xFFFF is used to indicate that no Maximum Noise Margin limit is to be applied. (R, W, Set-by-create) (mandatory) (2 bytes)

**Downstream Minimum Noise Margin:** This is the minimum Noise Margin the ATU-R receiver shall tolerate. If the noise margin falls below this level, the ATU-R shall request the ATU-C to increase the ATU-C transmit power. If an increase to ATU-C transmit power is not possible, a loss-of-margin (LOM) defect occurs, the ATU-R shall fail and attempt to re-initialize and the NMS shall be notified. The minimum noise margin ranges from 0 (0) to 31 (310) dB with 0.1 dB steps. (R, W, Set-by-create) (mandatory) (2 bytes)

**Upstream Minimum Noise Margin:** This is the minimum Noise Margin the ATU-C receiver shall tolerate. If the noise margin falls below this level, the ATU-C shall request the ATU-R to increase the ATU-R transmit power. If an increase of ATU-R transmit power is not possible, a loss-of-margin (LOM) defect occurs, the ATU-C shall fail and attempt to re-initialize and the NMS shall be notified. The minimum noise margin ranges from 0 (0) to 31 (310) dB with 0.1 dB steps. (R, W, Set-by-create) (mandatory) (2 bytes)

**Downstream Rate Adaptation Mode:** This parameter specifies the mode of operation of a rate-adaptive ATU-C in the transmit direction. The parameter can take three values.

1 = **Mode 1:** MANUAL – Rate changed manually.

*At startup*

The Downstream Minimum Data Rate parameter specifies the data rate the ATU-C transmitter shall operate at for each of the bearer channels, with a downstream noise margin which is at least as large as the specified Downstream Target Noise Margin, relative to the required BER for each of the downstream bearer channels, or better. If the ATU-C fails to achieve the Downstream Minimum Data Rate for one of the bearer channels, the ATU-C will fail to initialize, and the NMS will be notified. Although the ATU-C and the line might be able to support a higher data rate, the ATU-C shall not transmit a higher data rate than what is requested for each of the bearer channels.

*At showtime*

The ATU-C transmitter shall maintain the specified Downstream Minimum Data Rate for each of the bearer channels.

- 2 = **Mode 2:** AT\_INIT-Rate automatically selected at startup only and does not change after that.

*At startup*

The Downstream Minimum Rate parameter specifies the minimum data rate the ATU-C transmitter shall operate at for each of the bearer channels, with a downstream noise margin which is at least as large as the specified Downstream Target Noise Margin, relative to the required BER for each of the bearer channels, or better. If the ATU-C fails to achieve the Downstream Minimum Data Rate for one of the bearer channels, the ATU-C will fail to initialize, and the NMS will be notified. If the ATU-C transmitter is able to support a higher downstream data rate at initialization, the excess data rate will be distributed amongst the downstream bearer channels according to the ratio (0 to 100%) specified by the Rate Adaptation Ratio parameter for each bearer channel (adding up to 100% over all bearer channels). When the Downstream Maximum Data Rate is achieved in one of the bearer channels, then the remaining excess bit rate is assigned to the other bearer channels, still according to their relative Rate Adaptation Ratio parameters. As long as the downstream data rate is below the Downstream maximum Data Rate for one of the bearer channels, data rate increase shall take priority over transmit power reduction.

*At showtime*

During showtime, no downstream data rate adaptation is allowed. The downstream data rate, which has been settled during initialization for each of the bearer channels, shall be maintained.

- 3 = **Mode 3:** DYNAMIC – Data rate is automatically selected at initialization and is continuously adapted during operation (showtime). The DYNAMIC Rate Adaptation mode is optional. All related configuration parameters are also optional.

*At startup*

In Mode 3, the ATU-C shall start up as in Mode 2.

*At showtime*

During showtime, rate adaptation is allowed with respect to the Ratio Adaptation Ratio for distributing the excess data rate amongst the bearer channels (see Mode 2), and assuring that the Downstream Minimum Data Rate remains available at the required BER for each of the bearer channels, or better. The downstream data rate can vary between the Downstream Minimum Data Rate and the Downstream Maximum Data Rate. Downstream Rate Adaptation is performed when the conditions specified for Downstream Upshift Noise Margin and Downstream Upshift Interval – or for Downstream Downshift Noise Margin and Downstream Downshift Interval – are satisfied. This means:

- For an Upshift action: Allowed when the downstream noise margin is above the Downstream Upshift Noise Margin during Downstream Minimum Time Interval for Upshift Rate Adaptation (i.e., upon RAU anomaly).
- For a Downshift action: Allowed when the downstream noise margin is below the Downstream Downshift Noise Margin during Downstream Minimum Time Interval for Downshift Rate Adaptation (i.e., upon RAD anomaly).

As long as the downstream data rate is below the Downstream Maximum Data Rate for one of the bearer channels, data rate increase shall take priority over transmit power reduction. (R, W, Set-by-create) (mandatory) (1 byte)

**Upstream Rate Adaptation Mode:** This parameter specifies the mode of operation of a rate-adaptive ATU-R in the transmit direction. The parameter is used only if the rate-adaptive functionality is supported and can take three values:

- 1 = MANUAL
- 2 = AT\_INIT
- 3 = DYNAMIC

The definition of each of the values is identical to their definition in the Downstream Rate Adaptation Mode (with replacing of ATU-C with ATU-R and downstream with upstream). (R, W, Set-by-create) (mandatory) (1 byte)

**Downstream Up-shift Noise Margin:** If the downstream noise margin is above the Downstream Upshift Noise Margin and stays above that for more than the time specified by the Downstream Minimum Upshift Rate Adaptation Interval, the ATU-R shall attempt to increase the downstream net data rate. The Downstream Up-shift Noise Margin ranges from 0 (0) to 31 (310) dB with 0.1 dB steps. (R, W, Set-by-create) (optional) (2 bytes)

**Upstream Up-shift Noise Margin:** If the upstream noise margin is above the Upstream Up-shift Noise Margin and stays above that for more than the time specified by the Upstream Minimum Upshift Rate Adaptation Interval, the ATU-C shall attempt to increase the upstream net data rate. The Upstream Up-shift Noise Margin ranges from 0 (0) to 31 (310) dB with 0.1 dB steps. (R, W, Set-by-create) (optional) (2 bytes)

**Upstream PSD Mask Selection:** This configuration parameter defines which upstream PSD mask is enabled. This parameter is used only for Annexes J and M of ITU-T Recs G.992.3 and G.992.5. As only one selection parameter is defined in the MIB, the same selection value applies to all relevant modes enabled in the ATSE line configuration parameter. It ranges from 1 to 9 and selects the mask with the following definition.

Selected mask		
Upstream PSD mask selection value	Annex J of ITU-T Rec. G.992.3/5	Annex M of ITU-T Rec. G.992.3/5
1	ADLU-32	EU-32
2	ADLU-36	EU-36
3	ADLU-40	EU-40
4	ADLU-44	EU-44
5	ADLU-48	EU-48
6	ADLU-52	EU-52
7	ADLU-56	EU-56
8	ADLU-60	EU-60
9	ADLU-64	EU-64

(R, W, Set-by-create) (mandatory) (1 byte)

**Minimum Overhead Rate Upstream:** This attribute defines the minimum rate of the message-based overhead that shall be maintained by the ATU in upstream direction. MSGMINus is expressed in bits per second and ranges from 4000 to 64000 bit/s. This attribute is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. (R, W, Set-by-create) (optional) (2 bytes)

**Minimum Overhead Rate Downstream:** This attribute defines the minimum rate of the message based overhead that shall be maintained by the ATU in downstream direction. MSGMINds is expressed in bits per second and ranges from 4000 to 64000 bit/s. This attribute is

only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. (R, W, Set-by-create) (optional) (2 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### **7.3.70 ADSL line configuration profile part 2**

This managed entity contains part 2 of the Line Configuration Profile for an ADSL line. An instance of this managed entity is created/deleted on request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall exist and may be associated with zero or more instances of the Physical Path Termination Point ADSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**Downstream Minimum Time Interval for Up-shift Rate Adaptation:** This parameter defines the interval of time the downstream noise margin should stay above the Downstream Up-shift Noise Margin before the ATU-R shall attempt to increase the downstream net data rate. The time interval ranges from 0 to 16 383 s. (R, W, Set-by-create) (optional) (2 bytes)

**Upstream Minimum Time Interval for Up-shift Rate Adaptation:** This parameter defines the interval of time the upstream noise margin should stay above the Upstream Up-shift Noise Margin before the ATU-C shall attempt to increase the upstream net data rate. The time interval ranges from 0 to 16 383 s. (R, W, Set-by-create) (optional) (2 bytes)

**Downstream Down-shift Noise Margin:** If the downstream noise margin is below the Downstream Down-shift Noise Margin and stays below that for more than the time specified by the Downstream Minimum Downshift Rate Adaptation Interval, the ATU-R shall attempt to decrease the downstream net data rate. The Downstream Down-shift Noise Margin ranges from 0 (0) to 31 (310) dB with 0.1 dB steps. (R, W, Set-by-create) (optional) (2 bytes)

**Upstream Down-shift Noise Margin:** If the upstream noise margin is below the Upstream Down-shift Noise Margin and stays below that for more than the time specified by the Upstream Minimum Downshift Rate Adaptation Interval, the ATU-C shall attempt to decrease the upstream net data rate. The Upstream Down-shift Noise Margin ranges from 0 (0) to 31 (310) dB with 0.1 dB steps. (R, W, Set-by-create) (optional) (2 bytes)

**Downstream Minimum Time Interval for Downshift Rate Adaptation:** This parameter defines the interval of time the downstream noise margin should stay below the Downstream Down-shift Noise Margin before the ATU-R shall attempt to decrease the downstream net data rate. The time interval ranges from 0 to 16 383 s. (R, W, Set-by-create) (optional) (2 bytes)

**Upstream Minimum Time Interval for Downshift Rate Adaptation:** This parameter defines the interval of time the upstream noise margin should stay below the Upstream Downshift Noise

Margin before the ATU-C shall attempt to decrease the upstream net data rate. The time interval ranges from 0 to 16 383 s. (R, W, Set-by-create) (optional) (2 bytes)

**ATU Impedance State forced:** This configuration parameter defines the impedance state to be forced on the near-end ATU. It applies only to the T/S-interface. It is only valid for Annex A/G.992.3, Annex A/G.992.4 and Annex A/G.992.5. It is coded as an integer value with following definition:

- 1 Force the near-end ATU to the disabled state.
- 2 Force the near-end ATU to the inactive state.
- 3 Force the near-end ATU to the active state.

(R, W, Set-by-create) (mandatory) (1 byte)

**L0-TIME:** This parameter represents the minimum time (in seconds) between an Exit from the L2 state and the next Entry into the L2 state. It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. It ranges from 0 to 255 s. (R, W, Set-by-create) (mandatory) (1 byte)

**L2-TIME:** This parameter represents the minimum time (in seconds) between an Entry into the L2 state and the first Power Trim in the L2 state and between two consecutive Power Trims in the L2 State. It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. It ranges from 0 to 255 s. (R, W, Set-by-create) (mandatory) (1 byte)

**Downstream Maximum Nominal Power Spectral Density:** This parameter represents the maximum nominal transmit PSD in the downstream direction during initialization and showtime (in dBm/Hz). A single MAXNOMPSDs parameter is defined per mode enabled in the ATSE line configuration parameter. It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. It ranges from –60 (0) to –30 (900) dBm/Hz, with 0.1 dB steps. (R, W, Set-by-create) (mandatory) (2 bytes)

**Upstream Maximum Nominal Power Spectral Density:** This parameter represents the maximum nominal transmit PSD in the upstream direction during initialization and showtime (in dBm/Hz). A single MAXNOMPSDus parameter is defined per mode enabled in the ATSE line configuration parameter. It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. It ranges from –60 (0) to –30 (900) dBm/Hz, with 0.1 dB steps. (R, W, Set-by-create) (mandatory) (2 bytes)

**Downstream Maximum Nominal Aggregate Transmit Power:** This parameter represents the maximum nominal aggregate transmit power in the downstream direction during initialization and showtime (in dBm). It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. It ranges from 0 (0) to 25.5 (255) dBm, with 0.1 dB steps. (R, W, Set-by-create) (mandatory) (1 byte)

**Upstream Maximum Nominal Aggregate Transmit Power:** This parameter represents the maximum nominal aggregate transmit power in the upstream direction during initialization and showtime (in dBm). It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. It ranges from 0 (0) to 25.5 (255) dBm, with 0.1 dB steps. (R, W, Set-by-create) (mandatory) (1 byte)

**Upstream Maximum Aggregate Receive Power:** This parameter represents the maximum upstream aggregate receive power over a set of subcarriers (in dBm) as specified in the relevant Recommendation. The ATU-C shall request an upstream power cutback such that the upstream aggregate receive power over that set of subcarriers is at or below the configured maximum value. It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. It ranges from –25.5 (0) to 25.5 (510) dBm, with 0.1 dB steps. A special value of 0xFFFF is used to indicate that no Upstream Maximum Aggregate Receive Power limit is to be applied. (R, W Set-by-create) (mandatory) (2 bytes)

## *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

## *Notifications*

None.

### **7.3.71 ADSL line configuration profile part 3**

This managed entity contains part 3 of the Line Configuration Profile for an ADSL line. An instance of this managed entity is created/deleted on request of the OLT.

## *Relationships*

Zero or more instances of this managed entity shall exist and may be associated with zero or more instances of the Physical Path Termination Point ADSL UNI.

## *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**Loop Diagnostics Mode Forced:** This configuration parameter defines whether the line should be forced into the loop diagnostics mode by the near-end ATU on this line. It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. It is coded as an integer value with following definition:

- 0 Inhibits the near-end ATU from performing loop diagnostics mode procedures on the line. Loop diagnostic mode procedures may still be initiated by the far-end ATU.
- 1 Forces the near-end ATU to perform the loop diagnostics procedures.

The line needs to be forced to the L3 state before it can be forced to the loop diagnostics mode. Only while the line power management state is the L3 state, the line can be forced into the loop diagnostics mode procedures. When the loop diagnostics mode procedures are completed successfully, the Access Node shall reset the LDSF MIB element to 0 and the line shall return to remain in the L3 idle state. The loop diagnostics data shall be available at least until the line is forced to the L0 state. If the loop diagnostics procedures cannot be completed successfully, (after a vendor-discretionary number of retries and/or within a vendor-discretionary timeout), then an Initialization Failure occurs. As long as loop diagnostics procedures are not completed successfully, attempts shall be made to do so, until the loop diagnostics mode is no longer forced on the line through this configuration parameter. (R, W, Set-by-create) (mandatory) (1 byte)

**Automode Cold Start Forced:** This parameter is defined in order to improve testing of the performance of ATUs supporting automode when it is enabled in the MIB. The valid values are 0 and 1. A change in value of this parameter indicates a change in loop conditions applied to the devices under test. The ATUs shall reset any historical information used for automode and for shortening G.994.1 handshake and initialization.

Automode is defined as the case where multiple operation-modes are enabled in the MIB in the G.997.1 "ATU Transmission System Enabling (ATSE)" table and where the selection of the operation-mode to be used for transmission does not only depend on the common capabilities of both ATUs (as exchanged in ITU-T Rec. G.994.1), but depends also on achievable data rates under given loop conditions. (R, W, Set-by-create) (mandatory) (1 byte)



**L2-ATPR:** This parameter represents the maximum aggregate transmit power reduction (in dB) that can be performed in the L2 Request (i.e., at transition of L0 to L2 state) or through a single Power Trim in the L2 state. It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. It ranges from 0 (0) dB to 31 (31) dB (R, W, Set-by-create) (mandatory) (1 byte)

**L2-ATPRT:** This parameter represents the total maximum aggregate transmit power reduction (in dB) that can be performed in an L2 state. This is the sum of all reductions of L2 Request (i.e., at transition of L0 to L2 state) and Power Trims. It ranges from 0 (0) dB to 31 (31)dB. (R, W, Set-by-create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### **7.3.72 ADSL channel configuration profile**

This managed entity contains the Channel Configuration Profile for an ADSL line. An instance of this managed entity is created/deleted on request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall exist and may be associated with zero or more instances of the Physical Path Termination Point ADSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**Minimum Data Rate:** This parameter specifies the minimum net data rate for the bearer channel as desired by the operator of the system. The rate is coded in bit/s. (R, Set-by-create) (mandatory) (4 bytes)

**Maximum Data Rate:** This parameter specifies the maximum net data rate for the bearer channel as desired by the operator of the system. The data rate is coded in bit/s. (R, Set-by-create) (mandatory) (4 bytes)

**Rate Adaptation Ratio:** This parameter (expressed in %) specifies the ratio that should be taken into account for the bearer channel when performing rate adaptation in the direction of the bearer channel. The ratio is defined as a percentage in the 0 to 100 range. A ratio of 20% means that 20% of the available data rate (in excess of the Minimum Data Rate summed over all bearer channels) will be assigned to this bearer channel and 80% to the other bearer channels.

The sum of rate adaptation ratios over all bearers in one direction shall be equal to 100%. (R, Set-by-create) (optional) (1 byte)

**Maximum Interleaving Delay:** This parameter is the maximum one-way interleaving delay introduced by the PMS-TC between the alpha and the beta reference points, in the direction of the bearer channel. The one-way interleaving delay is defined in individual ADSL Recommendations as  $\lceil S \cdot D \rceil / 4$  ms, where "S" is the S-factor and "D" is the "Interleaving Depth" and  $\lceil x \rceil$  denotes rounding to the higher integer.

The ATUs shall choose the S and D values such that the actual one-way interleaving delay is less or equal than the configured Maximum Interleaving Delay. The delay is coded in ms, with the value 0 and 1 special values. The value 0 indicates no delay bound is being imposed. The value 1 indicates the Fast Latency Path shall be used in the G.992.1 operating mode and S and D shall be selected such that  $S \leq 1$  and  $D = 1$  in G.992.2, G.992.3 and G.992.4 operating modes. Value range: 2-255. (R, Set-by-create) (mandatory) (1 byte)

**Data Rate Threshold Up-shift:** This parameter is a threshold on the net data rate up-shift achieved over one or more bearer channel data rate adaptations. An up-shift rate change alarm (event) is triggered when the actual data rate exceeds the data rate at the last entry into showtime by more than the threshold. The data rate threshold is coded in bit/s. (R, Set-by-create) (mandatory) (4 bytes)

**Data Rate Threshold Down-shift:** This parameter is a threshold on the net data rate down-shift achieved over one or more bearer channel data rate adaptations. A down-shift rate change alarm (event) is triggered when the actual data rate is below the data rate at the last entry into showtime by more than the threshold. The data rate threshold is coded in bit/s. (R, Set-by-create) (mandatory) (4 bytes)

**Minimum Reserved Data Rate:** This parameter specifies the minimum reserved net data rate for the bearer channel as desired by the operator of the system. The rate is coded in bit/s. (R, Set-by-create) (mandatory) (4 bytes)

**Minimum Data Rate in low power state:** This parameter specifies the minimum net data rate for the bearer channel as desired by the operator of the system during the low power state (L1/L2). The power management low power states L1 and L2 are defined in ITU-T Recs G.992.2 and G.992.3 respectively. The data rate is coded in bit/s. (R, Set-by-create) (mandatory) (4 bytes)

**Minimum Impulse Noise Protection:** This parameter specifies the minimum impulse noise protection for the bearer channel. It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. The impulse noise protection is expressed in symbols and can take the following integer values:

- 1 = 0 symbol
- 2 = ½ symbol
- 3 = 1 symbol
- 4 = 2 symbol

(R, Set-by-create) (mandatory) (1 byte)

**Maximum Bit Error Ratio:** This parameter specifies the maximum bit error ratio for the bearer channel as desired by the operator of the system. It is only valid for ITU-T Recs G.992.3, G.992.4 and G.992.5. The bit error ratio can take the following integer values:

- 1 = 1E-3
- 2 = 1E-5
- 3 = 1E-7

(R, Set-by-create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

## *Notifications*

None.

### **7.3.73 ADSL subcarrier masking downstream profile**

This managed entity contains the Subcarrier Masking Downstream Profile for an ADSL line. An instance of this managed entity is created/deleted on request of the OLT.

## *Relationships*

Zero or more instances of this managed entity shall exist and may be associated with zero or more instances of the Physical Path Termination Point ADSL UNI.

## *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**Downstream Subcarrier Mask1:** This configuration parameter is a bitmap representing the downstream mask values for subcarriers 1 to 128. The MSB of the first byte corresponds to subcarrier 1, and the LSB of the last byte corresponds to subcarrier 128.

Each bit position defines whether the corresponding subcarrier is masked on this line in the downstream direction. It is coded as 1 if masked and 0 if not masked (default).

Subcarrier number 1 is the lowest, and subcarrier number NSCds is the highest subcarrier that can be transmitted in the downstream direction.

NOTE – For ITU-T Recs G.992.3 and G.992.4, the number of subcarrier downstream (NSCds) is defined in the corresponding Recommendations. For ITU-T Rec. G.992.1, NSCds = 256, for ITU-T Rec. G.992.2, NSCds = 128, and for ITU-T Rec. G.992.5, NSCds = 512.

(R, W, Set-by-create) (mandatory) (16 bytes)

**Downstream Subcarrier Mask2:** This configuration parameter is a bitmap representing the downstream mask values for subcarriers 129 to 256. The MSB of the first byte corresponds to subcarrier 129, and the LSB of the last byte corresponds to entry 256.

Each bit position defines whether the corresponding subcarrier is masked on this line in the downstream direction. It is coded as 1 if masked and 0 if not masked (default).

Subcarrier number 1 is the lowest, and subcarrier number NSCds is the highest subcarrier that can be transmitted in the downstream direction.

NOTE – For ITU-T Recs G.992.3 and G.992.4, the number of subcarrier downstream (NSCds) is defined in the corresponding Recommendations. For ITU-T Rec. G.992.1, NSCds = 256, for ITU-T Rec. G.992.2, NSCds = 128, and for ITU-T Rec. G.992.5, NSCds = 512.

(R, W) (mandatory for modems that support NSCds > 128) (16 bytes)

**Downstream Subcarrier Mask3:** This configuration parameter is a bitmap representing the downstream mask values for subcarriers 257 to 384. The MSB of the first byte corresponds to subcarrier 257, and the LSB of the last byte corresponds to entry subcarrier 384.

Each bit position defines whether the corresponding subcarrier is masked on this line in the downstream direction. It is coded as 1 if masked and 0 if not masked (default).

Subcarrier number 1 is the lowest, and subcarrier number NSCds is the highest subcarrier that can be transmitted in the downstream direction.

NOTE – For ITU-T Recs G.992.3 and G.992.4, the number of subcarrier downstream (NSCds) is defined in the corresponding Recommendations. For ITU-T Rec. G.992.1, NSCds = 256, for ITU-T Rec. G.992.2, NSCds = 128, and for ITU-T Rec. G.992.5, NSCds = 512.

(R, W) (mandatory for modems that support NSCs > 256) (16 bytes)

**Downstream Subcarrier Mask4:** This configuration parameter is a bitmap representing the downstream mask values for subcarriers 385 to 512. The MSB of the first byte corresponds to subcarrier 385, and the LSB of the last byte corresponds to entry subcarrier 512.

Each bit position defines whether the corresponding subcarrier is masked on this line in the downstream direction. It is coded as 1 if masked and 0 if not masked (default).

Subcarrier number 1 is the lowest, and subcarrier number NSCs is the highest subcarrier that can be transmitted in the downstream direction.

NOTE – For ITU-T Recs G.992.3 and G.992.4, the number of subcarrier downstream (NSCs) is defined in the corresponding Recommendations. For ITU-T Rec. G.992.1, NSCs = 256, for ITU-T Rec. G.992.2, NSCs = 128, and for ITU-T Rec. G.992.5, NSCs = 512.

(R, W) (mandatory for modems that support NSCs > 384) (16 bytes)

**TableValid:** This boolean attribute controls and reports the operational status of this downstream subcarrier mask attributes.

If this attribute is true (coded as 0x01), then the downstream subcarrier mask represented in this ME has been impressed on the DSL equipment.

If this attribute is false (coded as 0x00), then the downstream subcarrier mask represented in this ME has not been impressed on the DSL equipment. Default value is false.

The value of this attribute can be modified by the ONU and OLT, as follows:

If the OLT changes any of the four mask attributes or sets TableValid to false, then TableValid is set to false.

If the TableValid is false and OLT sets TableValid to true, then the ONU will impress the downstream subcarrier mask data to the DSL equipment.

(R, W) (mandatory) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes. Note that setting the mask attributes does not directly change the DSL equipment operating mode, because of the TableValid attribute.

#### *Notifications*

None.

### **7.3.74 ADSL subcarrier masking upstream profile**

This managed entity contains the Subcarrier Masking Upstream Profile for an ADSL line. An instance of this managed entity is created/deleted on request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall exist and may be associated with zero or more instances of the Physical Path Termination Point ADSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**Upstream Subcarrier Mask:** This configuration parameter is a bitmap representing the upstream mask values for subcarriers 1 to 64. The MSB of the first byte corresponds to subcarrier 1, and the LSB of the last byte corresponds to subcarrier 64.

Each bit position defines whether the corresponding subcarrier is masked on this line in the upstream direction. It is coded as 1 if masked and 0 if not masked (default).

Subcarrier number 1 is the lowest, and subcarrier number NSCus is the highest subcarrier that can be transmitted in the upstream direction.

NOTE – For ITU-T Recs G.992.3 and G.992.4, the number of subcarrier upstream (NSCus) is defined in the corresponding Recommendations. For Annex A/G.992.1 and ITU-T Rec. G.992.2, NSCus = 32, for Annex B/G.992.1, NSCus = 64, and for ITU-T Rec. G.992.5, NSCus = 64.

(R, W, Set-by-create) (mandatory) (8 bytes)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes. Note that in this case, setting this attribute will result in the mask information being impressed on the DSL equipment immediately.

#### *Notifications*

None.

### **7.3.75 ADSL downstream PSD mask profile**

This managed entity contains the Downstream PSD Mask Profile for an ADSL line. An instance of this managed entity is created/deleted on request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall exist and may be associated with zero or more instances of the Physical Path Termination Point ADSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**Downstream PSD Mask:** This configuration parameter is a table where each entry consists of an Entry Number (1 byte, first entry numbered 1) field, Subcarrier Index (2 bytes) field, and a MIB PSD Mask Level (1 byte) field. This table defines the downstream PSD mask applicable at the U-C2 reference point. This MIB PSD mask may impose PSD restrictions in addition to the Limit PSD mask defined in the relevant Recommendation (e.g., ITU-T Rec. G.992.5).

The downstream PSD mask in the CO-MIB shall be specified through a set of breakpoints. Each breakpoint shall consist of a subcarrier index  $i$  (using the same definition of 'i' as given in 7.3.73) and a MIB PSD mask level (expressed in dBm/Hz) at that subcarrier. The set of breakpoints can then be represented as [(i1, PSD-1), (i2, PSD-2), ... , (iN, PSD-N)]. The MIB PSD Mask Level field shall be coded as an unsigned integer representing the MIB PSD mask levels 0 (0) dBm/Hz to -95 (190) dBm/Hz, in steps of 0.5 dBm/Hz. The maximum number of breakpoints is 32.

This attribute is only valid for ITU-T Rec. G.992.5.

The requirements for a valid set of breakpoints are defined in the relevant Recommendations (e.g., ITU-T Rec. G.992.5). The entries will have default value of 0x00 for Subcarrier Index and 0x0 for MIB PSD Mask Level (i.e., no breakpoints). Table entries for this attribute are added or modified using the Set action. Setting an entry with a non-zero Subcarrier Index and MIB PSD Mask Level implies insertion into the table. Setting an entry's Subcarrier Index and MIB PSD Mask Level to 0 implies deletion from the table, if present.

(R, W) (mandatory) ( $N \times 4$  bytes where  $N$  is the number of breakpoints)

**TableValid:** This boolean attribute controls and reports the operational status of this Downstream PSD Mask attribute.

If this attribute is true (coded as 0x01), then the downstream PSD mask represented in this ME has been impressed on the DSL equipment.

If this attribute is false (coded as 0x00), then the downstream PSD mask represented in this ME has not been impressed on the DSL equipment. Default value is false.

The value of this attribute can be modified by the ONU and OLT, as follows:

If the OLT changes any of the PSD mask table entries or sets TableValid to false, then TableValid is set to false.

If the TableValid is false and OLT sets TableValid to true, then the ONU will impress the downstream PSD mask data to the DSL equipment.

(R, W) (mandatory) (1 byte)

#### *Actions*

**Get:** Get one or more attributes. Latch a snapshot (i.e., copy) of the current Downstream PSD Mask and use 4 bytes to respond with the size of data which should be obtained using the "Get next" command.

**Get next:** Get the latched attribute values of the managed entity within the current snapshot.

**Set:** Generally, this action is used to set one or more entire attribute values. When used on the Downstream PSD Mask attribute, the Set action either adds, modifies, or deletes table entries in Downstream PSD Mask. A maximum of 7 table entries can be added/modified/deleted by a single Set action.

#### *Notifications*

None.

### **7.3.76 ADSL downstream RFI bands profile**

This managed entity contains the Downstream RFI Bands Profile for an ADSL line. An instance of this managed entity is created/deleted on request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall exist and may be associated with zero or more instances of the Physical Path Termination Point ADSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**Downstream RFI Bands:** This configuration parameter is a table where each entry consists of an Entry Number (1 byte, first entry numbered 1) field, Subcarrier Index1 (2 bytes) field, and Subcarrier Index2 (2 bytes) field. The subcarrier indices are defined in 7.3.73. This table defines the subset of downstream RFI Bands breakpoints, as specified in Downstream PSD Mask ME, that shall be used to notch an RFI band. This subset consists of couples of consecutive subcarrier indices belonging to breakpoints [i1;i2], corresponding to the low level of the notch. The maximum number of RFI bands is 32. This attribute is only valid for ITU-T Rec. G.992.5.

The specific interpolation around these points is defined in the relevant Recommendations (e.g., ITU-T Rec. G.992.5). The CO-MIB shall define the RFI notches using breakpoints in the Downstream PSD Mask ME as specified in the relevant Recommendations (e.g., ITU-T Rec. G.992.5).

The entries will have default value of 0x00 for Subcarrier Index1 and Subcarrier Index2. Table entries for this attribute are added or modified using the Set action. Setting an entry with a non-zero Subcarrier Index1 and Subcarrier Index2 implies insertion into the table. Setting an entry's Subcarrier Index1 and Subcarrier Index2 to 0 implies deletion from the table, if present.

(R, W) (mandatory) ( $N \times 5$  bytes where N is the number of RFI bands)

**TableValid:** This boolean attribute controls and reports the operational status of this Downstream RFI Bands attribute.

If this attribute is true (coded as 0x01), then the downstream RFI bands represented in this ME has been impressed on the DSL equipment.

If this attribute is false (coded as 0x00), then the downstream RFI bands represented in this ME has not been impressed on the DSL equipment. Default value is false.

The value of this attribute can be modified by the ONU and OLT, as follows:

If the OLT changes any of the RFI bands table entries or sets TableValid to false, then TableValid is set to false.

If the TableValid is false and OLT sets TableValid to true, then the ONU will impress the downstream RFI bands data to the DSL equipment.

(R, W) (mandatory) (1 byte)

#### *Actions*

**Get:** Get one or more attributes. Latch a snapshot (i.e., copy) of the current Downstream RFI Bands and use 4 bytes to respond with the size of data which should be obtained using the "Get next" command.

**Get next:** Get the latched attribute values of the managed entity within the current snapshot.

**Set:** Generally, this action is used to set one or more entire attribute values. When used on the Downstream RFI Bands attribute, the Set action either adds, modifies, or deletes table entries in Downstream RFI Bands. A maximum of 6 table entries can be added/modified/deleted by a single Set action.

#### *Notifications*

None.

### **7.3.77 ADSL ATU-C performance monitoring history data**

This managed entity represents the last completed 15-minute interval collected performance monitoring of the ATU-C – ATU-R ADSL modem path as seen from the ATU-C.

Instances of this managed entity are created/deleted by the OLT after an instance of the corresponding Physical Path Termination Point ADSL UNI managed entity is created/deleted.

#### *Relationships*

One instance of this managed entity can exist for each instance of a Physical Path Termination Point ADSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the ID of the Physical Path Termination Point ADSL UNI with which this ATU-C Performance Monitoring History Data is associated. (R, W, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> ID:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Loss of Frame Seconds:** This attribute is the count of seconds in the previous 15-minute interval when there was Loss of Framing. (R) (mandatory) (2 bytes)

**Loss of Signal Seconds:** This attribute is the count of seconds in the previous 15-minute interval when there was Loss of Signal. (R) (mandatory) (2 bytes)

**Loss of Link Seconds:** This attribute is the count of seconds in the previous 15-minute interval when there was Loss of Link. (R) (mandatory) (2 bytes)

**Loss of Power Seconds:** This attribute is the count of seconds in the previous 15-minute interval when there was Loss of Power. (R) (mandatory) (2 bytes)

**Errored Seconds:** This attribute is the count of Errored Seconds in the previous 15-minute interval. (R) (mandatory) (2 bytes)

**Severely Errored Seconds:** This attribute is the count of Severely Errored Seconds in the previous 15-minute interval. (R) (mandatory) (2 bytes)

**Line Initializations:** This attribute is the count of Line Initializations in the previous 15-minute interval. (R) (mandatory) (2 bytes)

**Failed Line Initializations:** This attribute is a count of the total number of failed full initializations in the previous 15-minute interval. (R) (mandatory) (2 bytes)

**Short Initializations:** This attribute is a count of the total number of fast retrains or short initializations attempted on the line (successful and failed) in the previous 15-minute interval. (R) (optional) (2 bytes)

**Failed Short Initializations:** This attribute is a count of the total number of failed fast retrains or short initializations in the previous 15-minute interval. (R) (optional) (2 bytes)

**FEC Seconds:** This attribute is the count of seconds in the previous 15-minute interval when there was a Forward Error Correction anomaly. (R) (mandatory) (2 bytes)

**Unavailable Seconds:** This attribute is the count of seconds in the previous 15-minute interval the ATU-C was unavailable. (R) (mandatory) (2 bytes)

### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Get Current Data:** Get the current value of one or more attributes.

**Set:** Set one or more attributes.



## Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 22.

**Table 22/G.983.2 – Alarm list for ADSL performance monitoring history data  
(reproduced from Table 5/G.983.10)**

Number	Event	Description	Threshold data counter number (Note)
	<b>Threshold Crossing Alert</b>		
0	Loss of Frame Seconds	Loss of Frame Seconds threshold crossing	1
1	Loss of Signal Seconds	Loss of Signal Seconds threshold crossing	2
2	Loss of Link Seconds	Loss of Link Seconds threshold crossing	3
3	Loss of Power Seconds	Loss of Power seconds threshold crossing	4
4	Errored Seconds	Errored seconds threshold crossing	5
5	Severely Errored Seconds	Severely Errored seconds threshold crossing	6
6	Line Initializations	Line Initializations threshold crossing	7
7	Failed Line Initializations	Failed Line Initializations threshold crossing	8
8	Short Initializations	Short Initializations threshold crossing	9
9	Failed Short Initializations	Failed Short Initializations threshold crossing	10
10	FEC Seconds	FEC Seconds threshold crossing	11
11	Unavailable Seconds	Unavailable Seconds threshold crossing	12
12-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.78 ADSL ATU-R performance monitoring history data

This managed entity represents the last completed 15-minute interval collected performance monitoring of the ATU-C-ATU-R ADSL modem path as seen from the ATU-R.

Instances of this managed entity are created/deleted by the OLT after an instance of the corresponding Physical Path Termination Point ADSL UNI managed entity is created/deleted.

## Relationships

One instance of this managed entity can exist for each instance of a Physical Path Termination Point ADSL UNI.

## Attributes

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the ID of the Physical Path Termination Point ADSL UNI with which this ATU-R Performance Monitoring History Data is associated. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> ID:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Loss of Frame Seconds:** This attribute is the count of seconds in the previous 15-minute interval when there was Loss of Framing. (R) (mandatory) (2 bytes)

**Loss of Signal Seconds:** This attribute is the count of seconds in the previous 15-minute interval when there was Loss of Signal. (R) (mandatory) (2 bytes)

**Loss of Power Seconds:** This attribute is the count of seconds in the previous 15-minute interval when there was Loss of Power. (R) (mandatory) (2 bytes)

**Errored Seconds:** This attribute is the count of Errored Seconds in the previous 15-minute interval. (R) (mandatory) (2 bytes)

**Severely Errored Seconds:** This attribute is the count of Severely Errored Seconds in the previous 15-minute interval. (R) (mandatory) (2 bytes)

**FEC Seconds:** This attribute is the count of seconds in the previous 15-minute interval when there was a Forward Error Correction anomaly. (R) (mandatory) (2 bytes)

**Unavailable Seconds:** This attribute is the count of seconds in the previous 15-minute interval the ATU-R was unavailable. (R) (mandatory) (2 bytes)

## Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Get Current Data:** Get the current value of one or more attributes.

**Set:** Set one or more attributes.

## Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 23.

**Table 23/G.983.2 – Alarm list for ATU-R performance monitoring history data  
(Reproduced from Table 6/G.983.10)**

Number	Event	Description	Threshold Data Counter Number (Note)
	<b>Threshold Crossing Alert</b>		
0	Loss of Frame Seconds	Loss of Frame Seconds threshold crossing	1
1	Loss of Signal Seconds	Loss of Signal Seconds threshold crossing	2
2	Loss of Power Seconds	Loss of Power seconds threshold crossing	3
3	Errored Seconds	Errored seconds threshold crossing	4
4	Severely Errored Seconds	Severely Errored seconds threshold crossing	5
5	FEC Seconds	FEC Seconds threshold crossing	6
6	Unavailable Seconds	Unavailable Seconds threshold crossing	7
7-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.79 ADSL ATU-C channel performance monitoring history data

This managed entity represents the last completed 15-minute interval collected performance monitoring of the ATU-C – ATU-R ADSL channel as seen from the ATU-C.

Instances of this managed entity are created/deleted by the OLT after an instance of the corresponding Physical Path Termination Point ADSL UNI managed entity is created/deleted.

#### Relationships

One instance of this managed entity can exist for each instance of a Physical Path Termination Point ADSL UNI.

#### Attributes

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The two most significant bits of the first byte are the Bearer Channel ID. The six least significant bits of the first byte are the slot ID (defined in 7.1.3). The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a subscriber line card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> ID:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Corrected blocks:** This attribute is the count of all blocks received with errors that were corrected on this channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Uncorrected Blocks:** This attribute is the count of all blocks received with uncorrectable errors on this channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Transmitted Blocks:** This attribute is the count of all encoded blocks transmitted on this channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Received Blocks:** This attribute is the count of all encoded blocks received on this channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Code Violations:** This attribute is the count of CRC-8 anomalies in the bearer channel in the previous 15-minute interval. (R) (mandatory) (2 bytes)

**Forward Error Corrections:** This attribute is the count of FEC anomalies in the bearer channel in the previous 15-minute interval. (R) (mandatory) (2 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Get Current Data:** Get the current value of one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 24.

**Table 24/G.983.2 – Alarm list for ATU-C channel performance monitoring history data  
(reproduced from Table 7/G.983.10)**

Number	Event	Description	Threshold data counter number (Note)
	<b>Threshold Crossing Alert</b>		
0	Corrected Blocks	Corrected Blocks threshold crossing	1
1	Uncorrected Blocks	Uncorrected Blocks threshold crossing	2
2	Code Violations	Code Violation threshold crossing	3
3	Forward Error Corrections	FEC threshold crossing	4
4-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.80 ADSL ATU-R channel performance monitoring history data

This managed entity represents the last completed 15-minute interval collected performance monitoring of the ATU-C – ATU-R ADSL channel as seen from the ATU-R.

Instances of this managed entity are created/deleted by the OLT after an instance of the corresponding Physical Path Termination Point ADSL UNI managed entity is created/deleted.

#### *Relationships*

One instance of this managed entity can exist for each instance of a Physical Path Termination Point ADSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The two most significant bits of the first byte are the Bearer Channel ID. The six least significant bits of the first byte are the slot ID (defined in 7.1.3). The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a subscriber line card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> ID:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Corrected blocks:** This attribute is the count of all blocks received with errors that were corrected on this channel within the previous 15-minute interval. (R) ( mandatory) (4 bytes)

**Uncorrected Blocks:** This attribute is the count of all blocks received with uncorrectable errors on this channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Transmitted Blocks:** This attribute is the count of all encoded blocks transmitted on this channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Received Blocks:** This attribute is the count of all encoded blocks received on this channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Code Violations:** This attribute is the count of CRC-8 anomalies in the bearer channel in the previous 15-minute interval. (R) (mandatory) (2 bytes)

**Forward Error Corrections:** This attribute is the count of FEC anomalies in the bearer channel in the previous 15-minute interval. (R) (mandatory) (2 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Get Current Data:** Get the current value of one or more attributes.

**Set:** Set one or more attributes.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 25.

**Table 25/G.983.2 – Alarm list for ATU-R channel performance monitoring history data (reproduced from Table 8/G.983.10)**

Number	Event	Description	Threshold Data Counter Number (Note)
	<b>Threshold Crossing Alert</b>		
0	Corrected Blocks	Corrected Blocks threshold crossing	1
1	Uncorrected Blocks	Uncorrected Blocks threshold crossing	2
2	Code Violations	Code Violation threshold crossing	3
3	Forward Error Corrections	FEC threshold crossing	4
4-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

#### 7.3.81 TC adaptor performance monitoring history data ADSL

This managed entity represents the last completed 15-minute interval collected performance monitoring of the ATU-C-ATU-R ATM Data Path.

Instances of this managed entity are created/deleted by the OLT after an instance of the corresponding Physical Path Termination Point ADSL UNI managed entity is created/deleted.

## Relationships

One instance of this managed entity can exist for each instance of a Physical Path Termination Point ADSL UNI.

## Attributes

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the ID of the Physical Path Termination Point ADSL UNI with which this ATU-R Channel Performance Monitoring History Data is associated. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> ID:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Near-end HEC violation count:** The near-end HEC\_violation\_count performance parameter is a count of the number of occurrences of a near-end HEC anomaly in the ATM Data Path. (R) (mandatory) (2 bytes)

**Near-end delineated total cell count (CD-P):** The near-end delineated\_total\_cell\_count performance parameter is a count of the total number of cells passed through the cell delineation and HEC function process operating on the ATM Data Path while in the SYNC state. (R) (mandatory) (4 bytes)

**Near-end User total cell count:** The near-end User\_total\_cell\_count performance parameter is a count of the total number of cells in the ATM Data Path delivered at the V-C (for ATU-C) or T-R (for ATU-R) interface. (R) (mandatory) (4 bytes)

**Near-end Idle Cell Bit Error Count:** The near-end idle\_bit\_error\_count performance parameter is a count of the number of bit errors in the idle cell payload received in the ATM Data Path at the near-end. (R) (mandatory) (2 bytes)

**Far-end HEC violation count:** The far-end HEC\_violation\_count performance parameter is a count of the number of occurrences of a far-end HEC anomaly in the ATM Data Path. (R) (mandatory) (2 bytes)

**Far-end delineated total cell count:** The far-end delineated\_total\_cell\_count performance parameter is a count of the total number of cells passed through the cell delineation process and HEC function operating on the ATM Data Path while in the SYNC state. (R) (mandatory) (4 bytes)

**Far-end User total cell count:** The far-end User\_total\_cell\_count performance parameter is a count of the total number of cells in the ATM Data Path delivered at the V-C (for ATU-C) or T-R (for ATU-R) interface. (R) (mandatory) (4 bytes)

**Far-end Idle Cell Bit Error Count:** The far-end idle\_bit\_error\_count performance parameter is a count of the number of bit errors in the idle cell payload received in the ATM Data Path at the far-end. (R) (mandatory) (2 bytes)

## Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Get Current Data:** Get the current value of one or more attributes.

**Set:** Set one or more attributes.

## Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 26.

**Table 26/G.983.2 – Alarm list for TC adaptor performance monitoring history data ADSL (reproduced from Table 9/G.983.10)**

Number	Event	Description	Threshold data counter number (Note)
	<b>Threshold Crossing Alert</b>		
0	Near-end HEC violation	Near-end HEC violation count threshold crossing	1
1	Near-end Idle Cell Bit Error Count	Near-end Idle Cell Bit Error Count threshold crossing	2
2	Far-end HEC violation count	Far-end HEC violation count threshold crossing	3
3	Far-end Idle Cell Bit Error Count	Far-end Idle Cell Bit Error Count threshold crossing	4
4-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.82 Physical path termination point VDSL UNI

This managed entity represents the point at a VDSL connection in the ONU where physical paths terminate and physical path level functions (e.g., path overhead functions) are performed.

Instances of this managed entity shall be automatically created/deleted by the ONU upon the creation/deletion of a Subscriber Line Card of VDSL type.

If the Subscriber Line Card of VDSL type is a plug-in unit, the number of managed entities automatically created is the maximum number supportable by the Subscriber Line Card slot. This allows the creation of these managed entities before the unit is plugged-in.

#### Establishment of a "Physical Path Termination Point VDSL UNI"

The Physical Path Termination Point VDSL UNI is auto created when the Subscriber Line Card of type VDSL is created. On auto creation the three profile pointers within the Managed Entity are set to their default values of 0x00. However, the PPTP VDSL UNI must refer to three valid profiles before it can be operational.



## Relationships

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as VDSL type.

Extensions for VDSL using Single Carrier Modulation (SCM) and Multiple Carrier Modulation (MCM) are for further study.

## Attributes

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot ID (defined in 7.1.3). The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255): 0x01 is used for the leftmost/lowest port on a subscriber line card, 0x02 is used for the next right/upper port, and so forth. (R) (mandatory) (2 bytes)

**Loopback Configuration:** This attribute represents the loopback configuration of this physical interface. Value 0x00: no loopback; value 0x01: loopback2 ("Loopback2" refers to a loopback at the local VDSL modem). The OLT can execute a physical level loopback test after loopback is set. Upon autonomous instantiation, the value 0x00 is used. (R, W) (mandatory) (1 byte)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) the functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**Availability State:** This attribute indicates whether the hardware to support this UNI is available on the plugged in line card. Valid values are available(0), notAvailable(1), unknown(2). (R) (optional) (1 byte)

**VDSL Line Coding Type:** This data type is used as the syntax for the VDSL Line Code. Attributes with this syntax identify the line coding used. The three values are:

- other(1) – none of the following;
- mcm(2) – Multiple Carrier Modulation;
- scm(3) – Single Carrier Modulation.

(R) (mandatory) (1 byte)

**VDSL Line Type:** Defines the type of VDSL physical line entity that exists, by defining whether and how the line is channelized. If the line is channelized, the value will be other than noChannel(1). This object defines which channel type(s) are supported. Defined values are:

- noChannel(1) – no channels exist;
- fastOnly(2) – only fast channel exists;
- slowOnly(3) – only slow channel exists;
- fastOrSlow(4) – either fast or slow channel exist, but only one at a time;
- fastAndSlow(5) – both fast and slow channels exist.

(R) (mandatory) (1 byte)

**ARC:** This attribute is used to control alarm reporting from this managed entity. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ARCInterval:** This attribute provides a provisionable length of time. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**VDSL Line Configuration Profile ID:** This attribute provides a pointer to an instance of the VDSL Line Configuration Profile managed entity that contains the data necessary for initializing a VDSL MODEM. The value 0x00 is used to indicate that this ME does not point to a line configuration profile. The default value 0x00 is used when this ME is auto created. (R, W) (mandatory) (2 bytes)

**VDSL Channel Configuration Profile ID:** This attribute provides a pointer to an instance of the VDSL Channel Configuration Profile managed entity that contains the data necessary for channelizing a VDSL Connection. The value 0x00 is used to indicate that this ME does not point to a channel configuration profile. The default value 0x00 is used when this ME is auto created. (R, W) (mandatory) (2 bytes)

**VDSL Band Plan Configuration Profile ID:** This attribute provides a pointer to an instance of the VDSL Band Plan Configuration Profile managed entity that contains the data necessary to set up a VDSL Connection. The value 0x00 is used to indicate that this ME does not point to band plan configuration profile. The default value 0x00 is used when this ME is auto created. (R, W) (mandatory) (2 bytes)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify the attribute and its new value. The AVCs for this managed entity are given in Table 27.

**Table 27/G.983.2 – AVC list for physical path termination point VDSL UNI  
(reproduced from Table 10/G.983.10)**

Number	Attribute value change	Description
1-2	N/A	
3	OpState	Operational state
4-11	N/A	
12-16	Reserved	

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONU and OLT should know the alarm list used by this entity. The alarms for this entity are given in Table 28.

**Table 28/G.983.2 – Alarm list for physical path termination point VDSL UNI  
(reproduced from Table 11/G.983.10)**

Number	Alarm	Description
0	NE_LOF	Near End (VTU-O) Loss of Framing
1	NE_LOS	Near End (VTU-O) Loss of Signal
2	NE_LOP	Near End (VTU-O) Loss of Power
3	NE_LOSQ	Near End (VTU-O) Loss of Signal Quality
4	NE_LOL	Near End (VTU-O) Loss of Link
5	FE_LOF	Far End (VTU-R) Loss of Framing

**Table 28/G.983.2 – Alarm list for physical path termination point VDSL UNI  
(reproduced from Table 11/G.983.10)**

Number	Alarm	Description
6	FE_LOS	Far End (VTU-R) Loss of Signal
7	FE_LOP	Far End (VTU-R) Loss of Power
8	FE_LOSQ	Far End (VTU-R) Loss of Signal Quality
9-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.83 VDSL VTU-O physical data

This managed entity represents the physical status of the VDSL Termination Unit (ONU) (VTU-O) in a VDSL connection in the ONU.

An instance of this managed entity shall be automatically created/deleted by the ONU upon the creation/deletion of a Subscriber Line Card of VDSL type.

#### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as VDSL type.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot ID. The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255). (R) (mandatory) (2 bytes)

**Line Transmit Rate:** Indicates the current VTU-O line transmit rate in kbit/s. This value will be less than or equal to the current attainable rate.

NOTE – 1 kbit/s = 1000 bit/s.

(R) (mandatory) (4 bytes)

**Serial Number Part 1:** The vendor-specific string that identifies the vendor equipment. It consists of up to 32 ASCII characters. This attribute contains the first 16 characters. (R) (mandatory) (16 bytes)

**Serial Number Part 2:** The vendor-specific string that identifies the vendor equipment. It consists of up to 32 ASCII characters. This attribute contains the second 16 characters. (R) (mandatory) (16 bytes)

**Vendor ID:** The vendor ID code is a copy of the binary vendor identification field expressed as readable characters in hexadecimal notation. (R) (mandatory) (16 bytes)

**Version Number:** The vendor-specific version number sent by this VTU as part of the initialization messages. It is a copy of the binary version number field expressed as readable characters in hexadecimal notation. (R) (mandatory) (16 bytes)

**Current Status:** Indicates current state of the VTU-O. This is a bit-map of possible conditions. The various bit positions are:

- 0 – noDefect – There are no defects on the line.
- 1 – lossOfFraming – VTU-O failure due to not receiving a valid frame.
- 2 – lossOfSignal – VTU-O failure due to not receiving signal.

- 3 – lossOfPower – VTU-O failure due to loss of power.
- 4 – lossOfSignalQuality – Loss of Signal Quality is declared when the Noise Margin falls below the Minimum Noise Margin, or the bit-error-rate exceeds  $10^{-7}$ .
- 5 – lossOfLink – VTU-O failure due to inability to link with peer VTU. Set whenever the transceiver is in the 'Warm Start' state.
- 6 – dataInitFailure – VTU-O failure during initialization due to bit errors corrupting startup exchange data.
- 7 – configInitFailure – VTU-O failure during initialization due to peer VTU not able to support requested configuration.
- 8 – protocolInitFailure – VTU-O failure during initialization due to incompatible protocol used by the peer VTU.
- 9 – noPeerVtuPresent – VTU-O failure during initialization due to no activation sequence detected from peer VTU.

(R) (mandatory) (2 bytes)

**Current Output Power:** Measured total output power transmitted by this VTU in steps of 0.1 dBm. This is the measurement that was reported during the last activation sequence. The effective range is 0 (0) to +16 (160) dBm. (R) (mandatory) (1 byte)

**Current SNR Margin:** Noise Margin as seen by this VTU with respect to its received signal in steps of 0.25 dB. The effective range is –31.75 (–127) to +31.75 (127) dB. (R) (mandatory) (1 byte)

**Current Attenuation:** Measured difference in the total power transmitted by the peer VTU and the total power received by this VTU. The effective range is 0 (0) to +63.75 (255) dB. (R) (mandatory) (1 byte)

**Current Attainable Rate:** Indicates the maximum currently attainable line transmit rate by the VTU-O in kbit/s. This value will be equal to or greater than the current line rate.

NOTE – 1 kbit/s = 1000 bit/s.

(R) (mandatory) (4 bytes)

**Current Loop Length Estimate:** Estimated loop length in feet assuming a 26 AWG (0.4 mm) loop. (R) (mandatory) (2 bytes)

#### *Actions*

**Get:** Get one or more attributes.

#### *Notifications*

None.

### **7.3.84 VDSL VTU-R physical data**

This managed entity represents the physical status of the VDSL Termination Unit (Remote) (VTU-R) in a VDSL connection in the ONU.

An instance of this managed entity shall be automatically created/deleted by the ONU upon the creation/deletion of a Subscriber Line Card of VDSL type.

#### *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as VDSL type.

## Attributes

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot ID. The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255). (R) (mandatory) (2 bytes)

**Line Transmit Rate:** Indicates the current VTU-R line transmit rate in kbit/s. This value will be less than or equal to the current attainable rate.

NOTE – 1 kbit/s = 1000 bit/s.

(R) (mandatory) (4 bytes)

**Serial Number Part 1:** The vendor-specific string that identifies the vendor equipment. This attribute contains the first 16 characters. (R) (mandatory) (16 bytes)

**Serial Number Part 2:** The vendor-specific string that identifies the vendor equipment. It consists of up to 32 ASCII characters. This attribute contains the second 16 characters. (R) (mandatory) (16 bytes)

**Vendor ID:** The vendor ID code is a copy of the binary vendor identification field expressed as readable characters in hexadecimal notation. (R) (mandatory) (16 bytes)

**Version Number:** The vendor-specific version number sent by this VTU as part of the initialization messages. It is a copy of the binary version number field expressed as readable characters in hexadecimal notation. (R) (mandatory) (16 bytes)

**Current Status:** Indicates current state of the VTU line. This is a bit-map of possible conditions. The various bit positions are:

0 – noDefect – There are no defects on the line.

1 – lossOfFraming – VTU failure due to not receiving a valid frame.

2 – lossOfSignal – VTU failure due to not receiving signal.

3 – lossOfPower – VTU failure due to loss of power.

4 – lossOfSignalQuality – Loss of Signal Quality is declared when the Noise Margin falls below the Minimum Noise Margin, or the bit-error-rate exceeds  $10^{-7}$ .

(R) (mandatory) (1 byte)

**Current Output Power:** Measured total output power transmitted by this VTU in steps of 0.1 dBm. This is the measurement that was reported during the last activation sequence. The effective range is 0 (0) to +16 (160) dBm. (R) (mandatory) (1 byte)

**Current SNR Margin:** Noise Margin as seen by this VTU with respect to its received signal in 0.25 dB. The effective range is –31.75 (–127) to +31.75 (127) dB. (R) (mandatory) (1 byte)

**Current Attenuation:** Measured difference in the total power transmitted by the peer VTU and the total power received by this VTU. The effective range is 0 (0) to +63.75 (255) dB. (R) (mandatory) (1 byte)

**Current Attainable Rate:** Indicates the maximum currently attainable line transmit rate by the VTU-R in kbit/s. This value will be equal to or greater than the current line rate.

NOTE – 1 kbit/s = 1000 bit/s.

(R) (mandatory) (4 bytes)

## Actions

**Get:** Get one or more attributes.

## *Notifications*

None.

### **7.3.85 VDSL channel data**

This managed entity represents the physical status of the VDSL Fast and slow channels in a VDSL connection in the ONU.

An instance of this managed entity shall be automatically created/deleted by the ONU upon the creation/deletion of a Subscriber Line Card of VDSL type.

## *Relationships*

One or more instances of this managed entity shall be contained in an instance of a Subscriber Line Card managed entity classified as VDSL type.

## *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot ID. The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255). (R) (mandatory) (2 bytes)

**Current Interleave Delay Down:** Downstream Interleave Delay for this channel in milliseconds. Interleave delay defines the mapping (relative spacing) between subsequent input bytes at the interleaver input and their placement in the bit stream at the interleaver output. Larger numbers provide greater separation between consecutive input bytes in the output bit stream allowing for improved impulse noise immunity at the expense of payload latency. (R) (mandatory) (1 byte)

**Current Fast Payload Rate Down:** Actual fast channel downstream data rate, in kbit/s.

NOTE – 1 kbit/s = 1000 bit/s.

(R) (mandatory) (4 bytes)

**Current Slow Payload Rate Down:** Actual slow downstream data rate, in kbit/s.

NOTE – 1 kbit/s = 1000 bit/s.

(R) (mandatory) (4 bytes)

**Current Fast CRC Block Length Down:** Indicates the length of the downstream fast channel data-block, in bytes, on which the CRC operates. (R) (mandatory) (2 bytes)

**Current Slow CRC Block Length Down:** Indicates the length of the downstream slow channel data-block, in bytes, on which the CRC operates. (R) (mandatory) (2 bytes)

**Current Slow Burst Protect Down:** Actual level of downstream impulse noise (burst) protection, in microseconds, for the slow channel. (R) (mandatory) (2 bytes)

**Current Fast FEC Down:** Actual downstream Forward Error Correction (FEC) redundancy, in percent, related overhead for the fast channel. (R) (mandatory) (1 byte)

**Current Interleave Delay Up:** Downstream Interleave Delay for this channel in milliseconds. Interleave delay applies only to the interleave (slow) channel and defines the mapping (relative spacing) between subsequent input bytes at the interleaver input and their placement in the bit stream at the interleaver output. Larger numbers provide greater separation between consecutive input bytes in the output bit stream allowing for improved impulse noise immunity at the expense of payload latency.

In the case where the interface type is fast, return a value of zero. (R) (mandatory) (1 byte)

**Current Fast Payload Rate Up:** Actual fast channel upstream data rate, in kbit/s.

NOTE – 1 kbit/s = 1000 bit/s.

(R) (mandatory) (4 bytes)

**Current Slow Payload Rate Up:** Actual slow upstream data rate, in kbit/s.

NOTE – 1 kbit/s = 1000 bit/s.

(R) (mandatory) (4 bytes)

**Current Fast CRC Block Length Up:** Indicates the length of the upstream fast channel data-block, in bytes, on which the CRC operates. (R) (mandatory) (2 bytes)

**Current Slow CRC Block Length Up:** Indicates the length of the upstream slow channel data-block, in bytes, on which the CRC operates. (R) (mandatory) (2 bytes)

**Current Slow Burst Protect Up:** Actual level of upstream impulse noise (burst) protection, in microseconds, for the slow channel. (R) (mandatory) (2 bytes)

**Current Fast FEC Up:** Actual upstream Forward Error Correction (FEC) redundancy, in percent, related overhead for the fast channel. (R) (mandatory) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

#### *Notifications*

None.

### **7.3.86 VDSL line configuration profile**

An instance of this managed entity represents a VDSL Line Configuration Profile supported on the ONU. Zero or more VDSL Physical Path Termination Points can reference an instance of a VDSL Line Configuration Profile managed entity.

Instances of this managed entity are created and deleted by the ONU on request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall be contained in an ONU. One or more instances of this managed entity shall be contained in an ONU containing instances of Physical Path Termination Point VDSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, W, Set-by-create) (mandatory) (2 bytes)

**Down Rate Mode:** Specifies the rate selection behaviour for the line in the downstream direction. manual(1) forces the rate to the configured rate, adaptAtInit(2) adapts the line based upon line quality. (R, W, Set-by-Create) (mandatory) (1 byte)

**Up Rate Mode:** Specifies the rate selection behaviour for the line in the upstream direction. manual(1) forces the rate to the configured rate, adaptAtInit(2) adapts the line based upon line quality. (R, W, Set-by-Create) (mandatory) (1 byte)

**Down Max Power:** Specifies the maximum aggregate downstream power level in the range 0 (0) to 14.5 dBm (58) in 0.25 dBm intervals. (R, W, Set-by-Create) (mandatory) (1 byte)

**Up Max Power:** Specifies the maximum aggregate upstream power level in the range 0 (0) to 14.5 dBm (58) in 0.25 dBm intervals. (R, W, Set-by-Create) (mandatory) (1 byte)

**Down Max SNR Margin:** Specifies the maximum downstream Signal/Noise Ratio Margin in units of 0.25 dB, for a range of 0 (0) to 31.75 dB (127). (R, W, Set-by-Create) (mandatory) (1 byte)

**Down Min SNR Margin:** Specifies the minimum downstream Signal/Noise Ratio Margin in units of 0.25 dB, for a range of 0 (0) to 31.75 dB (127). (R, W, Set-by-Create) (mandatory) (1 byte)

**Down Target SNR Margin:** Specifies the target downstream Signal/Noise Ratio Margin in units of 0.25 dB, for a range of 0 (0) to 31.75 dB (127). This is the Noise Margin the transceivers must achieve with a BER of  $10^{-7}$  or better to successfully complete initialization. (R, W, Set-by-Create) (mandatory) (1 byte)

**Up Max SNR Margin:** Specifies the maximum upstream Signal/Noise Ratio Margin in units of 0.25 dB, for a range of 0 (0) to 31.75 dB (127). (R, W, Set-by-Create) (mandatory) (1 byte)

**Up Min SNR Margin:** Specifies the minimum upstream Signal/Noise Ratio Margin in units of 0.25 dB, for a range of 0 (0) to 31.75 dB (127). (R, W, Set-by-Create) (mandatory) (1 byte)

**Up Target SNR Margin:** Specifies the target upstream Signal/Noise Ratio Margin in units of 0.25 dB, for a range of 0 (0) to 31.75 dB (127). This is the Noise Margin the transceivers must achieve with a BER of  $10^{-7}$  or better to successfully complete initialization. (R, W, Set-by-Create) (mandatory) (1 byte)

**Down PBO Control:** Downstream power backoff (PBO) control for this line. For transceivers which do not support downstream PBO control, this object MUST be fixed at disabled(1). If auto(2) is selected, the transceiver will automatically adjust the power backoff. If manual(3) is selected, then the transceiver will use the Down PBO Level. (R, W, Set-by-Create) (mandatory) (1 byte)

**Up PBO Control:** Upstream power backoff (PBO) control for this line. For transceivers which do not support upstream PBO control, this object MUST be fixed at disabled(1). If auto(2) is selected, the transceiver will automatically adjust the power backoff. If manual(3) is selected, then the transceiver will use the Up PBO Level. (R, W, Set-by-Create) (mandatory) (1 byte)

**Down PBO Level:** Specifies the downstream backoff level to be used when Down PBO Control = manual(3). Valid range is 0 dB (0) to 40 dB (160) in 0.25 dB intervals. (R, W, Set-by-Create) (mandatory) (1 byte)

**Up PBO Level:** Specifies the upstream backoff level to be used when Up PBO Control = manual(3). Valid range is 0 dB (0) to 40 dB (160) in 0.25 dB intervals. (R, W, Set-by-Create) (mandatory) (1 byte)

**Line Type:** This parameter provisions the VDSL physical entity at start-up by defining whether and how the line will be channelized, i.e., which channel type(s) are supported. If the line is to be channelized, the value will be other than noChannel(1).

Defined values are:

noChannel(1) – no channels exist;

fastOnly(2) – only the fast channel exists;

slowOnly(3) – only the slow channel exists

fastOrSlow(4) – either the fast or the slow channel exists, but only one at a time;

fastAndSlow(5) – both fast and slow channels exist.

(R, W, Set-by-Create) (mandatory) (1 byte)



## Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

## Notifications

None.

### 7.3.87 VDSL channel configuration profile

An instance of this managed entity represents a VDSL Channel Configuration Profile supported on the ONU. Zero or more VDSL Physical Path Termination Points can reference an instance of a VDSL Channel Configuration Profile managed entity.

Instances of this managed entity are created and deleted by the ONU on request of the OLT.

## Relationships

Zero or more instances of this managed entity shall be contained in an ONU. One or more instances of this managed entity shall be contained in an ONU containing instances of Physical Path Termination Point VDSL UNI.

## Attributes

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**Down Rate Ratio:** This attribute is the configured allocation ratio of excess downstream transmit bandwidth between fast and slow channels. Only applies when two channel mode and adaptAtInit are supported. Distribute bandwidth on each channel in excess of the corresponding Minimum Transmit Bit Rate so that:

$$\text{Rate Change Ratio} = [\text{Fast}/(\text{Fast} + \text{Slow})] \times 100$$

In other words, this value is the fast channel percentage. Valid range is 0 to 100. (R, W, Set-by-Create) (optional) (1 byte)

**Up Rate Ratio:** This attribute is the configured allocation ratio of excess upstream transmit bandwidth between fast and slow channels. Only applies when two channel mode and adaptAtInit are supported. Distribute bandwidth on each channel in excess of the corresponding Minimum Transmit Bit Rate so that:

$$\text{Rate Change Ratio} = [\text{Fast}/(\text{Fast} + \text{Slow})] \times 100$$

In other words, this value is the fast channel percentage. Valid range is 0 to 100. (R, W, Set-by-Create) (optional) (1 byte)

**Down Slow Max Data Rate:** Specifies the maximum downstream slow channel data rate in steps of 64 kbit/s. The maximum aggregate downstream transmit speed of the line can be derived from the sum of maximum downstream fast and slow channel data rates. (R, W, Set-by-Create) (mandatory) (2 bytes)

**Down Slow Min Data Rate:** Specifies the minimum downstream slow channel data rate in steps of 64 kbit/s. The minimum aggregate downstream transmit speed of the line can be derived from the sum of minimum downstream fast and slow channel data rates. (R, W, Set-by-Create) (mandatory) (2 bytes)

**Up Slow Max Data Rate:** Specifies the maximum upstream slow channel data rate in steps of 64 kbit/s. The maximum aggregate upstream transmit speed of the line can be derived from the sum of maximum upstream fast and slow channel data rates. (R, W, Set-by-Create) (mandatory) (2 bytes)

**Up Slow Min Data Rate:** Specifies the minimum upstream slow channel data rate in steps of 64 kbit/s. The minimum aggregate upstream transmit speed of the line can be derived from the sum of minimum upstream fast and slow channel data rates. (R, W, Set-by-Create) (mandatory) (2 bytes)

**Down Max Interleave Delay:** Specifies the maximum interleave delay, in milliseconds, for the downstream slow channel. Valid range is 0 to 255 ms. (R, W, Set-by-Create) (mandatory) (1 byte)

**Up Max Interleave Delay:** Specifies the maximum interleave delay, in milliseconds, for the upstream slow channel. Valid range is 0 to 255 ms. (R, W, Set-by-Create) (mandatory) (1 byte)

**Down Target Slow Burst:** Specifies the target level of impulse noise (burst) protection, in microseconds, for the downstream slow channel. Valid range is 0 to 1275  $\mu$ s. (R, W, Set-by-Create) (mandatory) (2 bytes)

**Up Target Slow Burst:** Specifies the target level of impulse noise (burst) protection, in microseconds, for the upstream slow channel. Valid range is 0 to 1275  $\mu$ s. (R, W, Set-by-Create) (mandatory) (2 bytes)

**Down Fast Max Data Rate:** Specifies the maximum downstream fast channel data rate in steps of 64 kbit/s. (R, W, Set-by-Create) (mandatory) (2 bytes)

**Down Fast Min Data Rate:** Specifies the minimum downstream fast channel data rate in steps of 64 kbit/s. (R, W, Set-by-Create) (mandatory) (2 bytes)

**Up Fast Max Data Rate:** Specifies the maximum upstream fast channel data rate in steps of 64 kbit/s. (R, W, Set-by-Create) (mandatory) (2 bytes)

**Up Fast Min Data Rate:** Specifies the minimum upstream fast channel data rate in steps of 64 kbit/s. (R, W, Set-by-Create) (mandatory) (2 bytes)

**Down Max Fast FEC:** This parameter provisions the maximum level of Forward Error Correction (FEC) redundancy related overhead to be maintained, as a percentage, for the downstream fast channel. Valid range is 0 to 50 percent. (R, W, Set-by-Create) (optional) (1 byte)

**Up Max Fast FEC:** This parameter provisions the maximum level of Forward Error Correction (FEC) redundancy related overhead to be maintained, as a percentage, for the upstream fast channel. Valid range is 0 to 50 percent. (R, W, Set-by-Create) (optional) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### 7.3.88 VDSL band plan configuration profile

An instance of this managed entity represents a VDSL Band Plan Configuration Profile supported on the ONU. Zero or more VDSL Physical Path Termination Points can reference an instance of a VDSL Band Plan Configuration Profile managed entity.

Instances of this managed entity are created and deleted by the ONU on request of the OLT.

#### *Relationships*

Zero or more instances of this managed entity shall be contained in an ONU. One or more instances of this managed entity shall be contained in an ONU containing instances of Physical Path Termination Point VDSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. The value 0x00 is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**Band Plan:** The VDSL band plan to be used for the line. bandPlan997(1) is to be used for G.993.1 Bandplan-B, ETSI Bandplan, ANSI Plan 997. bandPlan998(2) is to be used for G.993.1 Bandplan-A, ANSI Plan 998. bandPlanFx(3) is to be used for G.993.1 Bandplan-C. other(4) is to be used for non-standard band plans. If this object is set to bandPlanFx(3), then Band Plan FX MUST also be set. (R, W, Set-by-Create) (mandatory) (1 byte)

**Band Plan FX:** The frequency limit, in kHz, between bands D2 and U2 when the Band Plan is set to bandPlanFx(3). Valid range is 3 750 to 12 000 kHz. (R, W, Set-by-Create) (optional) (2 bytes)

**Band Opt Usage:** Defines the VDSL link use of the optional frequency range [25 kHz-138 kHz] (Opt). unused(1) indicates Opt is unused, upstream(2) indicates Opt usage is for upstream, downstream(3) indicates Opt usage is for downstream. (R, W, Set-by-Create) (mandatory) (1 byte)

**Up PSD Template:** The upstream PSD template to be used for the line. Here, templateMask1(1) refers to a notched mask that limits the transmitted PSD within the internationally standardized HAM (amateur Radio) radio bands, while templateMask2(2) refers to an unnotched mask. The masks themselves depend upon the applicable standard being used (Applicable Standard). (R, W, Set-by-Create) (mandatory) (1 byte)

**Down PSD Template:** The downstream PSD template to be used for the line. Here, templateMask1(1) refers to a notched mask that limits the transmitted PSD within the internationally standardized HAM (Handheld Amateur Radio) radio bands, while templateMask2(2) refers to an unnotched mask. The masks themselves depend upon the applicable standard being used (Applicable Standard). (R, W, Set-by-Create) (mandatory) (1 byte)

**HAM Band Mask:** The transmit power spectral density mask code, used to avoid interference with HAM (Handheld Amateur Radio) radio bands by introducing power control (notching) in one or more of these bands. Amateur radio band notching is defined in the VDSL spectrum as follows:

Band	Start frequency	Stop frequency
-----	-----	-----
30 m	1 810 kHz	2 000 kHz
40 m	3 500 kHz	3 800 kHz (ETSI); 4000 kHz (ANSI)
80 m	7 000 kHz	7 100 kHz (ETSI); 7300 kHz (ANSI)
160 m	10 100 kHz	10 150 kHz

Notching for each standard band can be enabled or disabled via this bit mask. Two custom notches may be specified. If customNotch1 is enabled, then both **Custom Notch 1 Start** and **Custom Notch 1 Stop** MUST be specified. If customNotch2 is enabled, then both **Custom Notch 2 Start** and **Custom Notch 2 Stop** MUST be specified. Valid bit values are defined as follows, all combinations are allowed:

customNotch1(0) – custom (region-specific) notch

customNotch2(1) – custom (region-specific) notch

amateurBand30m(2) – amateur radio band notch

amateurBand40m(3) – amateur radio band notch

amateurBand80m(4) – amateur radio band notch

amateurBand160m(5) – amateur radio band notch

(R, W, Set-by-Create) (mandatory) (1 byte)

**Custom Notch 1 Start:** Specifies the start frequency, in kHz, of custom HAM (Handheld Amateur Radio) notch 1. This field MUST be less than or equal to **Custom Notch 1 Stop**. Valid range is 0 to 65 535 kHz. (R, W, Set-by-Create) (optional) (2 bytes)

**Custom Notch 1 Stop:** Specifies the stop frequency, in kHz, of custom HAM (Handheld Amateur Radio) notch 1. This field MUST be greater than or equal to **Custom Notch 1 Start**. (R, W, Set-by-Create). Valid range is 0 to 65 535 kHz. (optional) (2 bytes)

**Custom Notch 2 Start:** Specifies the start frequency, in kHz, of custom HAM (Handheld Amateur Radio) notch 2. This field MUST be less than or equal to **Custom Notch 2 Stop**. Valid range is 0 to 65 535 kHz. (R, W, Set-by-Create) (optional) (2 bytes)

**Custom Notch 2 Stop:** Specifies the stop frequency, in kHz, of custom HAM (Handheld Amateur Radio) notch 2. This field MUST be greater than or equal to **Custom Notch 2 Start**. Valid range is 0 to 65 535 kHz. (R, W, Set-by-Create) (optional) (2 bytes)

**Deployment Scenario:** The VDSL line deployment scenario. When using fttCab(1), the VTU-C is located in a street cabinet. When using fttEx(2), the VTU-C is located at the central office. Changes to this value will have no effect on the transceiver. (R, W, Set-by-Create) (mandatory) (1 byte)

**ADSL Presence:** Indicates presence of ADSL service in the associated cable bundle/binder. none(1) indicates no ADSL service in the bundle, adslOverPots(2) indicates ADSL service over POTS is present in the bundle, adslOverISDN(3) indicates ADSL service over ISDN is present in the bundle. (R, W, Set-by-Create) (mandatory) (1 byte)

**Applicable Standard:** The VDSL standard to be used for the line. ansi(1) indicates ANSI standard, etsi(2) indicates ETSI standard, itu(3) indicates ITU standard, other(4) indicates a standard other than the above. (R, W, Set-by-Create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### 7.3.89 VDSL VTU-O physical interface monitoring history data

This managed entity contains the last completed 15-minute interval collected statistic data for a VDSL physical interface.

Instances of this managed entity are created/deleted by the OLT after an instance of the Physical Path Termination Point VDSL UNI managed entity is created/deleted.

The performance management of the physical interfaces used by VDSL shall be supported. Failure/notifications should include threshold alerts for unacceptable performance (error) rates. Performance data should include transmission counts of Errored Seconds (ES), Severely Errored Seconds (SES) and Unavailable Seconds (UAS).

#### *Relationships*

One instance of this managed entity can exist for each instance of the Physical Path Termination Point VDSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot ID. The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255). (R, W, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> ID:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Loss of Framing Seconds:** Count of seconds during this interval that there was Loss of Framing. (R) (mandatory) (2 bytes)

**Loss of Signal Seconds:** Count of seconds during this interval that there was Loss of Signal. (R) (mandatory) (2 bytes)

**Loss of Power Seconds:** Count of seconds during this interval that there was Loss of Power. (R) (mandatory) (2 bytes)

**Loss of Link Seconds:** Count of seconds during this interval that there was Loss of Link. (R) (mandatory) (2 bytes)

**Errored Seconds:** Count of Errored Seconds during this interval. An Errored Second is a one-second interval containing one or more CRC anomalies, or one or more LOS or LOF defects. (R) (mandatory) (2 bytes)

**Severely Errored Seconds:** Count of Severely Errored Seconds during this interval. (R) (mandatory) (2 bytes)

**Unavailable Seconds:** Count of Unavailable Seconds during this interval. (R) (mandatory) (2 bytes)

**Line Initializations:** Count of the line initialization attempts during this interval. This count includes both successful and failed attempts. (R) (mandatory) (2 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Get Current Data:** Get the current value of one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. Both ONU and OLT should know the event list used by this entity. The list of TCAs for this entity is given in Table 29.

**Table 29/G.983.2 – Alarm list for VDSL VTU-O physical interface monitoring history data (reproduced from Table 12/G.983.10)**

Number	Event	Description	Threshold data counter number (Note)
	<b>Threshold Crossing Alert</b>		
0	LOFS	Exceeds threshold	1
1	LOSS	Exceeds threshold	2
2	LOLS	Exceeds threshold	3
3	LOPS	Exceeds threshold	4
4	ES	Exceeds threshold	5
5	LI	Exceeds threshold	6
6	SES	Exceeds threshold	7
7	UAS	Exceeds threshold	8
8-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### **7.3.90 VDSL VTU-R physical interface monitoring history data**

This managed entity contains the last completed 15-minute interval collected statistic data for a VDSL physical interface.

Instances of this managed entity are created/deleted by the OLT after an instance of the Physical Path Termination Point VDSL UNI managed entity is created/deleted.

The performance management of the physical interfaces used by VDSL shall be supported. Failure/notifications should include threshold alerts for unacceptable performance (error) rates. Performance data should include transmission counts of Errored Seconds (ES), Severely Errored Seconds (SES) and Unavailable Seconds (UAS).

## Relationships

One instance of this managed entity can exist for each instance of the Physical Path Termination Point VDSL UNI.

## Attributes

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot ID. The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255). (R, W, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> ID:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set by-create) (mandatory) (2 bytes)

**Loss of Framing Seconds:** Count of seconds during this interval that there was Loss of Framing. (R) (mandatory) (2 bytes)

**Loss of Signal Seconds:** Count of seconds during this interval that there was Loss of Signal. (R) (mandatory) (2 bytes)

**Loss of Power Seconds:** Count of seconds during this interval that there was Loss of Power. (R) (mandatory) (2 bytes)

**Loss of Link Seconds:** Count of seconds during this interval that there was Loss of Link. (R) (mandatory) (2 bytes)

**Errored Seconds:** Count of Errored Seconds during this interval. An Errored Second is a one-second interval containing one or more CRC anomalies, or one or more LOS or LOF defects. (R) (mandatory) (2 bytes)

**Severely Errored Seconds:** Count of Severely Errored Seconds during this interval. (R) (mandatory) (2 bytes)

**Unavailable Seconds:** Count of Unavailable Seconds during this interval. (R) (mandatory) (2 bytes)

## Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Get Current Data:** Get the current value of one or more attributes.

**Set:** Set one or more attributes.

## Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. Both ONU and OLT should know the event list used by this entity. The list of TCAs for this entity is given in Table 30.

**Table 30/G.983.2 – Alarm list for VDSL VTU-R physical interface monitoring history data (reproduced from Table 13/G.983.10)**

Number	Event	Description	Threshold data counter number (Note)
	<b>Threshold Crossing Alert</b>		
0	LOFS	Exceeds threshold	1
1	LOSS	Exceeds threshold	2
2	LOLS	Exceeds threshold	3
3	LOPS	Exceeds threshold	4
4	ES	Exceeds threshold	5
5	SES	Exceeds threshold	6
6	UAS	Exceeds threshold	7
7-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.91 VDSL VTU-O channel performance monitoring history data

This managed entity contains the last completed 15-minute interval collected statistic data for both fast and slow VDSL channels, as seen from the VTU-O.

Instances of this managed entity are created/deleted by the OLT after an instance of the Physical Path Termination Point VDSL UNI managed entity is created/deleted.

#### Relationships

One instance of this managed entity can exist for each instance of the Physical Path Termination Point VDSL UNI.

#### Attributes

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot ID. The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255). (R, W, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last



completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> ID:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set by-create) (mandatory) (2 bytes)

**Fast Channel Corrected Blocks:** This attribute is the count of all blocks received by the VTU-O with errors that were corrected on the fast channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Fast Channel Bad Blocks:** This attribute is the count of all blocks received by the VTU-O with uncorrectable errors on the fast channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Fast Channel Transmitted Blocks:** This attribute is the count of all blocks transmitted by the VTU-O on the fast channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Fast Channel Received Blocks:** This attribute is the count of all blocks received by the VTU-O on the fast channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Slow Channel Corrected Blocks:** This attribute is the count of all blocks received by the VTU-O with errors that were corrected on the slow channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Slow Channel Bad Blocks:** This attribute is the count of all blocks received by the VTU-O with uncorrectable errors on the slow channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Slow Channel Transmitted Blocks:** This attribute is the count of all blocks transmitted by the VTU-O on the slow channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Slow Channel Received Blocks:** This attribute is the count of all blocks received by the VTU-O on the slow channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Get Current Data:** Get the current value of one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. Both ONU and OLT should know the event list used by this entity. The list of TCAs for this entity is given in Table 31.

**Table 31/G.983.2 – Alarm list for VDSL VTU-O channel performance monitoring history data (reproduced from Table 14/G.983.10)**

Number	Event	Description	Threshold data counter number (Note)
	<b>Threshold Crossing Alert</b>		
0	FCCB	Exceeds threshold	1
1	FCBB	Exceeds threshold	2
2	SCCB	Exceeds threshold	3
3	SCBB	Exceeds threshold	4
4-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.92 VDSL VTU-R channel performance monitoring history data

This managed entity contains the last completed 15-minute interval collected statistic data for both fast and slow VDSL channels, as seen from the VTU-R.

Instances of this managed entity are created/deleted by the OLT after an instance of the Physical Path Termination Point VDSL UNI managed entity is created/deleted.

#### *Relationships*

One instance of this managed entity can exist for each instance of the Physical Path Termination Point VDSL UNI.

#### *Attributes*

**Managed Entity ID:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the physical position of the UNI. The first byte is the slot ID. The second byte is the port ID with a value range from 0x01 to 0xFF (1 to 255). (R, W, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> ID:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set by-create) (mandatory) (2 bytes)

**Fast Channel Corrected Blocks:** This attribute is the count of all blocks received by the VTU-R with errors that were corrected on the fast channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Fast Channel Bad Blocks:** This attribute is the count of all blocks received by the VTU-R with uncorrectable errors on the fast channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Fast Channel Transmitted Blocks:** This attribute is the count of all blocks transmitted by the VTU-R on the fast channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Fast Channel Received Blocks:** This attribute is the count of all blocks received by the VTU-R on the fast channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Slow Channel Corrected Blocks:** This attribute is the count of all blocks received by the VTU-R with errors that were corrected on the slow channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Slow Channel Bad Blocks:** This attribute is the count of all blocks received by the VTU-R with uncorrectable errors on the slow channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Slow Channel Transmitted Blocks:** This attribute is the count of all blocks transmitted by the VTU-R on the slow channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

**Slow Channel Received Blocks:** This attribute is the count of all blocks received by the VTU-R on the slow channel within the previous 15-minute interval. (R) (mandatory) (4 bytes)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Get Current Data:** Get the current value of one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. Both ONU and OLT should know the event list used by this entity. The list of TCAs for this entity is given in Table 32.

**Table 32/G.983.2 – Alarm list for VDSL VTU-R channel performance monitoring  
history data (reproduced from Table 15/G.983.10)**

Number	Event	Description	Threshold Data Counter Number (Note)
	<b>Threshold Crossing Alert</b>		
0	FCCB	Exceeds threshold	1
1	FCBB	Exceeds threshold	2
2	SCCB	Exceeds threshold	3
3	SCBB	Exceeds threshold	4
4-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.93 Video return path service profile

#### *Relationships*

One instance of this managed entity may exist for each ONU. It is created automatically by the ONU on startup, if the ONU implements this service.

Please note that Annex A defines the transport methods required to support the video return path function. This includes providing a brief description of the relevant aspects of the two return path specifications supported (SCTE 55-1 [25] and 55-2 [26]). It also includes the formatting for carriage of the data over the B-PON data path.

Appendix VI presents three transparent ways to support the video return channel over a B-PON or other access system. The transparent aspect of the video return path is given only for information since it does not impact B-PON standardization.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for the instance of this managed entity. This 2-byte number always has the value 0x00. (R) (mandatory) (2 bytes)

**Administrative State:** This attribute is used to activate (unlock: value 0x00) and deactivate (lock: value 0x01) the functions performed by instances of this managed entity. Selection of a default value for this attribute is outside the scope of this Recommendation as it is normally handled through supplier-operator negotiations. (R, W) (mandatory) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**ARC:** This attribute is used to control alarm reporting from this managed entity. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**ARCInterval:** This attribute provides a provisionable length of time. See I.1.8 for a complete description. (R, W) (optional) (1 byte)

**VRP Mode:** This attribute specifies which format is being used for the VRP. These are defined by code-points:

0: Mode 1, SCTE 55-1 shall be used (256 kbit/s data rate, 62 byte PDUs, preceded by the unique word 0xCC CC CC 0). (mandatory)

- 1: Mode 2, SCTE 55-2 shall be used (256 kbit/s data rate, 59 byte PDUs, preceded by the unique word 0xCC CC CC 0D). (optional)
- 2: Mode 2, SCTE 55-2 shall be used (1.544 Mbit/s data rate, 59 byte PDUs, preceded by the unique word 0xCC CC CC 0D). (mandatory)
- 3: Mode 2, SCTE 55-2 should be used (3.088 Mbit/s data rate, 59 byte PDUs, preceded by the unique word 0xCC CC CC 0D). (optional)
- 4-255: Reserved.

(R, W) (mandatory) (1 byte)

**VRP Frequency lower bound:** This attribute reports the ONU VRP tuning range lower bound, in units of Hertz. (R) (mandatory) (4 bytes)

**VRP Frequency upper bound:** This attribute reports the ONU VRP tuning range upper bound, in units of Hertz. (R) (mandatory) (4 bytes)

**VRP Frequency used:** This attribute reports the ONU VRP tuner frequency currently in use, in units of Hertz. (R, W) (mandatory) (4 bytes)

**Mode 1 Physical Layer Configuration Mode:** This attribute controls the physical layer configuration to be used in mode 1. The attribute is bit mapped, as follows:

Bit 15: DQPSK mode. 0 = "Default Mode", 1 = "Alternate Mode"

Bit 14-8: Reserved

Bit 7: Randomizer Stage 6 preload

Bit 6: Randomizer Stage 7 preload

Bit 5: Randomizer Stage 8 preload

Bit 4: Randomizer Stage 9 preload

Bit 3: Randomizer Stage 10 preload

Bit 2: Randomizer Stage 11 preload

Bit 1: Randomizer Stage 12 preload

Bit 0: Randomizer Stage 13 preload

(R, W) (mandatory) (2 bytes)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify its new value. The AVC list is given in Table 33.

**Alarm:** This notification is used to notify the management system when a failure has been detected or cleared. Both ONT and OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 34.

**Table 33/G.983.2 – AVC list for video return path service**

Number	Attribute value change	Description
1	N/A	
2	OpState	Operational state of VRP Service
3-16	Reserved	

**Table 34/G.983.2 – Alarm list for video return path service**

Number	Event	Description
0	Frequency Mismatch	Frequency set by OLT is outside the capabilities of this ONU, or a frequency that is not on the standardized frequency plan
1-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.3.94 Video return path statistics

#### *Relationships*

One instance of this managed entity may exist for each ONU. It is created by the OLT.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for the instance of this managed entity. This 2-byte number always has the value 0x00. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the attribute counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. The attribute counters are updated at the end of the interval. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> ID:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Rx Total bursts:** This attribute reports the total number of bursts detected. (R) (optional) (4 bytes)

**Rx Good bursts:** This attribute reports the number of bursts that were detected and received correctly. (R) (optional) (4 bytes)

**Rx FEC corrected bursts:** This attribute reports the number of bursts that were detected with errors, but which were successfully corrected using FEC. (R) (optional) (4 bytes)

**Rx Missed bursts:** This attribute reports the number of bursts that were detected, but that were not received correctly (e.g., errors that are FEC uncorrectable). (R) (optional) (4 bytes)

**Rx Min Power:** This attribute reports the lowest power level of all bursts received in the current interval, in units of dBmV. (R) (optional) (1 byte)

**Rx Max Power:** This attribute reports the highest power level of all bursts received in the current interval, in units of dBmV. (R) (optional) (1 byte)

**Rx Current Power:** This attribute reports the power level of the latest burst received, in units of dBmV. (R) (mandatory) (optional) (1 byte)

**Rx FEC corrected Symbols:** This attribute reports the number of symbols that were corrected through the use of FEC. It provides an indicator of the bit error rate of the link. (R) (optional) (4 bytes)

#### Actions

**Set:** Set one Threshold ID.

**Get:** Get one or more attributes.

**Get current data:** This action returns the current value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval. Support of this action is optional.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a Threshold Crossing Alert (TCA) has been detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold by the actual counter; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the actual counters are reset to 0x00. The event list for this entity is given in Table 35.

**Table 35/G.983.2 – Alarm list for video return path statistics**

Number	Event	Description	Threshold data counter number (Note)
	<b>Threshold Crossing Alert</b>		
0	Rx Total bursts	Rx Total bursts threshold crossing	1
1	Rx Good bursts	Rx Good bursts threshold crossing	2
2	Rx FEC corrected bursts	Rx FEC corrected bursts threshold crossing	3
3	Rx Missed bursts	Rx Missed bursts threshold crossing	4
4	Rx Min Power	Rx Min Power threshold crossing	5
5	Rx Max Power	Rx Max Power threshold crossing	6
6	Rx Current Power	Rx Current Power threshold crossing	7
7	Rx FEC corrected Symbols	Rx FEC corrected Symbols threshold crossing	8
8-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

### 7.3.95 802.1p mapper service profile

This managed entity is used to associate the priorities of 802.1P priority tagged frames with a specific connection. Instances of this managed entity are created and deleted at the request of the OLT.

#### *Relationships*

One instance of this ME may be associated with zero or one instance of the PPTP UNI ME or the MAC bridge port configuration data ME.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. (R, Set-by-create) (mandatory) (2 bytes)

**PPTP UNI Pointer:** An instance identifier of the PPTP UNI that is associated with this 802.1p Priority Queue Mapper, in the case of direct 802.1p mapping. In the case of combined Bridging-mapping, this pointer is not used, and its value is set to 0xFFFF. (R, Set-by-create) (mandatory) (2 bytes)

**Interwork TP Pointer (for P-Bit priority 0):** This attribute represents a pointer to the Interworking Termination Point that is associated with P-Bit = 000 tagged frames. The value 0xFFFF is a null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Interwork TP Pointer (for P-Bit priority 1):** This attribute represents a pointer to the Interworking Termination Point that is associated with P-Bit = 001 tagged frames. The value 0xFFFF is a null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Interwork TP Pointer (for P-Bit priority 2):** This attribute represents a pointer to the Interworking Termination Point that is associated with P-Bit = 010 tagged frames. The value 0xFFFF is a null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Interwork TP Pointer (for P-Bit priority 3):** This attribute represents a pointer to the Interworking Termination Point that is associated with P-Bit = 011 tagged frames. The value 0xFFFF is a null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Interwork TP Pointer (for P-Bit priority 4):** This attribute represents a pointer to the Interworking Termination Point that is associated with P-Bit = 100 tagged frames. The value 0xFFFF is a null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Interwork TP Pointer (for P-Bit priority 5):** This attribute represents a pointer to the Interworking Termination Point that is associated with P-Bit = 101 tagged frames. The value 0xFFFF is a null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Interwork TP Pointer (for P-Bit priority 6):** This attribute represents a pointer to the Interworking Termination Point that is associated with P-Bit = 110 tagged frames. The value 0xFFFF is a null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Interwork TP Pointer (for P-Bit priority 7):** This attribute represents a pointer to the Interworking Termination Point that is associated with P-Bit = 111 tagged frames. The value 0xFFFF is a null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Unmarked Frame Option:** This attribute indicates how the ONT should handle Untagged Ethernet frames received across the associated Ethernet interface. Valid values include the following:

0: Convert from DSCP to 802.1p;

1: Tag frame to a certain value.

(R, W, Set-by-create) (mandatory) (1 byte)



**DSCP to P-Bit Mapping:** This attribute is used in conjunction with the Unmarked Frame Option attribute. If unmarked frame option is 0, this attribute structure can be considered a bitmap that represents a sequence of 64 "3-bit" groupings. Each of the 64 groupings represents the possible value of the 6-bit DSCP field. Each of the "3-bit" groupings represents the "P-bit value" to which the associated DSCP value should be mapped. Once marked, the P-Bit marked frame will then be routed to the GEM Interwork Pointer as indicated by the P-Bit to Interwork Pointer mappings above.

(R, W, Set-by-create) (mandatory) (24 bytes)

**Default P-Bit Marking:** This attribute is used in conjunction with the Unmarked Frame Option attribute. If unmarked frame option is 1, this attribute contains the default P-Bit priority setting that will be applied to the frame. The P-Bit marked frame will then be routed to the GEM Interwork Pointer as indicated by the P-Bit to Interwork Pointer mappings above.

(R, W, Set-by-create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

None.

### **7.3.96 OLT<sub>B-PON</sub>**

This optional managed entity identifies the OLT to which an ONT is connected.

The setting of this ME prompts the ONT to configure itself for operability with the OLT that has identified itself. If the OLT is operable with the ONT's default configuration then the setting of this ME is not required.

An instance of this managed entity is automatically created by the ONT after initialization and setup to the ONT's current configuration. Immediately following the startup phase, the OLT sets the ONT to the desired configuration.

#### *Relationships*

One instance of this managed entity is contained in the instance of the ONT managed entity.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. There is only one instance and it has the number 0x0000. (R) (mandatory) (2 bytes)

**OLT Vendor id:** This attribute identifies the OLT vendor that the ONT is interfacing with, and is the same format as the 4 most significant bytes of an ONT serial number as specified in ITU-T Rec. G.983.1. Upon autonomous instantiation, this attribute consists of all spaces. (R,W) (mandatory) (4 bytes)

**Equipment ID:** This attribute may be used to identify the specific type of OLT. In North America, this may be used for the equipment CLEI code. The default value of all spaces shall be used when Equipment ID information is not available or applicable to the OLT being represented. Upon autonomous instantiation, this attribute consists of all spaces. (R,W) (mandatory) (20 bytes)

**Version:** This attribute identifies the version of the OLT as defined by the vendor. The default value of a printable value of "0" shall be used when version information is not available or applicable to the OLT being represented. Upon autonomous instantiation, this attribute consists of all spaces. (R,W) (mandatory) (14 bytes)

#### *Actions*

**Set:** Set one or more attributes.

**Get:** Get one or more attributes.

#### *Notifications*

None.

### **7.3.97 Multicast interworking VCC termination point**

An instance of this managed entity represents a point in the ONT where the interworking of a service (e.g., IP) or underlying physical infrastructure (e.g., Ethernet) takes place. At this point, a bit stream is reconstructed from ATM cells.

Instances of this managed entity are created and deleted by the ONT on request of the OLT.

#### *Establishment of connection*

The multicast VCC TP is a special case of the ordinary VCC TP managed entity, whose purpose is specifically to manage the correspondence of IP multicast group addresses with the PON layer addresses. This is done via a new table attribute. The relationships that the ordinary VCC TP entity has would be maintained; however, the VP/VC network CTP would not reflect a normal connection per se, as the multicast VCC TP can represent many connections at once. So, the VP/VC network CTP object used in this case would not represent a circuit termination point, and would only be used to provide information on the traffic descriptors, priority queues, or performance management features.

The related VP/VC network CTP, Service Profile, and AAL profile entities must be created first. The multicast interworking VCC TP is then created with references to these entities.

#### *Modes of operation*

The default multicast operation of the PON is where all the multicast content streams are placed in one PON layer connection. This connection is then specified in the first entry of the MulticastAddressTable as set by the OLT. The single entry also specifies an all-inclusive IP multicast address range (e.g., 224.0.0.0 to 239.255.255.255). The ONT then filters the traffic based on either Ethernet MAC addresses or IP addresses. The VP/VC Network CTP ME has the VPI/VCI that supports all the multicast connections.

The optional multicast operation of the PON is where groups of one or more multicast content streams are carried over individual PON layer connections. In this case, the OLT sets as many table entries as desired for the multicasting control system. The ONT then filters the groups based on PON layer address. The ONT can also filter based on higher-layer addresses in a subsequent step. In this case, only one instance of VP/VC Network CTP ME is created by the request from OLT. Though this VP/VC Network CTP ME has only one VPI/VCI, ONT should regard this ME as the representative of those multicast VP/VC connections. Therefore, the traffic descriptors, priority queues, and performance management features for all the multicast connections are integrated into the VP/VC Network CTP ME.

#### *Discovery of Multicast support*

The OLT uses the multicast IW VCC TP entity as the means to discover the ONT's multicasting capability. This entity is mandatory if multicasting is supported by the ONT. Therefore, if the OLT

attempts to create this entity on an ONT that does not support multicasting, the create command will fail. Furthermore, if the ONT does not support multiple multicasting groups, then the OLT's attempt to set multiple table entries will fail. The OLT will then have to make the necessary adjustments.

### *Relationships*

One instance of this managed entity shall exist for each occurrence of transformation of ATM cells into a data stream where multicast interworking is desired. Note that the attributes "AAL Profile pointer" and "Service Profile pointer" imply relationships to these managed entities.

### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The value 0xFFFF is reserved. (R, Set-by-create) (mandatory) (2 bytes)

**VCI Value:** This attribute is not used. (R, Set-by-create) (mandatory) (2 bytes)

**VP/VCNetworkCTP Connectivity Pointer:** This attribute provides an instance identifier of the VP Network CTP<sub>B-PON</sub> or VC Network CTP<sub>B-PON</sub> that is associated with this Interworking VCC Termination Point. (R, Set-by-create) (mandatory) (2 bytes)

**Interworking Option:** This attribute identifies the type of non-ATM function that is being interworked; the option can be MAC Bridge LAN (0x01), IP Router (0x03), or 802.1p mapper (0x05). (R, Set-by-create) (mandatory) (1 byte)

**Service Profile Pointer:** This attribute provides the service profile type and a pointer to the instance of a service profile, such as the MAC Bridge Service Profile (if the interworking option = 0x01), IP Router Service Profile (if the interworking option = 0x03), or 802.1p mapper service profile (if interworking option = 0x05). (R, Set-by-create) (mandatory) (2 bytes)

**AAL Profile Pointer:** This attribute provides the AAL profile type and a pointer to an instance of AAL Profile such as AAL 5 Profile<sub>B-PON</sub> if the interworking option = 0x01, 0x03, 0x05. (R, Set-by-create) (mandatory) (2 bytes)

**Interworking Termination Point pointer:** This attribute is set to 0x0000, and not used. (R, Set-by-create) (mandatory) (2 bytes)

**AAL Loopback configuration:** This attribute is set to 0x0000 and not used. (R, W) (mandatory) (1 byte)

**PPTP Counter:** This attribute represents the number of instances of PPTP managed entities associated with this instance of the Interworking VCC Termination Point managed entity. If only one instance of a PPTP managed entity is associated with this instance of the Interworking VCC Termination Point managed entity, this attribute is set to 0x01. If multiple instances of PPTP managed entities are associated with this instance of the Interworking VCC Termination Point managed entity, this attribute is set to 0xZZ, where ZZ represents the number of associated PPTP instances. (R) (optional) (1 byte)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**MulticastAddressTable:** This attribute contains the mapping of IP multicast addresses to PON layer addresses. One entry provides the VPI/Port-ID value (2 bytes, right justified), VCI/spare value (2 bytes), IP multicast address start (4 bytes), and IP multicast address stop (4 bytes). An OMCI set message can carry a maximum of 2 entries at the same time. The first four bytes of each entry is treated as the index of the list, and a Set to a particular (VPI/Port-ID – VCI/spare) value will overwrite any existing entry with the same first four bytes. If the last eight bytes of a Set command are all zero, then that entry will be deleted from the list, as all-zero IP addresses

are not valid multicast addresses. (R, W) (mandatory for one entry, optional for multiple entries) (N \* 12 bytes, N is the number of entries in the list.)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes. Latch a snapshot (i.e., copy) of the current MulticastAddressTable and respond with the size of data (4 bytes) that should be obtained using the Get next command.

**Get Next:** Get the latched attribute values of the managed entity within the current snapshot.

**Set:** Set one or more attributes.

#### Notifications

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify the attribute and its new value. The list of AVCs for this managed entity is given in Table 36a.

**Alarm:** None.

**Table 36a/G.983.2 – AVC list for interworking VCC termination point**

Number	Attribute value change	Description
1-9	N/A	
10	OpState	Operational state of Interworking VCC Termination Point
11-16	Reserved	

**Table 36b/G.983.2 – Alarm list for interworking VCC termination point**

Number	Alarm	Description
0	End-to-end VC-AIS-LMIR	End-to-end VC-AIS receiving indication (optional)
1	End-to-end VC-RDI-LMIR	End-to-end VC-RDI receiving indication (optional)
2	End-to-end VC-AIS-LMIG	End-to-end VC-AIS generation indication (optional)
3	End-to-end VC-RDI-LMIG	End-to-end VC-RDI generation indication (optional)
4	Segment Loss of Continuity	Loss of continuity is detected when the Interworking VCC Termination Point is a segment end point (optional)
5	End-to-End Loss of Continuity	Loss of continuity is detected at the Interworking VCC Termination Point (optional)
6	CSA	Cell starvation alarm
7-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

## 7.4 VP and VC MUX management

### 7.4.1 VP Network CTP<sub>B-PON</sub>

This managed entity is used to represent the termination of VP links on an ONT. An instance of the ATM VP Cross-Connection (i.e., VP MUX in ONT) managed entity may be used to relate two

instances of the VP Network CTP<sub>B-PON</sub> managed entity for point-to-point cross-connection (multipoint cross-connection is for further study).

Instances of the VP Network CTP<sub>B-PON</sub> managed entity will be created on demand of the OLT:

- as a consequence of action "create" on the VP Network CTP<sub>B-PON</sub> managed entity, or
- as a consequence of action "create complete connection" on the ATM VP Cross-Connection managed entity.

Instances of the VP Network CTP<sub>B-PON</sub> managed entity will be deleted on demand of the OLT:

- as a consequence of action "delete" on the VP Network CTP<sub>B-PON</sub> managed entity, or
- as a consequence of action "delete complete connection" on the ATM VP Cross-Connection managed entity.

Notice that a VP Network CTP<sub>B-PON</sub> can be deleted only when no ATM VP Cross-Connection or Interworking VCC Termination Point is associated with it. It is the responsibility of the OLT to make sure that the VP Network CTP<sub>B-PON</sub> meets this condition at the time when the OLT requests to delete it.

Note that this managed entity aggregates connectivity functionality from the network view and alarms from the network element view as well as artefacts from trails.

### *Relationships*

Zero or more instances of the VP Network CTP<sub>B-PON</sub> managed entity shall exist for each instance of the TC Adapter<sub>B-PON</sub>, PON TC Adapter or Interworking VCC Termination Point managed entity.

Relationship to Priority Queue<sub>B-PON</sub>/Traffic Descriptor Profile Pointer: see attribute definition.

Relationship to UPC Disagreement Monitoring History Data<sub>B-PON</sub>: one or zero implied in the managed entity id of UPC Disagreement Monitoring History Data<sub>B-PON</sub>.

This managed entity is related to the ATM VP Cross-Connection managed entity through the Termination Point ANI/UNI side attributes of the ATM VP Cross-Connection managed entity.

### *Attributes*

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all Network CTP<sub>B-PON</sub> MEs, of both VP and VC type. (R, Set-by-create) (mandatory) (2 bytes)

**VPI Value:** This attribute identifies the VPI value associated with the VP link being terminated. This value must be unique over any ANI or UNI. (R, Set-by-create) (mandatory) (2 bytes)

**UNI/ANI Pointer:** This attribute associates the VP Network CTP<sub>B-PON</sub> with the ANI (i.e., PON interface) or a UNI. It points to the connected ANI/UNI instance id.

NOTE – For the case using the multiplexing function of AAL 2 (i.e., multiple instances of UNI are associated with a VP Network CTP<sub>B-PON</sub> instance), this attribute is assigned a special value:

0x00XX will be used for pseudo slotIDs;

0xXX00 will be used for pseudo portIDs.

Therefore, 0x0000 will be used only for integrated interfaces (integrated type of ONT) that support multiple AAL 2 functions. (R, Set-by-create) (mandatory) (2 bytes)

**Direction:** This attribute specifies whether the VP link is used for UNI-to-ANI (value 0x01), ANI-to-UNI (value 0x02), or bidirectional (value 0x03) connection. (R, W, Set-by-create) (mandatory) (1 byte)

**Priority Queue Pointer for downstream:** This attribute points to the instance of the Priority Queue<sub>B-PON</sub> used for this VP Network CTP<sub>B-PON</sub> in the downstream direction. Note that the value of this pointer is null when the VP Network CTP<sub>B-PON</sub> is at the ANI side. (R, Set-by-create) (mandatory) (2 bytes)

**Traffic Management Pointer for upstream:** This attribute points to the instance of the Priority Queue<sub>B-PON</sub> or T-CONT used for this VP Network CTP<sub>B-PON</sub> in the upstream direction. It is used when the UNI/ANI pointer indicates an ANI instance id. If the **Traffic Management Option** attribute in ONT<sub>B-PON</sub> is 0x00, then this pointer indicates the Priority Queue serving this VP CTP. If the **Traffic Management Option** attribute in ONT<sub>B-PON</sub> is 0x01, then this pointer indicates the T-CONT serving this VP CTP. (R, Set-by-create) (mandatory) (2 bytes)

**Traffic Descriptor Profile Pointer:** This attribute serves as a pointer to the instance of the Traffic Descriptor Profile managed entity that contains the traffic parameters used for this VP Network CTP<sub>B-PON</sub>. This attribute is used when the **Traffic Management Option** attribute in ONT<sub>B-PON</sub> is 0x01. It applies to the UNI side VP Network CTP<sub>B-PON</sub> if UPC is used. In this case, this pointer points to a Traffic Descriptor managed entity.

When traffic shaping is used, it applies to the ANI side VP Network CTP<sub>B-PON</sub>. In this case, this pointer points to a Traffic Descriptor Profile managed entity and the **Priority Queue Pointer for the upstream** attribute is null. (R, Set-by-create) (optional) (2 bytes)

See also Appendix IV.

**UNI Counter:** This attribute represents the number of instances of UNI<sub>B-PON</sub> managed entities associated with an instance of the VP Network CTP<sub>B-PON</sub> managed entity. If only one instance of a UNI<sub>B-PON</sub> managed entity is associated with an instance of the VP Network CTP<sub>B-PON</sub> managed entity, this attribute is set to 0x01. If multiple instances of UNI<sub>B-PON</sub> managed entities are associated with an instance of the VP Network CTP<sub>B-PON</sub> managed entity (i.e., in case of AAL 2 multiplexing), this attribute is set to 0xZZ, where ZZ represents the number of associated UNI<sub>B-PON</sub> instances. (R) (optional) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

**Set:** Set one or more attributes of this managed entity.

#### *Notifications*

**Alarm:** This notification is used to notify the management system for the ATM Layer Management Indication (LMI) when an alarm has been detected or cleared. The OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 37. See also Appendix III.

**Table 37/G.983.2 – Alarm list for VP network CTP<sub>B-PON</sub>**

Number	Alarm	Description
0	VP-AIS-LMIR	VP-AIS receiving indication (optional)
1	VP-RDI-LMIR	VP-RDI receiving indication (optional)
2	VP-AIS-LMIG	VP-AIS generation indication (optional)
3	VP-RDI-LMIG	VP-RDI generation indication (optional)
4	Segment Loss of Continuity	Loss of continuity is detected when the VP Network CTP <sub>B-PON</sub> is a segment end point (optional)
5	End-to-End Loss of Continuity	Loss of continuity is detected when the VP Network CTP <sub>B-PON</sub> supports an Interworking VCC Termination Point (optional)
6-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

#### **7.4.2 ATM VP cross-connection**

For point-to-point ATM VP Cross-Connections, this managed entity is used to represent the Cross-Connect relationship between two VP Network CTP<sub>B-PON</sub>. For multipoint ATM VP Cross-Connections, which are optional, the use of this managed entity is for further study.

Instances of this managed entity shall be created and deleted by the OLT based on ATM connection set up.

##### *Relationships*

Zero or more instances of the ATM VP Cross-Connection managed entity shall exist for each instance of the ONT<sub>B-PON</sub> managed entity.

##### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the instance identifier of the VP Network CTP<sub>B-PON</sub> at the ANI side of this ATM VP cross-connect. (R, Set-by-create) (mandatory) (2 bytes)

**Termination Point ANI side:** This attribute identifies the instance of the VP Network CTP<sub>B-PON</sub> managed entity that represents the cross-connected VP Network CTP<sub>B-PONS</sub> on the ANI side. (R, Set-by-create) (mandatory) (2 bytes)

**Termination Point UNI side:** This attribute identifies the instance of the VP Network CTP<sub>B-PON</sub> managed entity that represents the cross-connected VP Network CTP<sub>B-PONS</sub> on the UNI side. (R, Set-by-create) (mandatory) (2 bytes)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**Administrative State:** This attribute is used to "unlock" (value 0x00) and "lock" (value 0x01) the functions performed by instances of this managed entity. (R, W, Set-by-create) (mandatory) (1 byte)

##### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Create complete connection:** Create two instances of the VP Network CTP<sub>B-PON</sub> managed entity (ANI-side and UNI-side) and one instance of the ATM VP Cross-Connection managed entity.

**Delete complete connection:** Delete two instances of the VP Network CTP<sub>B-PON</sub> managed entity (ANI-side and UNI-side) and one instance of the ATM VP Cross-Connection managed entity.

**Get:** Get attributes of this managed entity.

**Get complete connection:** Get all attributes of a connection; this holds the attributes of two instances of the VP Network CTP<sub>B-PON</sub> managed entity (ANI-side and UNI-side) and the attributes of the corresponding ATM VP Cross-Connection managed entity.

**Set:** Set one or more attributes.

### *Notifications*

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify its new value. The list of AVCs for this managed entity is given in Table 38.

**Table 38/G.983.2 – AVC list for ATM VP cross-connection**

Number	AVC	Description
1	N/A	
2	N/A	
3	OpState	Operational state
4	N/A	
5-16	Reserved	

### **7.4.3 VP PM history data**

This managed entity is used to collect and report performance monitoring data associated with a VPC for the last completed 15-minute interval. The instances of this managed entity are created and deleted on request of the OLT. Note that these processes supersede the in-band PM OAM functions.

### *Relationships*

Zero or more instances of this managed entity may exist for each instance of the VP Network CTP<sub>B-PON</sub> managed entity. If the instance is associated with the ANI-side VP CTP, then the performance of the downstream ATM flows is reported. If the instance is associated with the UNI-side VP CTP, then the performance of the upstream ATM flows is reported.

### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the Managed Entity id of the corresponding VP Network CTP<sub>B-PON</sub>. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the actual counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. (R) (mandatory) (1 byte)



**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Lost C=0+1 Cells:** This attribute measures background cell loss. It cannot distinguish between cells lost because of header bit errors, ATM-level header errors, cell policing, or buffer overflows. It records only loss of information independent of the priority of the cell. If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (2 bytes)

**Lost C = 0 Cells:** This attribute measures background cell loss. It cannot distinguish between cells lost because of header bit errors, ATM-level header errors, cell policing, or buffer overflows. It records only loss of high priority cells. If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (2 bytes)

**Misinserted Cells:** This attribute is used to measure occurrences of when a cell is misrouted to an active VP that is being monitored. If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (2 bytes)

**Transmitted C = 0 + 1 Cells:** This attribute provides a count of all cells that are originated at a monitored connection by the transmitting end point (i.e., backward reporting is assumed). (R) (mandatory) (5 bytes)

**Transmitted C = 0 Cells:** This attribute provides a count of all high priority cells that are originated at a monitored connection by the transmitting end point (i.e., backward reporting is assumed). (R) (mandatory) (5 bytes)

**Impaired Block:** This severely errored cell block counter will be incremented whenever one of the following events takes place: the number of misinserted cells exceeds  $M_{\text{misinserted}}$ , the number of bipolar violations exceeds  $M_{\text{errored}}$ , or the number of lost cells exceeds  $M_{\text{lost}}$ . The values for  $M_{\text{misinserted}}$ ,  $M_{\text{errored}}$ , and  $M_{\text{lost}}$  are set based on vendor-operator negotiation. (R) (mandatory) (2 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes. Support of this action is optional.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the counters are reset to 0x00. Both ONT and OLT should know the event list used by this entity, given in Table 39.

**Table 39/G.983.2 – Alarm list for VP PM history data**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	Lost CLP=0+ 1 Cells	Exceeds threshold	1
1	Lost CLP=0 Cells	Exceeds threshold	2
2	Misinserted Cells	Exceeds threshold	3
3	Impaired Blocks	Exceeds threshold	4
4-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

#### 7.4.4 VC network CTP<sub>B-PON</sub>

This managed entity is used to represent the termination of VC links on an ONT. An instance of the ATM VC Cross-Connection (i.e., VC MUX in ONT) managed entity may be used to relate two instances of the VC Network CTP<sub>B-PON</sub> managed entity for point-to-point cross-connection (multipoint cross-connection is for further study).

Instances of the VC Network CTP<sub>B-PON</sub> managed entity will be created on demand of the OLT:

- as a consequence of action "create" on the VC Network CTP<sub>B-PON</sub> managed entity, or
- as a consequence of action "create complete connection" on the ATM VC Cross-Connection managed entity.

Instances of the VC Network CTP<sub>B-PON</sub> managed entity will be deleted on demand of the OLT:

- as a consequence of action "delete" on the VC Network CTP<sub>B-PON</sub> managed entity, or
- as a consequence of action "delete complete connection" on the ATM VC Cross-Connection managed entity.

Notice that a VC Network CTP<sub>B-PON</sub> can be deleted only when no ATM VC Cross-Connection or Interworking VCC Termination Point is associated with it. It is the responsibility of the OLT to make sure that the VC Network CTP<sub>B-PON</sub> meets this condition at the time when the OLT requests to delete it.

Note that this managed entity aggregates connectivity functionality from the network view and alarms from the network element view as well as artefacts from trails.

#### *Relationships*

Zero or more instances of the VC Network CTP<sub>B-PON</sub> managed entity shall exist for each instance of the TC Adapter<sub>B-PON</sub>, PON TC Adapter or Interworking VCC Termination Point managed entity.

Relationship to Priority Queue<sub>B-PON</sub> /Traffic Descriptor Profile Pointer: see attribute definition.

Relationship to UPC Disagreement Monitoring History Data<sub>B-PON</sub>: one or zero implied in the managed entity id of UPC Disagreement Monitoring History Data<sub>B-PON</sub>.

This managed entity is related to the ATM VC Cross-Connection managed entity through the Termination Point ANI/UNI side attributes of the ATM VC Cross-Connection managed entity.

## Attributes

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all Network CTP<sub>B-PON</sub> MEs, of both VP and VC type. (R, Set-by-create) (mandatory) (2 bytes)

**VPI Value:** This attribute identifies the VPI value associated with the VC link being terminated. (R, Set-by-create) (mandatory) (2 bytes)

**VCI Value:** This attribute identifies the VCI value associated with the VC link being terminated. The combination of VPI and VCI values must be unique over any ANI or UNI. (R, Set-by-create) (mandatory) (2 bytes)

**UNI/ANI Pointer:** This attribute associates the VC Network CTP<sub>B-PON</sub> with the ANI (i.e., PON interface) or a UNI. It points to the connected ANI/UNI instance id.

NOTE – For the case using the multiplexing function of AAL 2 (i.e., multiple instances of UNI are associated with a VC Network CTP<sub>B-PON</sub> instance), this attribute is assigned a special value:

- 0x00XX will be used for pseudo slotIDs;
- 0XX00 will be used for pseudo portIDs.

Therefore, 0x0000 will be used only for integrated interfaces (integrated type of ONT) that support multiple AAL 2 functions. (R, Set-by-create) (mandatory) (2 bytes)

**Direction:** This attribute specifies whether the VC link is used for UNI-to-ANI (value 0x01), ANI to-UNI (value 0x02), or bidirectional (value 0x03) connection. (R, W, Set-by-create) (mandatory) (1 byte)

**Priority Queue Pointer for downstream:** This attribute points to the instance of the Priority Queue<sub>B-PON</sub> used for this VC Network CTP<sub>B-PON</sub> in the downstream direction. Note that the value of this pointer is null when the VC Network CTP<sub>B-PON</sub> is at the ANI side. (R, Set-by-create) (mandatory) (2 bytes)

**Traffic management Pointer for upstream:** This attribute points to the instance of the Priority Queue<sub>B-PON</sub> or T-CONT used for this VC Network CTP<sub>B-PON</sub> in the upstream direction. It is used when the UNI/ANI pointer indicates an ANI instance id. If the **Traffic Management Option** attribute in ONT<sub>B-PON</sub> is 0x00, then this pointer indicates the Priority Queue serving this VC CTP. If the **Traffic Management Option** attribute in ONT<sub>B-PON</sub> is 0x01, then this pointer indicates the T-CONT serving this VC CTP. (R, Set-by-create) (mandatory) (2 bytes)

**Traffic Descriptor Profile Pointer:** This attribute serves as a pointer to the instance of the Traffic Descriptor Profile managed entity that contains the traffic parameters used for this VC Network CTP<sub>B-PON</sub>. This attribute is used when the **Traffic Management Option** attribute in ONT<sub>B-PON</sub> is 0x01. It applies to the UNI side VC Network CTP<sub>B-PON</sub> if UPC is used. In this case, this pointer points to a Traffic Descriptor managed entity.

When traffic shaping is used, it applies to the ANI side VC Network CTP<sub>B-PON</sub>. In this case, this pointer points to a Traffic Descriptor Profile managed entity and the **Priority Queue Pointer for the upstream** attribute is null. (R, Set-by-create) (optional) (2 bytes)

See also Appendix IV.

## Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

**Set:** Set one or more attributes of this managed entity.

## Notifications

**Alarm:** This notification is used to notify the management system for the ATM Layer Management Indication (LMI) when an alarm has been detected or cleared. The OLT should know the alarm list used by this entity. The alarm list for this entity is given in Table 40. See also Appendix III. Note that in the case where an Interworking VCC Termination Point ME is directly associated with this CTP, these alarms are suppressed on the CTP.

**Table 40/G.983.2 – Alarm list for VC network CTP<sub>B-PON</sub>**

Number	Alarm	Description
0	VC-AIS-LMIR	VC-AIS receiving indication (optional)
1	VC-RDI-LMIR	VC-RDI receiving indication (optional)
2	VC-AIS-LMIG	VC-AIS generation indication (optional)
3	VC-RDI-LMIG	VC-RDI generation indication (optional)
4	Segment Loss of Continuity	Loss of continuity is detected when the VC Network CTP <sub>B-PON</sub> is a segment end point (optional)
5	End-to-End Loss of Continuity	Loss of continuity is detected when the VC Network CTP <sub>B-PON</sub> supports an Interworking VCC Termination Point (optional)
6-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.4.5 ATM VC cross-connection

For point-to-point ATM VC Cross-Connections, this managed entity is used to represent the cross-connect relationship between two VC Network CTP<sub>B-PON</sub>s. For multipoint ATM VC Cross-Connections, which are optional, the use of this managed entity is for further study.

Instances of this managed entity shall be created and deleted by the OLT based on ATM connection set up.

## Relationships

Zero or more instances of the ATM VC Cross-Connection managed entity shall exist for each instance of the ONT<sub>B-PON</sub> managed entity.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is directly associated with the instance identifier of the VC Network CTP<sub>B-PON</sub> at the ANI side of this ATM VC cross-connect. (R, Set-by-create) (mandatory) (2 bytes)

**Termination Point ANI side:** This attribute identifies the instance of the VC Network CTP<sub>B-PON</sub> managed entity that represents the cross-connected VC Network CTP<sub>B-PON</sub>s on the ANI side. (R, Set-by-create) (mandatory) (2 bytes)

**Termination Point UNI side:** This attribute identifies the instance of the VC Network CTP<sub>B-PON</sub> managed entity that represents the cross-connected VC Network CTP<sub>B-PON</sub>s on the UNI side. (R, Set-by-create) (mandatory) (2 bytes)

**Operational State:** This attribute indicates whether or not this managed entity is capable of performing its task. The operational state reflects the perceived ability to receive or to generate a valid signal. Valid values are enabled (0x00) and disabled (0x01). (R) (optional) (1 byte)

**Administrative State:** This attribute is used to "unlock" (value 0x00) and "lock" (value 0x01) the functions performed by instances of this managed entity. (R, W, Set-by-create) (mandatory) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Create complete connection:** Create two instances of the VC Network CTP<sub>B-PON</sub> managed entity (ANI-side and UNI-side) and one instance of the ATM VC Cross-Connection managed entity.

**Delete complete connection:** Delete two instances of the VC Network CTP<sub>B-PON</sub> managed entity (ANI-side and UNI-side) and one instance of the ATM VC Cross-Connection managed entity.

**Get:** Get attributes of this managed entity.

**Get complete connection:** Get all attributes of a connection; this holds the attributes of two instances of the VC Network CTP<sub>B-PON</sub> managed entity (ANI-side and UNI-side) and the attributes of the corresponding ATM VC Cross-Connection managed entity.

**Set:** Set one or more attributes.

#### *Notifications*

**Attribute value change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify its new value. The list of AVCs for this managed entity is given in Table 41.

**Table 41/G.983.2 – AVC list for ATM VC cross-connection**

Number	AVC	Description
1	N/A	
2	N/A	
3	OpState	Operational state
4	N/A	
5-16	Reserved	

#### **7.4.6 VC PM history data**

This managed entity is used to collect and report performance monitoring data associated with a VCC for the last completed 15-minute interval. The instances of this managed entity are created and deleted on request of the OLT. Note that these processes supercede the in-band PM OAM functions.

#### *Relationships*

Zero or more instances of this managed entity may exist for each instance of the VC Network CTP<sub>B-PON</sub> managed entity. If the instance is associated with the ANI-side VP CTP, then the performance of the downstream ATM flows is reported. If the instance is associated with the UNI-side VP CTP, then the performance of the upstream ATM flows is reported.

#### *Attributes*

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the Managed Entity id of the corresponding VC Network CTP<sub>B-PON</sub>. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recently finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the actual counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute is set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Lost C = 0 + 1 Cells:** This attribute measures background cell loss. It cannot distinguish between cells lost because of header bit errors, ATM-level header errors, cell policing, or buffer overflows. It records only loss of information independent of the priority of the cell. If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (2 bytes)

**Lost C = 0 Cells:** This attribute measures background cell loss. It cannot distinguish between cells lost because of header bit errors, ATM-level header errors, cell policing, or buffer overflows. It records only loss of high priority cells. If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (2 bytes)

**Misinserted Cells:** This attribute is used to measure occurrences of when a cell is misrouted to an active VC that is being monitored. If the actual counter saturates, it remains on its maximum value. (R) (mandatory) (2 bytes)

**Transmitted C = 0 + 1 Cells:** This attribute provides a count of all cells that are originated at a monitored connection by the transmitting end point (i.e., backward reporting is assumed). (R) (mandatory) (5 bytes)

**Transmitted C = 0 Cells:** This attribute provides a count of all high priority cells that are originated at a monitored connection by the transmitting end point (i.e., backward reporting is assumed). (R) (mandatory) (5 bytes)

**Impaired Block:** This severely errored cell block counter will be incremented whenever one of the following events takes place: the number of misinserted cells exceeds  $M_{\text{misinserted}}$ , the number of bipolar violations exceeds  $M_{\text{errored}}$ , or the number of lost cells exceeds  $M_{\text{lost}}$ . The values for  $M_{\text{misinserted}}$ ,  $M_{\text{errored}}$ , and  $M_{\text{lost}}$  are set based on vendor-operator negotiation. (R) (mandatory) (2 bytes)

### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

## Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the counters are reset to 0x00. Both ONT and OLT should know the event list used by this entity, given in Table 42.

**Table 42/G.983.2 – Alarm list for VC PM history data**

Number	Event	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	Lost CLP=0+ 1 Cells	Exceeds threshold	1
1	Lost CLP=0 Cells	Exceeds threshold	2
2	Misinserted Cells	Exceeds threshold	3
3	Impaired Blocks	Exceeds threshold	4
4-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

## 7.5 Traffic management

### 7.5.1 Priority Queue<sub>B-PON</sub>

This managed entity specifies the priority queue in the ONT that is used for the VP Network CTP<sub>B-PON</sub>. All the Priority Queues used for the upstream traffic are created by the ONT after initialization. All the Priority Queues used for the downstream traffic are created/deleted by the ONT after the creation/deletion of the Subscriber Line Card.

The following assumption is made in order to simplify the queue management: the maximum number of priority queues supported by an ONT, Subscriber Line Card or PON IF Line Card is 32 (the maximum number is 256 in the case of DBA support). If  $N$  priority queues reside in the ONT, the Subscriber Line Card or PON IF Line Card,  $N$  Priority Queue<sub>B-PON</sub> managed entities will be automatically created by the ONT following the creation of the related equipment. Note that the OLT will find all the queues by reading the Priority Queue<sub>B-PON</sub> managed entity instances. If the OLT tries to retrieve a non-existing Priority Queue<sub>B-PON</sub>, this will be indicated in the response from the ONT to the OLT.

One or more Priority Queue should be created in the PON IF Linecard in order to guarantee the backward compatibility with the G.983.2 ONT.

See also Appendix IV.

Priority queues can exist in the ONT core and subscriber line cards as well as PON IF Line Cards. Therefore the managed entity id definition is extended for DBA applications.

In order to have a flexible connection and configuration between the priority queues and Traffic Schedulers and T-CONT buffers new attributes are added for DBA applications.

## Relationships

One or more instances of this managed entity shall be contained in the ONT<sub>B-PON</sub> managed entity to model the upstream direction if the **Traffic Management Option** attribute in ONT is 0x00.

One or more instances of this managed entity shall be associated with the Subscriber Line Card managed entity as downstream Priority Queue<sub>B-PON</sub>.

### *Attributes*

**Managed Entity id:** Non-DBA definition: This attribute provides a unique number for each instance of this managed entity. The first byte is the slot id of the Subscriber Line Card or PON IF card with which this queue is associated. The second byte is the priority of this queue (0x00 indicates the highest priority, and 0x1F (31) the lowest).

**DBA definition:** This attribute provides a unique number for each instance of this managed entity. The first byte is the slot id of the Subscriber Line Card or PON IF card with which this queue is associated. For integrated Subscriber Line/PON IF interfaces, this byte can be associated with "pseudo" slot ids 0x00, 0x80 (128), respectively. If the ONT has upstream priority queues that are not associated with the PON IF card at the creation of this instance, the first byte of this priority queue is 0xFF. The second byte is the priority of this queue (0x00 indicates the highest priority, and 0xFF (255) the lowest). The second byte is numbered by the ONT itself.

In either definition, the priority rank of the queues applies on a per-port or per-T-CONT basis. Congestion on one port or T-CONT will not block traffic being delivered to other ports or T-CONTs. (R) (mandatory) (2 bytes)

**Queue Configuration Option:** This attribute identifies the buffer-partitioning policy. The value of 0x01 means that all the queues share one buffer size of Maximum Queue Size and the value 0x00 means that each queue uses its individual buffer size of Maximum Queue Size. (R) (mandatory) (1 byte)

**Maximum Queue Size:** This attribute specifies the maximum size of the queue. (R) (mandatory) (2 bytes)

**Allocated Queue Size:** This attribute identifies the allocated size of this queue. (R, W) (mandatory) (2 bytes)

**Discard-cell-counter reset interval:** This attribute represents the interval in milliseconds at which the counter resets itself. (R, W) (optional) (2 bytes)

**Threshold value for discarded cells due to buffer overflow:** The threshold for the number of cells discarded on this queue due to buffer overflow. (R, W) (optional) (2 bytes)

**Back Pressure Operation:** This attribute is used to activate (enable: value 0x00) or deactivate (disable: value 0x01) the functions of Back Pressure operation. Default value is 0x00. (R, W) (mandatory if Back Pressure supported) (2 bytes)

**Back Pressure Time:** This attribute indicates the time duration in which the customer terminal temporarily suspends sending data. This attribute presents the duration in microseconds. This attribute can be used as a pause time for Ether UNI. Values: 0x00000000 to 0xFFFFFFFF. Upon autonomous instantiation, the value 0x00000000 is used. (R, W) (mandatory if Back Pressure supported) (4 bytes)

**Back Pressure occur Queue Threshold:** This attribute identifies the threshold size of this queue to start sending Back Pressure signal. (R, W) (mandatory if Back Pressure supported) (2 bytes)

**Back Pressure clear Queue Threshold:** This attribute identifies the threshold size of this queue to stop sending Back Pressure signal. (R, W) (mandatory if Back Pressure supported) (2 bytes)

**T-CONT buffer pointer:** This attribute represents the T-CONT buffer instance that is directly associated with this priority queue. Upon autonomous instantiation this attribute consists of the 0x8000, 0x8100 or 0xYY00. 0xYY is the first byte of this Managed Entity id. (The default value should be decided in consideration of the backward compatibility.) It is used when this priority



queue is contained by a T-CONT buffer directly, this pointer is null (0x0000) otherwise. (R, W) (mandatory if DBA supported) (2 bytes)

**Traffic Scheduler pointer:** This attribute represents the Traffic Scheduler instance that is directly associated with this priority queue. Upon autonomous instantiation this attribute is null (0x0000). This pointer is used when this priority queue is connected with a Traffic Scheduler. (R, W) (mandatory if DBA supported) (2 bytes)

**Weight:** This attribute represents weight for WRR. This weight is used by the Traffic Scheduler or T-CONT buffer (whose Policy is WRR) indicated by the Traffic Scheduler pointer or T-CONT buffer pointer, if present. Upon autonomous instantiation this attribute consists of the 0x01. (R, W) (mandatory if DBA supported) (1 byte)

#### Actions

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### Notifications

**Attribute Value Change:** This notification is used to report autonomous changes to the attributes of this managed entity. The notification shall identify the attribute that changed and its new value.

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) has been detected or cleared. Both ONT and OLT should know the event coding used by this entity. The event list for this entity is given in Table 43.

**Table 43/G.983.2 – Alarm list for Priority Queue<sub>B-PON</sub>**

Number	Alarm	Description
	<b>Threshold Crossing Alert</b>	
0	Cell loss	Exceeds threshold
1-223	Reserved	
224-239	Vendor-specific alarms	Not to be standardized

### 7.5.2 Traffic descriptors

ATM transfer capabilities (ATCs) are defined in ITU-T Rec. I.371 [7]. These are Deterministic Bit Rate (DBR), Statistical Bit Rate (SBR), ATM Block Transfer with Delayed Transmission (ABT/DT), ATM Block Transfer with Immediate Transmission (ABT/IT), Available Bit Rate (ABR), and Guaranteed Frame Rate (GFR).

[B-9] has defined analogous Service Categories. These are Constant Bit Rate (CBR), Real-time Variable Bit Rate (rt-VBR), Non-Real-Time VBR (nrt-VBR), Unspecified Bit Rate (UBR), Available Bit Rate (ABR), and Guaranteed Frame Rate (GFR).

Both the ITU-T SBR ATC and the ATM Forum VBR service categories may be further subdivided into 3 categories. These are taken to be separate ATCs or Service Categories and are designated by adding the numeral 1, 2, or 3 to the VBR or SBR acronym. For VBR1 and SBR1, the cell loss ratio (CLR) performance objective is applied to the aggregate traffic in the connection. For VBR2 and SBR2, the CLR objectives are applied only to cells with the cell loss priority (CLP) bit set to 0x00, and there is no tagging of cells. For VBR3 and SBR3, the CLR objective is applied only to cells with the cell loss priority (CLP) bit set to 0x00, and there is tagging of cells.

The plausible approximate correspondence among ITU-T ATC and the service categories in [B-9] is shown in Table 44.

**Table 44/G.983.2 – Traffic descriptors**

ITU	[B-9]	Traffic descriptor in G.983.2
DBR [1]	CBR	CBR/DBR Traffic Descriptor
DBR [U]	UBR	UBR Traffic Descriptor
SBR1 [2]	VBR1	SBR1/VBR1 Traffic Descriptor
SBR2 [1]/[3]	VBR2	SBR2/VBR2 Traffic Descriptor
SBR3 [3]	VBR3	SBR3/VBR3 Traffic Descriptor
ABR	ABR	ABR Traffic Descriptor
GFR	GFR	GFR Traffic Descriptor
ABT/DT ABT/IT		ABT/DT/IT Traffic Descriptor

The attribute value units used in the Traffic Descriptors in the following clauses are identical to the ones defined in ITU-T Rec. I.751 [9]. See also References [12] and [7] for a full discussion of traffic attributes.

Note carefully that all the traffic descriptor managed entities in an ONT must have a unique number, regardless of type.

#### **7.5.2.1 DBR/CBR traffic descriptor**

This managed entity specifies traffic and QoS parameters for upstream DBR/CBR virtual path connections.

Instances of this managed entity are created and deleted by the OLT.

##### *Relationships*

Zero or more instances of this managed entity may be contained in an instance of an ONT<sub>B-PON</sub> managed entity.

Each instance of this entity may be related to zero or more instances of VP Network CTP<sub>B-PON</sub> entities through their pointer attribute: Traffic Descriptor Profile Pointer.

##### *Attributes*

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all the traffic descriptors regardless of type. (R, Set-by-create) (mandatory) (2 bytes)

**Service Category/ATC:** Value 0x00 is used for DBR/CBR. (R, Set-by-create) (mandatory) (1 byte)

**Peak Cell Rate:** Peak Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Cell Delay Variation Tolerance in relation to the PCR:** Cell Delay Variation Tolerance in relation to the PCR for the CLP = 0 + 1 traffic flow. Unit is in microseconds. (R, Set-by-Creat) (mandatory) (2 bytes)

**CLR:** Maximum permissible Cell Loss Ratio for the CLP = 0 + 1 traffic flow. (R, Set-by-create) (mandatory) (2 bytes)

##### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

#### *Notifications*

None.

### **7.5.2.2 UBR traffic descriptor**

This managed entity specifies traffic and QoS parameters for upstream UBR virtual path connections.

Instances of this managed entity are created and deleted by the OLT.

#### *Relationships*

Zero or more instances of this managed entity may be contained in an instance of an ONT<sub>B-PON</sub> managed entity.

Each instance of this entity may be related to zero or more instances of VP Network CTP<sub>B-PON</sub> entities through their pointer attribute: Traffic Descriptor Profile Pointer.

#### *Attributes*

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all the traffic descriptors regardless of type. (R, Set-by-create) (mandatory) (2 bytes)

**Service Category/ATC:** Value 0x01 is used for UBR/DBR[U]. (R, Set-by-create) (mandatory) (1 byte)

**Peak Cell Rate:** Peak Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Cell Delay Variation Tolerance in relation to the PCR:** Cell Delay Variation Tolerance in relation to the PCR for the CLP = 0 + 1 traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**FrameDiscard:** This boolean attribute allows the indication of frame-aware handling. If set to 'false', no special handling is requested. If set to 'true', then the ONU is requested to treat data for this connection as frames (e.g., AAL 5 CPCS\_PDUs) rather than as individual cells. The treatment must be on a per-VC basis. While the precise implementation is equipment-specific, this treatment may for example involve discarding entire frames during congestion, rather than a few cells from many frames. (R, W, Set-by-create) (optional) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

#### *Notifications*

None.

### **7.5.2.3 SBR1/VBR1 traffic descriptor**

This managed entity specifies traffic and QoS parameters for upstream SBR1/VBR1 virtual path connections.

Instances of this managed entity are created and deleted by the OLT.

### *Relationships*

Zero or more instances of this managed entity may be contained in an instance of an ONT<sub>B-PON</sub> managed entity.

Each instance of this entity may be related to zero or more instances of VP Network CTP<sub>B-PON</sub> entities through their pointer attribute: Traffic Descriptor Profile Pointer.

### *Attributes*

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all the traffic descriptors regardless of type. (R, Set-by-create) (mandatory) (2 bytes)

**Service Category/ATC:** Value 0x02 is used for SBR1, value 0x03 is used for Real-time VBR1, and value 0x04 is used for Non Real-time VBR1. (R, Set-by-create) (mandatory) (1 byte)

**Peak Cell Rate:** Peak Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Sustainable Cell Rate:** Sustainable Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Maximum Burst Size:** Maximum Burst Size for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells. (R, Set-by-create) (mandatory) (2 bytes)

**Cell Delay Variation Tolerance in relation to the PCR:** Cell Delay Variation Tolerance in relation to the PCR for the CLP = 0 + 1 traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**Cell Delay Variation Tolerance in relation to the SCR:** Cell Delay Variation Tolerance in relation to the SCR for the CLP = 0 + 1 traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**CLR:** Maximum permissible Cell Loss Ratio for the CLP = 0 + 1 traffic flow. (R, Set-by-create) (mandatory) (2 bytes)

**FrameDiscard:** This boolean attribute allows the indication of frame-aware handling. If set to 'false', no special handling is requested. If set to 'true', then the ONU is requested to treat data for this connection as frames (e.g., AAL 5 CPCS\_PDUs) rather than as individual cells. The treatment must be on a per-VC basis. While the precise implementation is equipment-specific, this treatment may for example involve discarding entire frames during congestion, rather than a few cells from many frames. (R, W, Set-by-create) (optional) (1 byte)

### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

### *Notifications*

None.

#### **7.5.2.4 SBR2/VBR2 traffic descriptor**

This managed entity specifies traffic and QoS parameters for upstream SBR2/VBR2 virtual path connections.

Instances of this managed entity are created and deleted by the OLT.

## Relationships

Zero or more instances of this managed entity may be contained in an instance of an ONT<sub>B-PON</sub> managed entity.

Each instance of this entity may be related to zero or more instances of VP Network CTP<sub>B-PON</sub> entities through their pointer attribute: Traffic Descriptor Profile Pointer.

## Attributes

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all the traffic descriptors regardless of type. (R, Set-by-create) (mandatory) (2 bytes)

**Service Category/ATC:** Value 0x05 is used for SBR2, value 0x06 is used for real-time VBR2, and value 0x07 is used for non-real-time VBR2. (R, Set-by-create) (mandatory) (1 byte)

**Peak Cell Rate:** Peak Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Sustainable Cell Rate:** Sustainable Cell Rate for the CLP = 0 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Maximum Burst Size:** Maximum Burst Size for the CLP = 0 traffic flow. Unit is an integer number of cells. (R, Set-by-create) (mandatory) (2 bytes)

**Cell Delay Variation Tolerance in relation to the PCR:** Cell Delay Variation Tolerance in relation to the PCR for the CLP = 0 + 1 traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**Cell Delay Variation Tolerance in relation to the SCR:** Cell Delay Variation Tolerance in relation to the SCR for the CLP = 0 traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**CLR:** Maximum permissible Cell Loss Ratio for the CLP = 0 traffic flow. (R, Set-by-create) (mandatory) (2 bytes)

**FrameDiscard:** This boolean attribute allows the indication of frame-aware handling. If set to 'false', no special handling is requested. If set to 'true', then the ONU is requested to treat data for this connection as frames (e.g., AAL 5 CPCS\_PDUs) rather than as individual cells. The treatment must be on a per-VC basis. While the precise implementation is equipment-specific, this treatment may for example involve discarding entire frames during congestion, rather than a few cells from many frames. (R, W, Set-by-create) (optional) (1 byte)

## Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

## Notifications

None.

### 7.5.2.5 SBR3/VBR3 traffic descriptor

This managed entity specifies traffic and QoS parameters for upstream SBR3/VBR3 virtual path connections.

Instances of this managed entity are created and deleted by the OLT.

## Relationships

Zero or more instances of this managed entity may be contained in an instance of an ONT<sub>B-PON</sub> managed entity.

Each instance of this entity may be related to zero or more instances of VP Network CTP<sub>B-PON</sub> entities through their pointer attribute: Traffic Descriptor Profile Pointer.

## Attributes

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all the traffic descriptors regardless of type. (R, Set-by-create) (mandatory) (2 bytes)

**Service Category/ATC:** Value 0x08 is used for SBR3, value 0x09 is used for real-time VBR3, and value 0x0A is used for non-real-time VBR3. (R, Set-by-create) (mandatory) (1 byte)

**Peak Cell Rate:** Peak Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Sustainable Cell Rate:** Sustainable Cell Rate for the CLP = 0 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Maximum Burst Size:** Maximum Burst Size for the CLP = 0 traffic flow. Unit is an integer number of cells. (R, Set-by-create) (mandatory) (2 bytes)

**Cell Delay Variation Tolerance in relation to the PCR:** Cell Delay Variation Tolerance in relation to the PCR for the CLP = 0 + 1 traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**Cell Delay Variation Tolerance in relation to the SCR:** Cell Delay Variation Tolerance in relation to the SCR for the CLP = 0 traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**CLR:** Maximum permissible Cell Loss Ratio for the CLP = 0 traffic flow. (R, Set-by-create) (mandatory) (2 bytes)

**FrameDiscard:** This boolean attribute allows the indication of frame-aware handling. If set to 'false', no special handling is requested. If set to 'true', then the ONU is requested to treat data for this connection as frames (e.g., AAL 5 CPCS\_PDU's) rather than as individual cells. The treatment must be on a per-VC basis. While the precise implementation is equipment-specific, this treatment may for example involve discarding entire frames during congestion, rather than a few cells from many frames. (R, W, Set-by-create) (optional) (1 byte)

## Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

## Notifications

None.

### 7.5.2.6 ABR traffic descriptor

This managed entity specifies traffic and QoS parameters for upstream ABR virtual path connections.

Instances of this managed entity are created and deleted by the OLT.

## Relationships

Zero or more instances of this managed entity may be contained in an instance of an  $\text{ONT}_{\text{B-PON}}$  managed entity.

Each instance of this entity may be related to zero or more instances of VP Network  $\text{CTP}_{\text{B-PON}}$  managed entities through their pointer attribute: Traffic Descriptor Profile Pointer.

## Attributes

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all the traffic descriptors regardless of type. (R, Set-by-create) (mandatory) (2 bytes)

**Service Category/ATC:** Value 0x0B is used for ABR. (R, Set-by-create) (mandatory) (1 byte)

**Peak Cell Rate:** Peak Cell Rate for the  $\text{CLP} = 0$  traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Cell Delay Variation Tolerance in relation to the PCR:** Cell Delay Variation Tolerance in relation to the PCR for the  $\text{CLP} = 0$  traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**Minimum Cell Rate:** Minimum Cell Rate for the  $\text{CLP} = 0$  traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Initial Cell Rate:** Rate at which a source should send initially and after an idle period. The unit is an integer number of cells/second. The value must not exceed PCR and is usually lower. (R, Set-by-create) (optional) (4 bytes)

**Transient Buffer Exposure:** These parameters are required for ABR traffic. (R, Set-by-create) (optional) (2 bytes)

**Rate Decrease Factor:** Controls the rate decrease that occurs when backward RM cells with  $\text{CI} = 1$  are received. Allowed values are  $1/2^k$ , with  $k$  between 0 and 15. The coding of the attribute is according to the value of  $k$ . (R, Set-by-create) (optional) (1 byte)

**Rate Increase Factor:** Controls the rate increase that occurs when a backward RM cell is received with  $\text{CI} = 0$  and  $\text{NI} = 0$ . Allowed values are  $1/2^k$ , with  $k$  between 0 and 15. The coding of the attribute is according to the value of  $k$ . (R, Set-by-create) (optional) (1 byte)

**Fixed Round Trip Time:** The sum of the fixed and propagation delays (in ms) from the source to the destination and back. (R, Set-by-create) (optional) (2 bytes)

**Number RM:** The maximum number of data cells a source may send for each forward RM cell. Allowed values are  $2^k$ , where  $k$  is used as the code and is between 1 and 8. (R, Set-by-create) (optional) (1 byte)

**Time RM:** Upper bound on the time (in ms) between forward RM cells for an active source. Allowed values are computed as  $100/2^k$ , where  $k$  is used as the code and is between 0 and 7. The default is  $k = 0$ . (R, Set-by-create) (optional) (1 byte)

**Cut-off Decrease Factor:** Controls the rate decreases associated with lost or delayed backward RM cells. Allowed values are:  $1/2^6$  (value 0x07),  $1/2^5$  (value 0x06),  $1/2^4$  (value 0x05),  $1/2^3$  (value 0x04),  $1/2^2$  (value 0x03),  $1/2$  (value 0x02), 0x01 (value 0x01) and 0x00 (value 0). (R, Set-by-create) (optional) (1 byte)

**ACR Decrease Time Factor:** Time permitted between sending RM cells before the rate decreases to ICR. The range is from 10 ms to 10.23 s in increments of milliseconds. (R, Set-by-create) (optional) (2 bytes)

**FrameDiscard:** This boolean attribute allows the indication of frame-aware handling. If set to 'false', no special handling is requested. If set to 'true', then the ONU is requested to treat data for this connection as frames (e.g., AAL 5 CPCS\_PDUs) rather than as individual cells. The treatment must be on a per-VC basis. While the precise implementation is equipment-specific, this treatment may for example involve discarding entire frames during congestion, rather than a few cells from many frames. (R, W, Set-by-create) (optional) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

#### *Notifications*

None.

### **7.5.2.7 ABT/DT/IT traffic descriptor**

This managed entity specifies traffic and QoS parameters for upstream ABT/DT/IT virtual path connections.

Instances of this managed entity are created and deleted by the OLT.

#### *Relationships*

Zero or more instances of this managed entity may be contained in an instance of an ONT<sub>B-PON</sub> managed entity.

Each instance of this entity may be related to zero or more instances of VP Network CTP<sub>B-PON</sub> managed entities through its pointer attribute: Traffic Descriptor Profile Pointer.

#### *Attributes*

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all the traffic descriptors regardless of type. (R, Set-by-create) (mandatory) (2 bytes)

**Service Category/ATC:** Value 0x0C is used for ABT/DT; value 0x0D is used for ABT/IT. (R, Set-by-create) (mandatory) (1 byte)

**Peak Cell Rate:** Peak Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Sustainable Cell Rate:** Sustainable Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (optional) (4 bytes)

**Maximum Burst Size:** Maximum Burst Size for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells. (R, Set-by-create) (optional) (2 bytes)

**Cell Delay Variation Tolerance in relation to the PCR:** Cell Delay Variation Tolerance in relation to the PCR for the CLP = 0 + 1 traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**Cell Delay Variation Tolerance in relation to the SCR:** Cell Delay Variation Tolerance in relation to the SCR for the CLP = 0 + 1 traffic flow. Unit is in microseconds. (R, Set-by-create) (optional) (2 bytes)

**Number RM:** The maximum number of data cells a source may send for each forward RM cell. Allowed values are  $2^k$ , where k is used as the code and is between 0x01 and 0x08. (R, Set-by-create) (optional) (1 byte)



**Time RM:** Upper bound on the time between forward RM cells for an active source. Allowed values are computed as  $100/2^k$ , where  $k$  is used as the code and is between 0x00 and 0x07. The default is  $k = 0$ . (R, Set-by-create) (optional) (1 byte)

**FrameDiscard:** This boolean attribute allows the indication of frame-aware handling. If set to 'false', no special handling is requested. If set to 'true', then the ONU is requested to treat data for this connection as frames (e.g., AAL 5 CPCS\_PDUs) rather than as individual cells. The treatment must be on a per-VC basis. While the precise implementation is equipment-specific, this treatment may for example involve discarding entire frames during congestion, rather than a few cells from many frames. (R, W, Set-by-create) (optional) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

#### *Notifications*

None.

### **7.5.2.8 GFR traffic descriptor**

This managed entity specifies traffic and QoS parameters for upstream GFR virtual path connections.

Instances of this managed entity are created and deleted by the OLT.

#### *Relationships*

Zero or more instances of this managed entity may be contained in an instance of an ONT<sub>B-PON</sub> managed entity.

Each instance of this entity may be related to zero or more instances of VP Network CTP<sub>B-PON</sub> managed entities through their pointer attribute: Traffic Descriptor Profile Pointer.

#### *Attributes*

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all the traffic descriptors regardless of type. (R, Set-by-create) (mandatory) (2 bytes)

**Service Category/ATC:** Value 0x0E is used for GFR. (R, Set-by-create) (mandatory) (1 byte)

**Peak Cell Rate:** Peak Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Sustainable Cell Rate:** Sustainable Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (optional) (4 bytes)

**Maximum Burst Size:** Maximum Burst Size for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells. (R, Set-by-create) (optional) (2 bytes)

**Cell Delay Variation Tolerance in relation to the PCR:** Cell Delay Variation Tolerance in relation to the PCR for the CLP = 0 + 1 traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**Cell Delay Variation Tolerance in relation to the SCR:** Cell Delay Variation Tolerance in relation to the SCR for the CLP = 0 traffic flow. Unit is in microseconds. (R, Set-by-create) (optional) (2 bytes)

**Maximum Frame size:** Maximum Frame size for GFR traffic. Unit is an integer number of cells. (R, Set-by-create) (optional) (2 bytes)

**Minimum Cell Rate:** Minimum Cell Rate for the CLP = 0 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**FrameDiscard:** This boolean attribute allows the indication of frame-aware handling. If set to 'false', no special handling is requested. If set to 'true', then the ONU is requested to treat data for this connection as frames (e.g., AAL 5 CPCS\_PDUs) rather than as individual cells. The treatment must be on a per-VC basis. While the precise implementation is equipment-specific, this treatment may for example involve discarding entire frames during congestion, rather than a few cells from many frames. (R, W, Set-by-create) (optional) (1 byte)

#### *Actions*

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

#### *Notifications*

None.

### **7.5.2.9 UBR+ traffic descriptor**

This managed entity specifies traffic and QoS parameters for upstream UBR+ virtual path connections. Instances of this managed entity are created and deleted by the OLT.

#### *Relationships*

Zero or more instances of this managed entity may be contained in an instance of an ONT<sub>B-PON</sub> managed entity. Each instance of this entity may be related to zero or more instances of VP Network CTP<sub>B-PON</sub> managed entities through their pointer attribute: Traffic Descriptor Profile Pointer.

#### *Attributes*

**Managed Entity id:** This attribute provides a number for each instance of this managed entity that is unique over all the traffic descriptors regardless of type. (R, Set-by-create) (mandatory) (2 bytes)

**Service Category/ATC:** Value 0x0F is used for UBR+ [U]. (R, Set-by-create) (mandatory) (1 byte)

**Peak Cell Rate:** Peak Cell Rate for the CLP = 0 + 1 traffic flow. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Minimum Cell Rate:** Minimum guaranteed cell rate. Unit is an integer number of cells/second. (R, Set-by-create) (mandatory) (4 bytes)

**Cell Delay Variation Tolerance in relation to the PCR:** Cell Delay Variation Tolerance in relation to the PCR for the CLP = 0 + 1 traffic flow. Unit is in microseconds. (R, Set-by-create) (mandatory) (2 bytes)

**FrameDiscard:** This boolean attribute allows the indication of frame-aware handling. If set to 'false', no special handling is requested. If set to 'true', then the ONU is requested to treat data for this connection as frames (e.g., AAL 5 CPCS\_PDUs) rather than as individual cells. The treatment must be on a per-VC basis. While the precise implementation is equipment-specific, this treatment may for example, involve discarding entire frames during congestion, rather than a few cells from many frames. (R, W, Set-by-create) (optional) (1 byte)

## Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

## Notifications

None.

### 7.5.3 This clause intentionally left blank

### 7.5.4 UPC Disagreement Monitoring History Data<sub>B-PON</sub>

An instance of this managed entity is used to collect and report the last completed 15-minute interval data associated with UPC Disagreement Monitoring functions performed by the ONT on individual VP Network CTP<sub>B-PON</sub> or VC Network CTP<sub>B-PON</sub> managed entities in ONT<sub>B-PON</sub>. The instances of this managed entity are created and deleted by the OLT.

## Relationships

One instance of this managed entity may exist for each instance of a VP Network CTP<sub>B-PON</sub> or VC Network CTP<sub>B-PON</sub> managed entity instantiated at the UNI side.

## Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. The assigned number is the same as the Managed Entity id of the corresponding VP Network CTP<sub>B-PON</sub> or VC Network CTP<sub>B-PON</sub>. (R, Set-by-create) (mandatory) (2 bytes)

**Interval End Time:** This attribute identifies the most recent finished 15-minute interval. It is a cyclic counter (modulo 0xFF (256)) that is incremented each time a new interval is finished and the actual counters are updated. The value of this attribute is 0x00 during the first 15-minute interval that starts with the reception of the "synchronize time" action. The value is 0x01 during the first period after this, and so on. If this managed entity is created after the reception of the "synchronize time" action, the value of this attribute set equal to the number of the last completed interval. The actual counters of this managed entity start counting directly. (R) (mandatory) (1 byte)

**Threshold Data<sub>B-PON</sub> id:** This attribute provides a pointer to an instance of the Threshold Data<sub>B-PON</sub> managed entity that contains the threshold values for the performance monitoring data collected by this managed entity. The value 0x0000 is interpreted as a Null pointer. (R, W, Set-by-create) (mandatory) (2 bytes)

**Discarded Cells due to UPC:** This attribute provides a raw, thresholded count of the number of discarded cells due to combined CLP = 0 and CLP = 1 UPC policing. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (2 bytes)

**Discarded CLP = 0 Cells due to UPC:** This attribute provides a raw, thresholded count of the number of discarded CLP = 0 cells due to CLP = 0 only UPC policing. This counter is only present if CLP = 0 traffic is separately policed. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (2 bytes)

**Tagged CLP = 0 Cells:** This attribute provides a raw, unthresholded count of the number of cells that have been tagged. If the actual counter saturates, it remains on its maximum value. Default value is 0x00. (R) (mandatory) (2 bytes)

**Successfully Passed Cells:** This attribute provides a raw, unthresholded count of the number of cells that have been passed by the combined CLP=0+1 UPC policing. (R) (mandatory) (5 bytes)

**Successfully Passed CLP = 0 Cells:** This attribute provides a raw, unthresholded count of the number of high priority cells that have been passed by the CLP=0 UPC policing. (R) (mandatory) (5 bytes)

#### Actions

**Create:** Create an instance of this managed entity.

**Delete:** Delete an instance of this managed entity.

**Get:** Get one or more attributes of this managed entity.

**Set:** Set one or more attributes of this managed entity.

**Get current data:** This action returns the *current* value of one or more actual counters associated with performance monitoring attributes and the value of the Interval End Time attribute representing the interval in which the request is made. The values in the specific counters are reset at the end of the interval.

NOTE – "Get" returns the statistical data stored in the attribute values; "Get current data" returns the real-time value of the actual counters associated with those attributes.

Support of this action is optional.

#### Notifications

**Threshold Crossing Alert:** This notification is used to notify the management system when a threshold crossing alert (TCA) is detected or cleared. The TCA change notification "on" will be sent at the crossing of the threshold; the TCA change notification "off" will be sent at the end of the 15-min period since that is when the counters are reset to 0x00. Both ONT and OLT should know the alarm list used by this entity, given in Table 45.

**Table 45/G.983.2 – Alarm list for UPC disagreement monitoring history data <sub>B-PON</sub>**

Number	Alarm	Description	Threshold data counter # (Note)
	<b>Threshold Crossing Alert</b>		
0	Discarded Cells due to UPC	Exceeds threshold	1
1	Discarded CLP = 0 Cells due to UPC	Exceeds threshold	2
2-223	Reserved		
224-239	Vendor-specific alarms	Not to be standardized	
NOTE – This numbering is used with the associated Threshold Data <sub>B-PON</sub> managed entity. Threshold Data counter 1 indicates the 1st thresholded counter, etc.			

#### 7.5.5 Traffic scheduler

An instance of this managed entity represents a logical object of some Traffic Scheduler to control upstream ATM cells. A Traffic Scheduler can accommodate ATM cells after priority queue or other Traffic Scheduler and transfer ATM cells toward the next Traffic Scheduler or T-CONT buffer.

#### Relationships

Zero or more instances of this managed entity are contained in an instance of the ONT managed entity.

#### Attributes

**Managed Entity id:** This attribute provides a unique number for each instance of this managed entity. This 2-byte number is associated with the physical capability that realizes the Traffic

Scheduler. The first byte is the slot id of the PON IF card with which this Traffic Scheduler is associated. For integrated PON IF interfaces, this byte can be associated with "pseudo" slot id 0x80 (128). If the ONT has Traffic Schedulers that are not associated with the PON IF card at the creation of this instance, the first byte of this Traffic Scheduler is 0xFF. The second byte is the Traffic Scheduler id that is numbered by the ONT itself. The Traffic Scheduler id is numbered in ascending order with the range of 0x00 to 0xFF in each PON-IF Line Card or ONT core. (R) (mandatory) (2 bytes)

**T-CONT Buffer pointer:** This attribute represents the T-CONT Buffer instance that is directly associated with this Traffic Scheduler. Upon autonomous instantiation this attribute consists of the 0x8000, 0x8100 or 0xYY00. 0xYY is the first byte of this Managed Entity ID. (The default value should be decided in consideration of the backward compatibility.) This pointer is used when this Traffic Scheduler is contained by the T-CONT buffer directly, it is null (0x0000) otherwise. (R) (mandatory) (2 bytes)

**Traffic Scheduler pointer:** This attribute represents the Traffic Scheduler instance that serves this Traffic Scheduler. Upon autonomous instantiation this attribute is null (0x0000). This pointer is used when this Traffic Scheduler is connected to the another Traffic Scheduler, it is null otherwise. (The default value should be decided in consideration of the backward compatibility.) (R) (mandatory) (2 bytes)

**Policy:** This attribute represents scheduling policy. Valid values include but are not limited to "Null"(value 0x00), "HOL"(value 0x01) or "WRR"(value 0x02). Upon autonomous instantiation this attribute consists of the 0x00. (R) (mandatory) (1 byte)

**Priority/Weight:** This attribute represents priority for HOL scheduling or the weight for WRR scheduling. This value is used by the T-CONT buffer or Traffic Scheduler indicated by the T-CONT buffer pointer or Traffic Scheduler pointer. If the indicated pointer has Policy = HOL, then this value is interpreted as a priority (0x00 indicates the highest priority, and 0xFF (255) the lowest). If the indicated pointer has Policy = WRR, then this value is interpreted as a weight. Upon autonomous instantiation this attribute consists of the 0x00. (R, W) (mandatory) (1 byte)

#### *Actions*

**Get:** Get one or more attributes.

**Set:** Set one or more attributes.

#### *Notifications*

**Attribute Value Change:** This notification is used to report autonomous changes of attributes of this managed entity. The notification shall identify its new value.

## **8 ONT Management and Control Channel (OMCC)**

An ATM connection shall be provisioned for the OMCC. ITU-T Rec. G.983.1 [3] specifies a PLOAM message that activates a VPI/VCI pair between the OLT and ONT processors. The VPI/VCI value for the management channel of each is programmed by the OLT using this message. The OMCCs of different ONTs should be assigned different VPIs. A grant flow must be allocated by the MAC layer of the OLT for upstream OMCC traffic of each ONT.

The following performance requirements related to the OMCC should be studied further with input from operators:

- a) The cells carrying ONT management messages should be sent with cell loss priority CLP = 0.
- b) The upstream traffic on each OMCC should not exceed x bandwidth, where x is based on the operator's requirement.

- c) An upstream OMCC cell should always be put in the high priority queue or be modelled with the CBR service category; the constraints on the downstream OMCC cells are out of the scope of the Recommendation as this is completely under control of the OLT.
- d) Message Response Time: The system should support response times that do not exceed 1 s for the high priority protocol handling messages and 3 s for the low priority protocol handling messages.

## 9 ONT management and control protocol

### 9.1 ONT management and control protocol cell format

#### 9.1.1 Introduction

Each ONT Management and Control Protocol packet is encapsulated directly in a single 53-byte ATM cell. The cell format is shown in Figure 41. The following clauses discuss the details.

ATM Header (5 bytes)	Transaction Correlation Identifier (2 bytes)	Message Type (1 byte)	Device Identifier (1 byte)	Message Identifier (3 bytes)	Message Contents (33 bytes)	AAL 5 Trailer (8 bytes)
-------------------------	---	--------------------------	-------------------------------	---------------------------------	--------------------------------	----------------------------

**Figure 41/G.983.2 – ONT management and control protocol cell format**

#### 9.1.2 ATM header

The header contains the VPI/VCI value of the OMCC for the addressed ONT (see clause 8).

The header PTI should equal 001. The CLP bit should equal 0.

The HEC should be calculated using the normal ATM CRC-8 polynomial.

#### 9.1.3 Transaction correlation identifier

The Transaction Correlation Identifier is used to associate a request message with its response message. For request messages, the OLT selects any transaction identifier. A response message carries the transaction identifier of the message to which it is responding. The transaction identifier of event messages is 0x0000.


As explained in 9.2 Message Flow Control and Error Recovery, the most significant bit of the Transaction Correlation Identifier is used to indicate the priority of the message. The following coding will be used: 0 = low priority, 1 = high priority. The OLT decides whether a command should be executed with low or high priority.

The mechanism that the OLT uses to assign the rest of the bits of the Transaction Correlation Identifier in an acknowledged command is not standardized and is left to the implementers.

However, since the Transaction Correlation Identifier is used to match a command from the OLT to the ONT with a response from the ONT to the OLT, some care is required in the choice of the Transaction Correlation Identifier. The OLT must assign the Transaction Correlation Identifier in such a way that, whenever it sends a command with a Transaction Correlation Identifier that has been used before in another command to the same ONT, it is guaranteed with sufficiently high probability that no response for the first command will be received.

#### 9.1.4 Message type

The Message Type field is subdivided into four parts. These are given in Figure 42.



**Figure 42/G.983.2 – Message type field subdivision**

The most significant bit, bit 8, is reserved for the destination bit (DB). In the OMCI this bit is always 0.

Bit 7, Acknowledge Request (AR), is used to indicate whether or not the message requires an acknowledgement. If an acknowledgement is expected, this bit is set to "1". If no acknowledgement is expected, the coding of this bit is "0". Note that "acknowledge" means a response to an action request, not an acknowledgement at the link layer.

Bit 6, Acknowledgement (AK), is used to indicate whether or not this message is an acknowledgement to an action request. If a message is an acknowledgement, this bit is set to "1". If the message is not a response, this bit is set to "0".

Bit 5 to bit 1, Message Type (MT), are used to indicate the message type. Codes 0 to 3 are reserved for future use. Codes 4 to 31 are used by this Recommendation. Table 46 lists the message types that are defined.

**Table 46/G.983.2 – OMCI message types**

MT	Type	Purpose	AK	Inc MIB data sync.
4	Create	Create a managed entity instance with its attributes	yes	yes
5	Create complete connection	Create an ATM VP Cross-Connection and two associated VP Network CTP <sub>B-PONS</sub> or create an ATM VC Cross-Connection and two associated VC Network CTP <sub>B-PONS</sub>	yes	yes
6	Delete	Delete a managed entity instance	yes	yes
7	Delete complete connection	Delete an ATM VP Cross-Connection and two associated VP Network CTP <sub>B-PONS</sub> or delete an ATM VC Cross-Connection and two associated VC Network CTP <sub>B-PONS</sub>	yes	yes
8	Set	Set one or more attributes of a managed entity	yes	yes
9	Get	Get one or more attributes of a managed entity	yes	no
10	Get complete connection	Get all attributes of an ATM VP Cross-Connection and the attributes of the associated VP Network CTP <sub>B-PONS</sub>	yes	no
11	Get all alarms	Latch the alarm statuses of all managed entities and reset the alarm message counter	yes	no
12	Get all alarms next	Get the alarm status of the next managed entity	yes	no
13	MIB upload	Latch the MIB	yes	no
14	MIB upload next	Get latched attributes of a managed entity instance	yes	no
15	MIB reset	Clear the MIB and reinitialize it to its default and reset the MIB data sync counter to 0	yes	no

**Table 46/G.983.2 – OMCI message types**

MT	Type	Purpose	AK	Inc MIB data sync.
16	Alarm	Notification of an alarm	no	no
17	Attribute value change	Notification of an autonomous attribute value change	no	no
18	Test	Request a test on a specific managed entity	yes	no
19	Start software download	Start a software download action	yes	yes
20	Download section	Download a section of a software image	yes/no	no
21	End software download	End of a software download action	yes	yes
22	Activate software	Activate the downloaded software image	yes	yes
23	Commit software	Commit the downloaded software image	yes	yes
24	Synchronize Time	Synchronize the time between OLT and ONT	yes	no
25	Reboot	Reboot ONT, Subscriber Line Card or PON IF Line Card	yes	no
26	Get next	Get the latched attribute values of the managed entity within the current snapshot	yes	no
27	Test result	Notification of test result that is initiated by "Test"	no	no
28	Get current data	Get current counter value associated with one or more attributes of a managed entity	yes	no
NOTE – The "Download section" action is only acknowledged for the last section within a window. See Appendix I.2.15.				

### 9.1.5 Device identifier

For systems based on ITU-T Rec. G.983.1 [3], this field is defined as 0x0A.

### 9.1.6 Message identifier

The message identifier consists of three bytes. The first, most significant, byte of the message identifier field is used to indicate which managed entity is the target of the action specified in the message type. The maximum number of possible managed entities is thus 256. The least significant two bytes of this message identifier field are used to identify the managed entity instance. The maximum number of instances per managed entity is thus 65 536.

Table 47 gives the managed entities and their class values in the OMCI. Depending on the managed entity, there will be only one (e.g., ONT<sub>B-PON</sub>) or several (e.g., VP Network CTP<sub>B-PON</sub>) instances.



**Table 47/G.983.2 – Managed entity identifiers**

Managed entity class value	Managed entity
1	ONT <sub>B-PON</sub>
2	ONT Data
3	PON IF Line Cardholder
4	PON IF Line Card
5	Subscriber Line Cardholder
6	Subscriber Line Card
7	Software Image
8	UNI <sub>B-PON</sub>
9	TC Adapter <sub>B-PON</sub>
10	Physical Path Termination Point ATM UNI
11	Physical Path Termination Point Ethernet UNI
12	Physical Path Termination Point CES UNI
13	Logical N × 64 kbit/s Sub-port Connection Termination Point
14	Interworking VCC Termination Point
15	AAL 1 Profile <sub>B-PON</sub>
16	AAL 5 Profile <sub>B-PON</sub>
17	AAL 1 Protocol Monitoring History Data <sub>B-PON</sub>
18	AAL 5 Protocol Monitoring History Data <sub>B-PON</sub>
19	AAL 2 Profile <sub>B-PON</sub>
20	(intentionally left blank)
21	CES Service Profile <sub>B-PON</sub>
22	(intentionally left blank)
23	CES Physical Interface Monitoring History Data
24	Ethernet Performance Monitoring History Data
25	VP Network CTP <sub>B-PON</sub>
26	ATM VP Cross-Connection
27	Priority Queue <sub>B-PON</sub>
28	DBR/CBR Traffic Descriptor
29	UBR Traffic Descriptor
30	SBR1/VBR1 Traffic Descriptor
31	SBR2/VBR2 Traffic Descriptor
32	SBR3/VBR3 Traffic Descriptor
33	ABR Traffic Descriptor
34	GFR Traffic Descriptor
35	ABT/DT/IT Traffic Descriptor
36	UPC Disagreement Monitoring History Data <sub>B-PON</sub>
37	(intentionally left blank)
38	ANI

**Table 47/G.983.2 – Managed entity identifiers**

<b>Managed entity class value</b>	<b>Managed entity</b>
39	PON TC Adapter
40	PON Physical Path Termination Point
41	TC Adapter Protocol Monitoring History Data
42	Threshold Data <sub>B-PON</sub>
43	Operator Specific
44	Vendor Specific
45	MAC Bridge Service Profile
46	MAC Bridge Configuration Data
47	MAC Bridge Port Configuration Data
48	MAC Bridge Port Designation Data
49	MAC Bridge Port Filter Table Data
50	MAC Bridge Port Bridge Table Data
51	MAC Bridge PM History Data
52	MAC Bridge Port PM History Data
53	Physical Path Termination Point POTS UNI
54	Voice CTP
55	Voice PM History Data
56	AAL 2 PVC Profile <sub>B-PON</sub>
57	AAL 2 CPS Protocol Monitoring History Data <sub>B-PON</sub>
58	Voice Service Profile AAL
59	LES Service Profile
60	AAL 2 SSCS Parameter Profile 1
61	AAL 2 SSCS Parameter Profile 2
62	VP PM History Data
63	Traffic Scheduler
64	T-CONT Buffer
65	UBR+ Traffic Descriptor
66	AAL 2 SSCS Protocol Monitoring History Data <sub>B-PON</sub>
67	IP Port Configuration Data
68	IP Router Service Profile
69	IP Router Configuration Data
70	IP Router PM History Data 1
71	IP Router PM History Data 2
72	ICMP PM History Data 1
73	ICMP PM History Data 2
74	IP Route Table
75	IP Static Routes
76	ARP Service Profile

**Table 47/G.983.2 – Managed entity identifiers**

<b>Managed entity class value</b>	<b>Managed entity</b>
77	ARP Configuration Data
78	VLAN Tagging Operation Configuration Data
79	MAC Bridge Port Filter Preassign Table
80	Physical Path Termination Point ISDN UNI
81	(Reserved for Physical Path Termination Point HPNA UNI)
82	Physical Path Termination Point Video UNI
83	Physical Path Termination Point LCT UNI
84	VLAN Tagging Filter Data
85	ONU <sub>B-PON</sub>
86	ATM VC Cross-Connection
87	VC Network CTP <sub>B-PON</sub>
88	VC PM History Data
89	Ethernet Performance Monitoring History Data 2
90	Physical Path Termination Point Video ANI
91	Physical Path Termination Point 802.11 UNI
92	802.11 Station Management data 1
93	802.11 Station Management data 2
94	802.11 General Purpose Object
95	802.11 MAC&PHY Operation and Antenna Data
96	802.11 Counters
97	802.11 PHY FHSS DSSS IR Tables
98	Physical Path Termination Point ADSL UNI Part 1
99	Physical Path Termination Point ADSL UNI Part 2
100	ADSL Line Inventory and Status Data Part 1
101	ADSL Line Inventory and Status Data Part 2
102	ADSL Channel Downstream Status Data
103	ADSL Channel Upstream Status Data
104	ADSL Line Configuration Profile Part 1
105	ADSL Line Configuration Profile Part 2
106	ADSL Line Configuration Profile Part 3
107	ADSL Channel Configuration Profile
108	ADSL Subcarrier Masking Downstream Profile
109	ADSL Subcarrier Masking Upstream Profile
110	ADSL Downstream PSD Mask Profile
111	ADSL Downstream RFI Bands Profile
112	ADSL ATU-C Performance Monitoring History Data
113	ADSL ATU-R Performance Monitoring History Data
114	ADSL ATU-C Channel Performance Monitoring History Data

**Table 47/G.983.2 – Managed entity identifiers**

Managed entity class value	Managed entity
115	ADSL ATU-R Channel Performance Monitoring History Data
116	TC Adaptor Performance Monitoring History Data ADSL
117	Physical Path Termination Point VDSL UNI
118	VDSL VTU-O Physical Data
119	VDSL VTU-R Physical Data
120	VDSL Channel Data
121	VDSL Line Configuration Profile
122	VDSL Channel Configuration Profile
123	VDSL Band Plan Configuration Profile
124	VDSL VTU-O Physical Interface Monitoring History Data
125	VDSL VTU-R Physical Interface Monitoring History Data
126	VDSL VTU-O Channel Performance Monitoring History Data
127	VDSL VTU-R Channel Performance Monitoring History Data
128	Video Return Path Service Profile
129	Video Return Path Statistics
130	802.1p mapper service profile
131	OLT <sub>B-PON</sub>
132	Multicast Interworking VCC Termination Point
133-239	Reserved for future standardization
240-255	Vendor-Specific Entities, not to be standardized

### 9.1.7 Message contents

The layout of the message contents field is message specific. The detailed layout of all messages is given in Appendix II.

### 9.1.8 AAL 5-trailer

The eight bytes of this field are used as follows:

- The CPCS-User-to-User-Indication (CPCS-UU) field is set to 0x00 at the transmitter and ignored at the receiver.
- The CPCS Common Part Indication (CPCS-CPI) field is set to 0x00 at the transmitter and ignored at the receiver.
- The length of the CPCS-SDU field is set to 0x0028.
- The 32-bit CRC is as specified in ITU-T Rec. I.363.5 [6].

### 9.1.9 OMCI protocol limitations

Due to the arrangement of the messages, the OMCI imposes limits on the size of the message payloads. Table 48 lists the important limits for both B-PON and G-PON usages of the OMCI. To enable re-use of managed entities over both B-PON and G-PON, it is important that all MEs are defined such that they fit into the G-PON limits.

**Table 48/G.983.2 – OMCI protocol limitations**

Item	Limited by	B-PON limit	G-PON limit
Total size of Set-by-Create Attributes (including ME ID)	Create	35	34
Size of (R) or (R,W) Simple Attribute	Get-Response	26	25
Size of (R) or (R,W) Table Entry	Set	31	30
Total size of a Get	Get-Response	26	25
Total size of a Get-current data	Get-Current Data Response	26	25

It is important that the OLT and ONT implementations take these limits into account. For example, it is very easy to form a 'get' command that asks the ONT to return more attributes than there is space in the Response message. Specifically, there is a known issue where the OLT and ONT may disagree on the maximum size limitation of the 'Get' response.

For the sake of maintaining backwards-compatibility, the behaviour when either the ONT or OLT utilizes a 30-byte message contents field is described:

Case 1. The OLT implements a maximum attribute space of 26 bytes, while the ONT implements a maximum attribute space of 30 bytes.

The OLT should not ask for attributes that exceed 26 bytes, so the ONT will just leave the extra space blank. Even in the case where the OLT asks for too many attributes, it will get an attribute mask that clarifies what is being sent and will ignore the attributes that extend beyond the 26 bytes.

Case 2. The OLT uses a maximum attribute space of 30 bytes, while the ONT uses a maximum attribute space of 26 bytes.

The OLT may ask for too many attributes, and the ONT can respond with however many attributes fit in its 26-byte attribute space. The OLT will get the appropriate attribute-present mask and will parse the attributes that were sent correctly. It will ask again later for those attributes that did not fit.

While this is the preferred behaviour, an alternate interpretation may be that the ONT would return a "parameter error" code when it receives a Get that does not fit in the Get Response. For the sake of interoperability, the expected behaviour between and OLT and ONT with different interpretations is provided below:

Case 1. The ONT reports a parameter error, and the OLT expects a partial list. If this happens, the OLT should react by simplifying its Get request. The ONT will then respond without an error.

Case 2. The ONT provides a partial list, while the OLT expects to get an error. The OLT will receive a normal message and will process it normally. The OLT should ask again for any attributes it did not get.

## **9.2 Message flow control and error recovery**


The flow control/error recovery procedures for message exchange over the OMCC are based upon a simplex acknowledged transaction stop-and-wait mechanism that can easily be extended to support concurrent execution of multiple transaction requests of different priority levels. These flow-control procedures ensure that a low level acknowledged transaction request transmitted from the OLT has been properly received and processed to completion by the ONT before the next message of the same priority level is sent by the OLT. The stop-and-wait protocol uses the transaction correlation identifier field, retry counter(s), and applicable transaction request timer(s) to control the message flow rate while relying upon a CRC calculation to verify the data integrity of all received messages.

A Transaction Request Timer  $T_i$  with expiration time  $T_{\max_i}$  is started when a transaction request message of priority level "i" is sent to an ONT and is stopped upon receipt of an error-free acknowledgement message containing the same transaction correlation id value. If a valid acknowledgement message is not received by the OLT after timer  $T_i$  expires, the OLT resends the original transaction request message.

A retransmitted acknowledged transaction request message carries the same correlation ID as the original message. Each time an acknowledged transaction request message is retransmitted by the OLT, the transmitter increments the Retry Counter  $R_i$  (the counter associated with priority level "i" acknowledged transaction requests). When a retry counter  $R_i$  (initialized to 0x00 upon start-up) reaches the maximum retry value,  $R_{\max_i}$ , the transmitter stops retransmitting the message and declares an OMCC link state error.


Note that these timers ( $T_i$ ) and retry counters ( $R_i$ ) are only maintained within the OLT controller and do not exist within the ONT. Furthermore, the default threshold values for timer expiration ( $T_{\max_i}$ ) and number of retries ( $R_{\max_i}$ ) are not subject to standardization. It is suggested that the default threshold values of both  $T_{\max}$  and  $R_{\max}$  be independently configurable for each priority level. The default value for  $T_{\max_1}$  (i.e., high priority threshold) should account for the typical message transmission delay plus the command message response time.

These flow control/error recovery procedures are illustrated in Figure 43 for a case where the OMCC link is not permanently broken. First the OLT sends an acknowledged transaction request (Message 1) with priority level 0. Subsequently (i.e., while Message 1 is still outstanding), the OLT issues an additional acknowledged transaction request (Message 2) with priority level 1. Both of these commands are received and executed with the associated response (acknowledgement messages) returned to the OLT by the ONT. The acknowledgement for Message 1 is received by the OLT in time, however the response to Message 2 is lost and never received. The OLT detects that something went wrong because timer  $T_1$  expires, and the OLT therefore retransmits the original command (Message 2). Note that the ONT detects that this retransmitted command is identical to the last received command (for priority level 1) and therefore does not re-execute it. The ONT simply retransmits the original response from the previous execution of Message 2, which reaches the OLT in time. Finally, the OLT sends an acknowledged transaction request (Message 3) with priority level 0, but the message itself gets lost and is never properly received by the ONT. After the associated timer ( $T_0$ ) expires, the OLT retransmits the command and now all goes well.



**Figure 43/G.983.2 – Concurrent message exchange with error recovery**

A case where the OMCC link is effectively broken (down) is shown in Figure 44.



**Figure 44/G.983.2 – OMCC link error detection**

### 9.3 OMCI handling within the ONT

#### 9.3.1 Prioritized protocol entities

This clause specifies the behaviour of the ONT more precisely than in the preceding clause with respect to the prioritized request mechanism of the OMCC.

Conceptually, the way the ONT handles the OMCC requests can be illustrated by referring to the dual priority level implementation example shown in Figure 45.


When the ONT receives an ATM cell via the VCC associated with the management channel, it shall calculate the CRC and compare it with the value found in the AAL 5 trailer. If the values do not match, the ONT shall discard the message. It is recommended that this event be logged by the ONT and possibly communicated to the OLT by some out-of-band mechanism but, as far as the protocol is concerned, the message is discarded silently.

Messages with a correct CRC are then placed into either of two distinct incoming FIFO-based message queues, according to the priority level (i.e., high or low) of the associated command. Note that the priority level of a given command is encoded using the most significant bit of the transaction correlation Identifier field. If the associated incoming message queue is already full, the ONT must simply discard the message. It is recommended that this event be logged by the ONT and possibly communicated to the OLT by some out-of-band mechanism but, as far as the protocol is concerned, the message is discarded silently.



There are two distinct incoming command processing protocol entities (one associated with each priority level) that are used to service messages sequentially from an independently associated incoming FIFO queue. Each of these protocol entities can execute concurrently. If a message is a one-way command (i.e., an unacknowledged command), the protocol entity will simply have the command executed. If a message is an acknowledged command, the protocol entity must first look at the Transaction Correlation Identifier. If it is not equal to the Transaction Correlation Identifier of the last executed command with the same priority level, the protocol entity will have the command executed and place the response/acknowledgement (with identical Transaction Correlation Identifier) in the outgoing FIFO queue of the same priority level. If the Transaction Correlation Identifier is equal to that of the last executed command with the same priority level (i.e., the case where the controller retransmits a command due to lack of proper acknowledgement), the protocol entity will not actually have the command executed but simply will place the response from the last execution of that command in the outgoing FIFO queue (i.e., resend the previous acknowledgement response). It is assumed that in both cases, the command processing protocol entity for a given priority level will block until there is room in the associated outgoing FIFO queue for the response message.

In the other direction, requests by the applications to send autonomous event notifications will simply result in the corresponding messages being directed to an event notification protocol entity for transmission to the OLT. The event notification protocol entity will forward these event notification messages to the low priority outgoing FIFO queue. In this case as well, the event notification protocol entity will block until there is room in the low priority outgoing FIFO queue to hold the notification message. The CRC generator will remove messages from the outgoing FIFO queues using a strict priority discipline (i.e., the low-priority queue will only be serviced when the high-priority queue is empty), generate a CRC, append a properly-formatted AAL 5 trailer to the cell payload, and transmit the message to the OLT.



**Figure 45/G.983.2 – Protocol entities within the ONT**

### 9.3.2 Restrictions on the actions in relation to the protocol entities

To reduce the complexity and the amount of memory necessary in the ONT, the OLT is not allowed to issue a MIB Upload or a Software Download of a certain priority level while a similar action in the other priority level is in progress.

## Annex A

### Transport of video return path service

#### A.1 Network overview

This Recommendation considers networks that use B-PON systems that include a video overlay. This system provides a bidirectional ATM transport service and a unidirectional video or data downstream broadcast or unicast service. If only broadcast video services are desired, then the only video transport required is the third wavelength, as shown in Figure A.1. The ONT converts the signals on the third wavelength to electrical signals on a coaxial output, suitable for video appliances such as televisions.




Figure A.1/G.983.2 – A B-PON with broadcast video only

In many cases, however, interactive video services are needed. In this case, the customer's video termination equipment (commonly referred to as a Set Top Box, or STB) needs connectivity back to the video control equipment in the central office. In the case of the B-PON system, this connectivity must be provided by the ONU and OLT. This scenario is depicted in Figure A.2. The connection begins in the STB, which transmits its information up the coaxial cables that connect it to the ONT. The ONT must receive this information, and adapt it to be carried on the B-PON in the form of an ATM connection. The OLT transports this connection through the network. At some point, the connection then terminates on the video control equipment.




Figure A.2/G.983.2 – A B-PON with interactive video services

Figure A.2 defines two interfaces that are important to interoperability. The STB-ONU interface is the first. This interface is defined by two standards: SCTE 55-1 and SCTE 55-2. These are peer standards that are mutually exclusive; that is, a system will run either one or the other, but not both at one time. Furthermore, each of these standards defines several grades of capability, one being chosen as the default (or basic practice). Clauses A.2 and A.4 clarify this interface for the purposes of providing the Video Return Path over B-PON.

The second important interface is the ONU-Network interface. This logical interface is an ATM connection that conducts the return path information back to the video equipment in the central office. The information must be formatted in a standardized way so that common control equipment can be used. The formatting depends on the particular return path interface being used. Clauses A.3 and A.5 define these formats.

Given the situation that there are two modes on both interfaces, it makes sense that the ONU has two modes of operation, denoted Mode 1 and Mode 2. Mode 1 corresponds to support of the SCTE 55-1 system, and Mode 2 corresponds to support of the SCTE 55-2 systems. The mode is set by the network operator during the initialization management of the video service.

## **A.2 Mode 1 STB-ONU Interface**

The STB-ONU interface, in this case, is based on that from the commonly deployed SCTE 55-1 standard. The 55-1 standard defines all the aspects of the interactive video control system, while the STB-ONU interface herein described is only concerned with the upstream transmission of data. Therefore, we specify below which sections and sub-sections are relevant to the definition of the STB-ONU interface.

Relevant sections of SCTE 55-1 that apply to the STB-ONU interface:

### **5.2 PHYSICAL LAYER FOR RETURN-PATH TRANSMISSION**

#### **5.2.1 Return-Path Modem Description – A general explanation, Required.**

#### **5.2.2 RF Return Path Packet Format – Specifies the format of the upstream packet, Required.**

Please note that the unique word specified in this section is given in standard QPSK notation, and not differential QPSK notation.

#### **5.2.3 RF Return-Path Forward Error Correction – Specifies the code used for the FEC bytes, Optional.**

Please note that while the FEC will be calculated by compliant STBs, the ONT's processing of the FEC is optional.

#### **5.2.4 RF Return-Path Randomizer – Specifies the randomizer used in the upstream packets, Required.**

Please note that the randomizer output is applied to the entire packet EXCEPT the unique word. Also, the programmable value of the randomizer seed to be used is given in the Video Return Path Service Profile Managed Entity.

#### **5.2.5 RF Return Path Modulator – Specifies the physical layer to be used, Required.**

Note that while the center frequency is specified to a wider range, in actual practice this frequency is limited from 8 to 12 MHz. Also, the DQPSK mode to be used is given in the Video Return Path Service Profile Managed Entity.

#### **5.2.6 RF Return-Path Demodulator Specification – Specifies the physical layer to be used, Required.**


All other sections of SCTE 55-1 are not relevant to the STB-ONT interface. In particular, the extended practice (section 5.3) is explicitly not supported.

### A.3 Mode 1 ONU-network interface

In mode 1, the ONU must forward the derandomized packet sequence field (1 byte) and the ATM data (53 bytes) intact to the video control system. The procedure to do this is:

- 1) Receive the DQPSK burst, and capture all 62 bytes of data and measure the power level of the burst relative to the nominal input power level for the receiver.
- 2) Exclusive OR the randomizer sequence with the received data.
- 3) (Optional) Calculate the FEC parity, compare with that received, and detect/correct errors. Discard cells that have uncorrectable errors.
- 4) Assemble the datagram to be forwarded, which is 56 bytes in length.
- 5) Encapsulate the datagram using AAL 5.
- 6) Forward the AAL 5 segments over an ATM Virtual Circuit allocated on the PON.

The structure of the incoming RF burst data and the outgoing ATM circuit data is shown in Figure A.3. The outgoing datagram is always 56 bytes in length, and is composed of a two byte Level Indication field, a one byte packet sequence field, and a 53 byte ATM data field. The unique word and FEC bytes are terminated in the ONU.



**Figure A.3/G.983.2 – The transformation of a 55-1 formatted burst into ATM datagrams**

The level indication field is formatted as: a1bb bbbb 0000 0000, where:

The bit 'a' is a detection indicator to be used if FEC is implemented in the ONT (if not, bit 'a' should be set to zero always), where:

a = 0 means burst was detected without errors;

a = 1 means a burst was detected with errors, but was corrected.

The '1' is a reserved bit.

The bits 'bbbbbb' are a power indication, containing the 2's complement representation of the measured power of this burst, in units of decibels relative to the nominal receive power of the equipment. For example, if the nominal receive power of the ONU is 10 dBmV, and a burst arrives with 17 dBmV, then bbbbbbb=000111. If the same ONU receives a 7 dBmV burst, then bbbbbbb=111101.

The "0000 0000" are all reserved bits.

The ATM VC that carries the video return path data can be configured to provide a UBR service. The cell rate of the service can be calculated from the latency requirements of the 55-1 protocol and equipment implementation. Practical implementations of this protocol have round trip delay tolerances on the order of 100 ms. After this time, the STB will begin to re-transmit its upstream cells. One of the contributors of the delay will be the cell transmission time, which in our case is double the inverse cell rate.

For example, if 20 ms is allocated for cell transmission time, then the cell rate for the video return path connection should be made  $2/20\text{ms} = 100$  cps.

To summarize, the ONU-Network interface is 56 byte payloads (as defined above) encapsulated in AAL 5, carried in an ATM VC.

#### **A.4 Mode 2 STB-ONU interface**

The STB-ONU interface in this case is based on that from the commonly deployed SCTE 55-2 standard. The 55-2 standard defines all the aspects of the interactive video control system, while the STB-ONU interface herein described is only concerned with the upstream transmission of data. Therefore, we specify below which sections and subsections are relevant to the definition of the STB-ONU interface.

Relevant sections of SCTE 55-2 that apply to the STB-ONU interface:

- 2.2 Upstream Physical Interface Specification – A general explanation of the system, Required.
- 2.2.1 Quaternary Phase Shift Keying (QPSK) – A description of the physical layer used, Required.
  - Grade A 256 kbit/s is optional
  - Grade B 1.544 Mbit/s is required
  - Grade C 3.088 Mbit/s is optional
- 2.2.2 Coaxial Cable Impedance – A physical layer parameter, Required.
- 2.2.3 Time Division Multiple Access (TDMA), Optional.
- 2.2.4 Contention Based Access, Required.


All other sections of SCTE 55-2 are not relevant to the STB-ONT interface.

#### **A.5 Mode 2 ONU-network interface**

In mode 2, the ONU forwards the de-randomized and re-addressed ATM cells (53 bytes) to the video control system. The procedure to do this is:

- 1) Receive the QPSK burst, and capture all 59 bytes of data.
- 2) Exclusive OR the randomizer sequence with the received data.
- 3) (Required) Calculate the FEC parity, compare with that received, and detect/correct errors. Discard cells that have uncorrectable errors.
- 4) Perform a virtual circuit merge on all connections coming from the subtending STBs. Note that this merging function requires the ONU to queue all cells in a subtending VC until the end-of-packet indication is received. This maintains AAL 5 user payload frame delineation.
- 5) Forward the merged AAL 5 segments over an ATM Virtual Circuit allocated on the PON.

The structure of the incoming RF burst data and the outgoing ATM circuit data is shown in Figure A.4. The outgoing datagram is a 53-byte ATM cell. The cells have undergone a VC merge. The unique word and FEC bytes are terminated in the ONU.



**Figure A.4/G.983.2 – The transformation of a 55-2 formatted burst into ATM datagrams**

The ATM VC that carries the video return path data can be configured to support the operator chosen QoS.

This method provides efficient bandwidth usage upstream since it maps the ATM payload from the STB onto the PON directly on a PON allocated VC.

To summarize, the ONU-Network interface is 53 byte cells, carrying AAL 5 encapsulated data, using a PON allocated ATM VC.

## Appendix I

### OMCI common mechanisms and services

This appendix describes the common mechanisms of the OMCI, e.g., the MIB resynchronization, and the OMCI services, e.g., the equipment management or connection management.

#### I.1 Common mechanisms

The common mechanisms consist of:

- a) MIB data sync increase.
- b) MIB audit and resynchronization.
- c) Alarm sequence number increase.
- d) Alarm audit and resynchronization.
- e) Get an attribute that is larger than the OMCI message contents field.
- f) Create an instance of a managed entity with an attribute that is larger than the OMCI message contents field.
- g) Reporting of test result.
- h) Alarm Reporting Control.

These common mechanisms will be explained by the use of scenario diagrams.

##### I.1.1 MIB data sync increase

The MIB at the OLT and the instances of the managed entities in the ONT have to be synchronized at all times. This clause describes the means for achieving this. The "tool" used for this is the MIB data sync attribute of the ONT Data managed entity.

The MIB data sync attribute is a global 8-bit *sequence number*. When auditing the MIB in the ONT, the OLT requests this sequence number. If this number coincides with the corresponding sequence number in the OLT, no further action is needed, as the two MIBs, in ONT and OLT, are thought to be identical. If there is a discrepancy, the OLT either:

- 1) downloads its copy (including the MIB data sync) of the MIB to the ONT, or
- 2) uploads the MIB of the ONT, compares it with its own MIB, sends the necessary commands to the ONT to correct the differences and downloads its sequence number.

The ONT will be audited with respect to its MIB in three cases:

- a) On loss and re-establishment of the OMCC.
- b) Periodically, based on the operator's requirements.
- c) On demand of the OpS.

On detecting a newly installed ONT, regardless of the sequence number of its MIB, the OLT will perform either a MIB audit followed by whatever modifications are required, or a MIB reset and ONT startup procedure (see I.2.1).

The MIB data sync counter will be incremented for the creation and deletion of managed entity instances that are the consequence of a command by the OLT. The MIB data sync counter will also be incremented for attribute value changes which are the consequence of a command by the OLT. The MIB data sync counter will be incremented once per executed command (see Figure I.1).

In contrast, the MIB data sync counter will not be incremented for autonomous creation and deletion of managed entity instances by the ONT itself. Neither will the MIB data sync counter be

incremented for autonomous changes to attributes of managed entities within the ONT (see Figure I.2).


The order in which the OLT and the ONT will update their MIBs and increment the MIB data sync is not imposed. However, both the OLT and the ONT must locally update the MIB and increment the MIB data sync as one atomic action.

When incremented, the sequence number that follows 255 is 1. 0x00 is reserved for the following cases:

- a) Default MIB with which the ONT left the factory.
- b) An ONT which after (re-) initialization cannot restore its MIB.


In other words, a sequence number of 0 indicates that the ONT's MIB is not well defined, and therefore requires audit/reconfiguration.

Note that no mechanisms exist to detect that an autonomous attribute value change notification has been lost. Therefore, the OLT must regularly read the values of the attributes that can change their values autonomously.



**Figure I.1/G.983.2 – Increment of MIB data sync at ONT and OLT under OLT command**






G.983.2\_Fl.2

**Figure I.2/G.983.2 – No increment of MIB data sync at ONT and OLT in case of autonomous attribute value changes**

## I.1.2 MIB audit and resynchronization

Figure I.3 shows the scenario diagram of the MIB audit and MIB resynchronization process.




G.983.2\_F1.3

Figure I.3/G.983.2 – Audit and MIB resynchronization

The OLT must issue as many MIBUploadNext requests as the number of instances given in the MIBUpload response. The maximum time between two MIBUploadNext requests is 1 minute. If the OLT does not send a MIBUploadNext request within this time after the previous MIBUploadNext request or after the MIBUpload start request, the ONT assumes the MIB upload to be terminated. The ONT can drop the copy of the MIB, and consider any MIBUploadNext requests to be out of range, as described in II.2.22.

### I.1.3 Alarm sequence number increase


The ONT informs the OLT of alarm status changes by sending alarm status change notifications. Note that these notifications are sent in unacknowledged messages that carry an eight-bit alarm sequence number for the benefit of the OLT to detect loss of alarm notifications (see Figure I.4 and I.1.4). After a restart of the ONT, the alarm sequence number is reset so that the first alarm notification sent by the ONT will have an alarm sequence number equal to 1. The alarm message sequence number is incremented for each alarm notification and wraps around from 255 to 1. Consequently, an alarm notification with sequence number 0x00 will never be sent.



**Figure I.4/G.983.2 – Increment of alarm sequence number at ONT and OLT**

### I.1.4 Alarm audit and resynchronization

When the OLT detects a gap in the received sequence, as shown in Figure I.5, it asks the ONT for an alarm status report by sending a "Get All Active Alarms" command. Obviously, this command is acknowledged by a response that contains the number of managed entity instances that have outstanding alarms. The OLT will request the alarm status of all these managed entities instances via the "Get All Alarms Next" command. The OLT will compare these alarm statuses of all these instances with its own and will notify the network manager of the changes. The alarm sequence number is reset by the ONT when it receives the "Get All Active Alarms" request.



G.983.2\_FI.5

Figure I.5/G.983.2 – Audit and alarm resynchronization

The OLT must issue as many GetAllAlarmsNext requests as the number of instances given in the GetAllAlarms start response. The maximum time between two GetAllAlarmsNext requests is

1 minute. If the OLT does not send a GetAllAlarmsNext request within this time after the previous GetAllAlarmsNext request or after the GetAllAlarms start request, the ONT assumes the alarm upload to be terminated. The ONT can drop the copy of the alarm table, and consider any GetAllAlarmsNext requests to be out of range, as described in II.2.18.

### I.1.5 Get an attribute that is larger than the OMCI message contents field

Figure I.5-a shows the scenario diagram when the OLT gets an attribute that is larger than the OMCI message contents field (see 9.1.9 for limitations). The OLT asks the ONT for the size of the attribute by sending a "Get" command. In the Get response, the ONT uses 4 bytes to indicate the size of the data. This implies that the Get response message is formatted as if the oversized attribute had a size of 4 bytes. Then, the OLT will request the attribute data from the ONT via the appropriate number of "Get next" commands. This scenario is used for the MAC Filter Table attribute of MAC Bridge Port Filter Table Data managed entity and the Bridge Table attribute of the MAC Bridge Port Bridge Table Data managed entity.





Figure I.5-a/G.983.2 – Get an attribute that is larger than the OMCI message field

The OLT must issue as many "Get next" requests as needed to accommodate the size of the data indicated in the Get response. The maximum time between two "Get next" requests is 1 minute. If the OLT does not send a "Get next" request within this time after the previous "Get next" request or after the Get start request, the ONT assumes the Get attribute command has been terminated and can drop the copy of the attribute, and consider any GetNext requests to be out of range, as described in II.2.44. In addition, the OLT should not initiate simultaneous multiple get-next processes to any one ONT.

### I.1.6 Create an instance of a managed entity with an attribute that is larger than the OMCI message contents field


Figure I.5-b shows the scenario diagram when the OLT creates an instance of a managed entity with an attribute that is larger than the OMCI message contents field (exactly 33 bytes). The OLT first creates an instance of the managed entity without attribute data by sending a "Create" command and then sets the attribute data by sending the appropriate number of "Set" commands. This scenario is useful for Threshold Data <sub>B-PON</sub> ME.



**Figure I.5-b/G.983.2 – Create an instance of a managed entity with an attribute that is larger than the OMCI message field**

### I.1.7 Report test result

Figure I.5-c shows the scenario diagram for when the OLT requests that the ONT perform a test. The OLT requests that the ONT starts testing by sending a "Test" command. This command is acknowledged by a "Test" response. Then, the ONT carries out the test. After the test is complete, the ONT reports the test result via a "Test result" notification message. This scenario is used for the "SelfTest" attribute of ONT<sub>B-PON</sub> managed entity or Subscriber Line Card managed entity. Moreover, this scenario may be useful for MLT tests or for additional tests that may be added in the future.



G.983.2\_FI.5-c

Figure I.5-c/G.983.2 – Reporting of test result

### I.1.8 Alarm reporting control

Alarm Reporting Control allows for the suppression of alarms from physical path termination points, under the control of the management system. A complete description of ARC from a generic viewpoint is given in Amendment 3 (2001)/M.3100. The OMCI provides for ARC functions using two attributes of the PPTP, 'ARC' and 'ARC Interval'. These two attributes are described below

ARC:

This attribute allows the activation of Alarm Reporting Control (ARC) for this PPTP. The attribute works in concert with the ARC\_interval attribute. A value of zero indicates disable, while a value of 1 indicates enable. The default value is disabled. When the ARC attribute is set to disabled, the PPTP is in the "ALM" state, as defined in Amendment 3 (2001)/M.3100. Alarms are reported normally in the ALM state. When the ARC attribute is set to enabled, then the PPTP is in the "NALM-QI" state, as defined in Amendment 3 (2001)/M.3100. Alarms are suppressed in this state.

The PPTP moves from the ALM state to the NALM-QI state when the OLT changes the ARC attribute to enabled. The PPTP moves from the NALM-QI state to the ALM state when either:

- 1) the PPTP is trouble free and the ARC\_interval timer expires; or
- 2) the ARC attribute is set to disable by the OLT.

If the ARC\_interval timer expires, the ONT will set the ARC attribute to disabled autonomously, and send an AVC to notify the OLT. Please refer to Amendment 3 (2001)/M.3100 for more extensive discussion of the behaviours of the state diagram.

Note that the ARC\_interval can assume normal timing values of 0 to 254 minutes. The value of 0 implies that a PPTP in the NALM-QI state will immediately transition to the ALM state upon detection of a problem-free state. An ARC\_interval value of 255 has the special meaning of 'infinity'. This value means that the timer shall never expire, and the PPTP will stay in the NALM-QI state until the OLT sets the ARC attribute to disabled. This behaviour is equivalent to the "NALM" state, which is another generic behaviour of the ARC function in Amendment 3 (2001)/M.3100.

Note that there is no support for the "NALM-TI" subfunction in the OMCI system. (R,W) (optional) (1 byte)

ARC\_interval:

This attribute defines the interval to be used with the ARC function for this PPTP. The values 0 through 254 give the duration in minutes for the NALM-QI timer. The special value 255 means that the timer never expires. The default value is zero. (R, W) (optional) (1 byte)

## **I.2 Common services**

The common services consist of:

- a) start-up phase of ONT;
- b) on demand subscriber line card provisioning;
- c) on demand subscriber line card de-provisioning;
- d) plug-and-play subscriber line card provisioning;
- e) plug-and-play subscriber line card de-provisioning;
- f) ATM VP Cross-Connection or ATM VC Cross-Connection set-up;
- g) ATM VP Cross-Connection or ATM VC Cross-Connection breakdown;
- h) software image download;
- i) software image changes;
- j) MAC bridge service connection set-up;
- k) MAC bridge service connection tear-down;
- l) Addition of entities to MAC Filter Table;
- m) Removal of entities from MAC Filter Table;
- n) Voice service connection set-up; and
- o) Voice service connection tear-down;
- p) IP Router service connection set-up;
- q) IP Router service connection tear-down;
- r) Addition of entities to IP Static Routes;
- s) Removal of entities from IP Static Routes;
- t) Structured/Unstructured CES service connection set-up (ATM mode);
- u) Structured/Unstructured CES service connection tear-down (ATM mode).

All the listed services will be explained by the use of scenario diagrams.

### **I.2.1 Start-up phase of ONT**

The start-up phase of an ONT, from the OMCI point of view, belongs to one of two cases:

- a) the ONT is "new" to the OLT; or
- b) the OLT already "saw" this ONT at this PON.



The details of start-up scenarios also vary for ONTs with different configuration options, e.g.,

- a) ONT with cardholders at both PON IF and UNI;
- b) ONT with integrated interfaces at both PON IF and UNI;
- c) ONT with cardholders at PON IF and integrated interfaces at UNI; and
- d) ONT with integrated interfaces at PON IF and cardholders at UNI.

Here the following scenarios will only show cases a) and b), from which the scenarios for cases c) and d) can be deduced.


NOTE – The preferred solution is that Subscriber Line Card and Subscriber Line Cardholder managed entities should always be modelled, regardless of whether or not the ONT has integrated interfaces.

Figure I.6 shows the start-up phase of a "new" ONT with Cardholders on both sides. Figure I.7 shows the start-up phase of a "new" ONT with integrated interfaces on both sides. Figure I.8 shows the start-up phase of an "old" ONT.


The behaviour of the ONT with respect to inserted Subscriber Line Cards during the start-up phase is not shown in the following figures. This behaviour is the subject of I.2.2.

Note that if attribute value changes do not arrive at the OLT, the OLT will not know the number of cardholders or integrated ports that reside in the ONT. The OLT can request the information of the newly created managed entity instances by a sequence of "Get" requests. If a "Get" request is issued on a non-existing instance, the response message to the OLT will indicate the error – Unknown managed entity instance.


In general, the AVCs shown in Figures I.6 and I.7 should be viewed as a partial method of ONT discovery. The OLT cannot rely on the receipt of AVCs to learn all ONT information, because not all managed entities or attributes issue AVCs, and because AVCs can be lost in transmission without an error being detected. Therefore, the OLT should audit any ONT immediately after a Reset is completed.




**Figure I.6/G.983.2 – Start-up of a "new" ONT with Cardholders on both sides**




**Figure I.6/G.983.2 – Start-up of a "new" ONT with Cardholders on both sides (continued)**




**Figure I.6/G.983.2 – Start-up of a "new" ONT with Cardholders on both sides (continued)**




**Figure I.6/G.983.2 – Start-up of a "new" ONT with Cardholders on both sides (*concluded*)**



**Figure I.7/G.983.2 – Start-up phase of a "new" ONT with integrated interfaces on both sides**



**Figure I.7/G.983.2 – Start-up phase of a "new" ONT with integrated interfaces on both sides (concluded)**



**Figure I.8/G.983.2 – Start-up phase of an "old" ONT**

### **I.2.2 Subscriber line card provisioning/deprovisioning**

The provisioning and deprovisioning of Subscriber Line Card can be triggered in two ways:

- a) On demand by the OpS;
- b) Plug-and-play, triggered by the detection of the card insertion/removal.

However, this trigger of provisioning and deprovisioning is transparent to the ONT, i.e., the ONT is always responding to OLT provisioning and deprovisioning commands. The difference between plug-and-play mode and on-demand mode would reside in the OLT. For the on-demand mode, the OLT will provision (deprovision) the presence of the subscriber line card in the ONT when it has been provisioned (deprovisioned) by the operator; for the plug-and-play mode, the OLT will provision the slot to "plug-and-play" and further provision (deprovision) the presence of the subscriber line card in the ONT as soon as it has received a notification from the ONT that a line card has been plugged in (out).

### **I.2.3 On-demand subscriber line card provisioning**

**NOTE** – It is possible to provision a subscriber line card while a subscriber line card of the same or of a different type is provisioned for the subscriber line cardholder. In case a subscriber line card of the same type is already provisioned, the provisioned command will have no effect. In case a subscriber line card of a different type is already provisioned, this subscriber line card will be automatically deprovisioned and only then will the system be configured according to the newly given plug-in unit type. Figure I.9 shows the scenario of provisioning an ATM LIM. Figure I.10 shows the scenario of provisioning a non-ATM LIM.

The cases below show the use of the attributes "Expected type" and "Sensed type" of the corresponding Physical Path Termination Point ATM/Ethernet/CES UNI.

#### **Case 1**

The subscriber linecard Holder or the ONT itself (the latter in case of integrated interfaces) only supports a specific type of interface. Notice that in the former case, the attribute "type" of the Subscriber Line Card managed entity will be equal to this type.

In this case, on creation of the Physical Path Termination Point managed entity instance, the attributes "Expected Plug-in Unit type" and "Actual Plug-in type" of the Subscriber Linecard Holder managed entity are both set equal to the specific interface type and the ONT sends attribute value change notifications to the OLT with the values of these attributes. It will not be possible for

the OLT to change the value of the attribute "Expected Plug-in Unit type" later on (i.e., any attempt by the OLT to change the value of the attribute will be refused by the ONT).

## Case 2


The subscriber linecard holder or the ONT itself (the latter in case of integrated interfaces) supports interfaces of different types.

In this case, on creation of the Physical Path Termination Point managed entity instance, the attribute "Expected Plug-in Unit type" is set to autosensing (0x00) and attribute "Actual Plug-in Unit type" is set to:

- inapplicable or unknown if the interface does not support autosensing or if the autosensing fails (actually, the coding is 0x00 in both cases);
- the sensed type if the interface supports autosensing and the autosensing was successful.

The ONT will send an attribute value change notification with the values of these attributes.


Later on, it will be possible for the OLT to change the value of attribute "Expected Plug-in Unit type" with the "Set" action. The value of attribute "Sensed type" will be set equal to the value of attribute "Expected type". Notice however that the ONT will only execute the "Set" action if the ONT supports the configured interface type.




G.983.2\_FI.9(A)

**Figure I.9/G.983.2 – ATM subscriber line card provisioning**






G.983.2\_F1.9(B)




G.983.2\_F1.9(C)

**Figure I.9/G.983.2 – ATM subscriber line card provisioning (concluded)**




G.983.2\_F1.10(A)



G.983.2\_F1.10(B)


**Figure I.10/G.983.2 – Non-ATM card subscriber line card provisioning**



**Figure I.10/G.983.2 – Non-ATM card subscriber line card provisioning (concluded)**

#### **I.2.4 On-demand subscriber line card deprovisioning**

The ONT will delete from the MIB all managed entities that it automatically created during the provisioning of this subscriber line card. On the other hand, the OLT will be responsible for deleting all those managed entities that are associated with this card and were created by the OLT. Figure I.11 shows the process of deprovisioning a Subscriber Line Card.




G.983.2\_FI.11

**Figure I.11/G.983.2 – Subscriber line card deprovisioning**

### I.2.5 Plug-and-play subscriber line card provisioning

A subscriber line cardholder can be provisioned for a plug-and-play mode of operation (see also Figure 32). Figure I.12 shows the scenario for provisioning a slot for plug-and-play.




**Figure I.12/G.983.2 – Plug-and-play subscriber line card provisioning**

Not shown in the scenario diagram given above are the notifications of the ONT due to incorrectly inserted subscriber line cards. Figure 32 is given for this purpose.

### I.2.6 Plug-and-play subscriber line card deprovisioning

When a subscriber line card is removed from a subscriber line cardholder, a notification will be send to the OLT. The OLT will deprovision the subscriber line cardholder upon receiving the notification (see Figure I.13).




**Figure I.13/G.983.2 – Plug-and-play subscriber line card deprovisioning**

## I.2.7 ATM service set-up

The ATM connections within the ONT can be created in two ways: one consists of consecutively requesting the creation of two VP Network CTP<sub>B-PONS</sub> and one ATM VP Cross-Connection (Figure I.14), whereas the other uses one request which will cause the simultaneous creation of two VP Network CTP<sub>B-PONS</sub> and one ATM VP Cross-Connection (Figure I.15).


In the given figures for ATM service set-up, the assumption is made that Priority Queues are used. If Traffic Descriptors are used, the Traffic Descriptor managed entity instance for the requested service must be created first. Also, the OLT might want to create corresponding History Data managed entities for the connection.

These descriptions can be extended for use with VC cross-connections as well. For ATM service set-up and tear-down using VC cross-connections, replace "VP Network CTP<sub>B-PONS</sub>" with "VC Network CTP<sub>B-PONS</sub>" and "ATM VP Cross-Connection" with "ATM VC Cross-Connection".



G.983.2\_FI.14

Figure I.14/G.983.2 – VP cross-connection set-up (alternative 1)




**Figure I.15/G.983.2 – VP cross-connection set-up (alternative 2)**


### I.2.8 ATM service tear-down

The connections within the ONT can be deleted in two ways: one consists of consecutive deletion of the ATM VP Cross-Connection and the two VP Network CTP<sub>B-PONS</sub> (Figure I.16), whereas the other uses one request to delete the ATM VP Cross-Connection and the two associated VP Network CTP<sub>B-PONS</sub> (Figure I.17). The correct order of the deletion of the instances in the first alternative is under the control of the OLT. If applicable, the OLT must delete the corresponding History Data managed entities as well.

These descriptions can be extended for use with VC cross-connections as well. For ATM service set-up and tear-down using VC cross-connections, replace "VP Network CTP<sub>B-PONS</sub>" with "VC Network CTP<sub>B-PONS</sub>" and "ATM VP Cross-Connection" with "ATM VC Cross-Connection".



**Figure I.16/G.983.2 – VP cross-connection deletion (alternative 1)**



**Figure I.17/G.983.2 – VP cross-connection deletion (alternative 2)**

### I.2.9 Structured CES service connection set-up


The following scenario of structured CES service connection set-up is given for an ONT with cross-connect functionality. For an ONT that does not model cross-connect functionality, the Interworking VCC Termination Point is directly associated with the VP/VC Network CTP<sub>B-PON</sub> on the ANI side.



Figure I.18 shows the set-up of the first structured CES service on a Subscriber Line Card. Additional services on the same UNI interface, with their Interworking VCC Termination Points, AAL 1 Profile<sub>B-PONS</sub> and CES Profile<sub>B-PONS</sub>, can also share the same VP/VC Network CTP<sub>B-PON</sub>.

Note that the AAL 1 and CES profiles can be shared among multiple Interworking VCC Termination Points. No creation of profiles is needed if the Interworking VCC Termination Point is pointing to an existing profile.

Also, the OLT might want to create corresponding History Data managed entities for the connection.




**Figure I.18/G.983.2 – Connection set-up of a structured CES**

### I.2.10 Structured CES service connection tear-down

The following scenario, shown in Figure I.19, of structured CES service connection tear-down is given for an ONT with cross-connect functionality. For an ONT that does not model cross-connect functionality, the Interworking VCC Termination Point is directly associated with the VP/VC Network CTP<sub>B-PON</sub> on the ANI side.

Note that the AAL 1 and CES profiles can be shared among multiple Interworking VCC Termination Points. If there are more Interworking VCC Termination Points associated with these profile managed entities, the OLT may not request to delete them. This holds also for the ATM connection used: if more Interworking VCC Termination Points are associated with this connection (i.e., VP/VC Network CTP<sub>B-PON</sub>), the ATM connection cannot be deleted.

If applicable, the OLT must delete the corresponding History Data managed entities as well.




**Figure I.19/G.983.2 – Connection tear-down of a structured CES**

### I.2.11 Unstructured CES service connection set-up

The following scenario, shown in Figure I.20, for unstructured CES service connection set-up, is given for an ONT with cross-connect functionality. For an ONT that does not model cross-connect functionality, the Interworking VCC Termination Point is directly associated with the VP/VC Network CTP<sub>B-PON</sub> on the ANI side.

Note that the AAL 1 and CES profiles can be shared among multiple Interworking VCC Termination Points. No creation of profiles is needed if the Interworking VCC Termination Point is pointing to an existing profile.

Also, the OLT might want to create corresponding History Data managed entities for the connection.




**Figure I.20/G.983.2 – Connection set-up of an unstructured CES**

### I.2.12 Unstructured CES service connection tear-down

The following scenario, shown in Figure I.21, for an unstructured CES service connection tear-down is given for an ONT with cross-connect functionality. For an ONT that does not model cross-connect functionality, the Interworking VCC Termination Point is directly associated with the VP/VC Network CTP<sub>B-PON</sub> on the ANI side.

Note that the AAL 1 and CES profiles can be shared among multiple Interworking VCC Termination Points. If there are more Interworking VCC Termination Points associated with these profile managed entities, the OLT may not request to delete them. This holds also for the ATM connection used: if more Interworking VCC Termination Points are associated with this connection (i.e., VP/VC Network CTP<sub>B-PON</sub>), the ATM connection cannot be deleted.

If applicable, the OLT must delete the corresponding History Data managed entities as well.



**Figure I.21/G.983.2 – Connection tear-down of an unstructured CES**

### **I.2.13 This clause intentionally left blank**

### **I.2.14 This clause intentionally left blank**

### **I.2.15 Software image download**


The download of a Software Image is based on a "segmented stop and wait" protocol; thus, the next segment can only be transmitted to the ONT if the previous segment is positively acknowledged. A Software Image segment (also named window) consists of one or more Software Image sections. Each section is transmitted in one OMCC message.

The number of sections in a segment is negotiated before the actual download. First the OLT proposes a segment size (not greater than 256). The ONT can propose a smaller segment size in the response. If the response indicates a smaller segment size, this is the size to be used in the download. Thus, an image segment consists of N image sections, with N being equal to the segment size. Only the last image section is acknowledged. If the ONT processed all sections of a segment properly, the acknowledgement will be positive, after which the OLT will download the next segment.

Note that the section numbering starts from 0 so that segments of precisely 8 kilobytes can be downloaded.

If an error occurred with a section of a segment (e.g., CRC error or missed section), the last section will be negatively acknowledged, which will result in an entire retransmission of the last segment.

When the last segment transferred is positively acknowledged, the OLT sends a CRC-32 to the ONT in the Software Image end download command. The ONT calculates the CRC-32 and compares it to the CRC received from the OLT. If they are equal, the image is considered valid. Figure I.22 gives the scenario for the software download.




G.983.2\_FI.22

Figure I.22/G.983.2 – Software download

## I.2.16 Software image activate and commit


See Figure I.23.



**Figure I.23/G.983.2 – Software activate (above) and software commit (below)**

## I.2.17 MAC bridge service connection set-up

Figure I.24 shows the scenario for MAC bridge service connection set-up for an ONT with cross-connect functionality. For an ONT that does not model cross-connect functionality, the Interworking VCC Termination Point is directly associated with the VP Network CTP<sub>B-PON</sub> on the ANI side. Note that the AAL 5 Profile<sub>B-PON</sub> can be shared among multiple Interworking VCC Termination Points. No creation of profiles is needed if the Interworking VCC Termination Point points to an existing profile. Also, the OLT may want to create corresponding History Data managed entities for the connection.




G.983.2\_F1.24

**Figure I.24/G.983.2 – Connection set-up for MAC bridge service connection**

### **I.2.18 MAC bridge service connection tear-down**

The following scenario, Figure I.25, depicts MAC bridge service connection tear-down for an ONT with cross-connect functionality. For an ONT that does not model cross-connect functionality, the Interworking VCC Termination Point is directly associated with the VP Network CTP<sub>B-PON</sub> on the ANI side. Note that the AAL 5 Profile<sub>B-PON</sub> can be shared among multiple Interworking VCC Termination Points. If there are more Interworking VCC Termination Points associated with this profile managed entity, the OLT may not request to delete it. This holds also for the ATM connection used: if more Interworking VCC Termination Points are associated to this connection (i.e., VP Network CTP<sub>B-PON</sub>), the ATM connection cannot be deleted. If applicable, the OLT must delete the corresponding History Data managed entities as well.





**Figure I.25/G.983.2 – Connection tear-down for MAC bridge service connection**

### I.2.19 Addition of entries on MAC filter table

The following scenario, Figure I.26, depicts addition of entries to the MAC Filter Table for an ONT.




Figure I.26/G.983.2 – Addition of entries to the MAC filter table

### I.2.20 Removal of entries from MAC filter table

The following scenario, Figure I.27, depicts the removal of entries from the MAC Filter Table for an ONT.





Figure I.27/G.983.2 – Removal of entries from MAC filter table

### **I.2.21 Voice over AAL 2 service connection set-up**

The following scenario, Figure I.28, depicts Voice over AAL 2 service connection set-up for an ONT with cross-connect functionality. For an ONT that does not model cross-connect functionality, the Interworking VCC Termination Point is directly associated with the VP Network CTP<sub>B-PON</sub> on the ANI side. Note that the Voice Service, LES Service, AAL 2 and AAL 2 PVC profiles can be shared among multiple Interworking VCC Termination Points. No creation of profiles is needed if the Interworking VCCTP points to an existing profile. Moreover, the SSCS Parameter1 and SSCS Parameter2 profiles can be shared among multiple AAL 2 Profile<sub>B-PONS</sub>, so no creation of profiles is needed if the AAL 2 Profile<sub>B-PON</sub> points to an existing profile. Also, the OLT may want to create corresponding History Data managed entities for the connection.




G.983.2\_F1.28

**Figure I.28/G.983.2 – Connection set-up for voice over AAL 2 service connection**

### **I.2.22 Voice over AAL 2 service connection tear-down**

The following scenario, Figure I.29, depicts the Voice over AAL 2 service connection tear-down for an ONT with cross-connect functionality. For an ONT that does not model cross-connect functionality, the Interworking VCC Termination Point is directly associated with the VP Network CTP<sub>B-PON</sub> on the ANI side. Note that the Voice Service, LES Service, AAL 2 and AAL 2 PVC profiles can be shared among multiple Interworking VCC Termination Points. If there are more Interworking VCC Termination Points associated with these profile managed entities, the OLT may not request to delete them. This holds also for the ATM connection used: if more Interworking VCC Termination Points are associated with this connection (i.e., VP Network CTP<sub>B-PON</sub>), the ATM connection cannot be deleted. Moreover, the SSCS Parameter1 and SSCS Parameter2 profiles can be shared among multiple AAL 2 Profiles<sub>B-PON</sub>. If there are more AAL 2 Profiles<sub>B-PON</sub> associated with these profile managed entities, the OLT may not request to delete them. If applicable, the OLT must delete the corresponding History Data managed entities as well.



G.983.2\_F1.29

**Figure I.29/G.983.2 – Voice over AAL 2 service connection tear-down**

### I.2.23 Voice over AAL 1 service connection set-up

The following scenario, Figure I.30, for Voice over AAL 1 service connection set-up is given for an ONT with cross-connect functionality. For an ONT that does not model cross-connect functionality, the Interworking VCC Termination Point is directly associated with the VP Network CTP<sub>B-PON</sub> on the ANI side.

Note that the Voice Service and AAL 1 profiles can be shared among multiple Interworking VCC Termination Points. No creation of profiles is needed if the Interworking VCC Termination Point is pointing to an existing profile. Also, the OLT might want to create corresponding History Data managed entities for the connection.





Figure I.30/G.983.2 – Connection set-up voice over AAL 1 service connection

### I.2.24 Voice over AAL 1 service connection tear-down

The following scenario, Figure I.31, for voice over AAL 1 service connection tear-down is given for an ONT with cross-connect functionality. For an ONT that does not model cross-connect functionality, the Interworking VCC Termination Point is directly associated with the VP Network CTP<sub>B-PON</sub> on the ANI side.

Note that the Voice Service and AAL 1 profiles can be shared among multiple Interworking VCC Termination Points. If there are more Interworking VCC Termination Points associated with these profile managed entities, the OLT may not request to delete them. This holds also for the ATM connection used: if more Interworking VCC Termination Points are associated with this connection (i.e., VP Network CTP<sub>B-PON</sub>), the ATM connection cannot be deleted. If applicable, the OLT must delete the corresponding History Data managed entities as well.



**Figure I.31/G.983.2 – Connection tear-down for Voice over AAL 1 service connection**




### **I.2.25 IP Router service connection set-up**

Figure I.32 shows the scenario for IP Router service connection set-up for an ONT with cross-connect functionality. For the case that an ONT does not model cross-connect function, the Interworking VCC Termination Point is directly associated to the VP Network CTP<sub>B-PON</sub> on the ANI side.

Note that the AAL 5 profile can be shared among multiple Interworking VCC Termination Points. No creation of profiles is needed if the Interworking VCCTP points to an existing profile. Moreover, the IP Router Service Profile and ARP Service Profile can be shared among multiple IP Port Configuration Data managed entities, so no creation of profiles is needed if the IP Port Configuration Data points to an existing profile.

The OLT also may want to create corresponding History Data managed entities for the connection.



G.983.2\_F1.32


**Figure I.32/G.983.2 – Connection set-up for IP router service connection**

### **I.2.26 IP router service connection tear-down**

The following scenario, Figure I.33, depicts IP router service connection tear-down for an ONT with cross-connect functionality. For the case that an ONT does not model cross-connect function, the Interworking VCC Termination Point is directly associated to the VP Network CTP<sub>B-PON</sub> on the ANI side.

Note that the AAL 5 profile can be shared among multiple Interworking VCC Termination Points. If there are more Interworking VCC Termination Points associated with this profile managed entity, the OLT may not request to delete it. This holds also for the ATM connection used: if more Interworking VCC Termination Points are associated to this connection (i.e., VP Network CTP<sub>B-PON</sub>), the ATM connection cannot be deleted. Moreover, the IP Router Service Profile and ARP Service Profile can be shared among multiple IP Port Configuration Data managed entities. If there are more IP Port Configuration Data managed entities associated with these profile managed entities, the OLT may not request to delete them.

If applicable, the OLT can delete the corresponding History Data managed entities as well.



G.983.2\_FI.33

**Figure I.33/G.983.2 – Connection tear-down for IP router service connection**

### I.2.27 Addition of entries to IP static routes

The following scenario, Figure I.34, depicts addition of entities to the IP static routes managed entity for an ONT.




Figure I.34/G.983.2 – Addition of entities to the IP static routes

### I.2.28 Removal of entries from IP static routes

The following scenario, Figure I.35, depicts the removal of entries from the IP static routes managed entity for an ONT.




Figure I.35/G.983.2 – Removal of entries from IP static routes


## I.3 Common services with PON protection

In cases where PON protection is implemented, some of the common service scenarios given in clause I.2 must be modified or augmented to accommodate the protection function. The following subclauses describe these cases.

**I.3.1 OMCC establishment – protection side ranged after start-up of working side**

Figure I.36 shows the OMCI start-up sequence when only the working-side PON-LT is ranged during the initial phase. In the given figure, the assumption is made that the OLT and the ONT are both available for PON protection.

NOTE – When the OLT and the ONT do not support a common protection scenario (i.e., 1+1, 1:1 and extra traffic), the protection side is not used.




**Figure I.36/G.983.2 – Start-up scenario for sequential ranging of working and protection sides**

### I.3.2 OMCC establishment for simultaneous ranging of working and protection PON-LTs

Figure I.37 shows the OMCI start-up sequence when both working-side PON-LT and protection-side PON-LT are ranged simultaneously during the initial phase. In the given figure, the assumption is made that the OLT and the ONT are both available for PON protection.

NOTE – When the OLT and the ONT do not support a common protection scenario (i.e., 1+1, 1:1 and extra traffic), the protection side is not used.




G.983.2\_F1.37

**Figure I.37/G.983.2 – Start-up scenario for simultaneous ranging of working and protection sides**

**I.3.3 VP configuration for the ONT defined as 1+1 model**

Figure I.38 shows the VP configuration sequence for the 1+1 protection architecture.  
NOTE – The same VPI/VCI for the OMCC should be used for both working and protection sides.




**Figure I.38/G.983.2 – VP configuration for 1+1 ONT**



### I.3.4 VP configuration for the ONT defined as 1:1 model

Figure I.39 shows the VP configuration sequence for the 1:1 protection architecture.


NOTE – The same VPI/VCI for the OMCC should be used for both working and protection sides.



**Figure I.39/G.983.2 – VP configuration for 1:1 ONT**

**I.3.5 VP removal for 1+1 model ONT**


Figure I.40 shows the VP removal sequence for the 1+1 protection architecture.



**Figure I.40/G.983.2 – VP removal for 1+1 ONT**

### I.3.6 VP removal for a 1:1 model ONT

Figure I.41 shows the VP removal sequence for the 1:1 protection architecture.




G.983.2\_FI.41

**Figure I.41/G.983.2 – VP removal for 1:1 ONT**

**I.3.7 Switch-over sequence for a 1+1 model ONT**


Figure I.42 shows the switch-over sequence for the 1+1 protection architecture. In the given figure, the assumption is made that the working side's PON-LT detects Signal Fail (SF) or Signal Degrade (SD).



**Figure I.42/G.983.2 – Switch-over sequence for 1+1 ONT**

**I.3.8 Switch-over sequence for a 1:1 model ONT**

Figure I.43 shows the switch-over sequence for the 1:1 protection architecture. In the given figure, the assumption is made that the working side's PON-LT detects Signal Fail (SF) or Signal Degrade (SD).



**Figure I.43/G.983.2 – Switch-over sequence for 1:1 ONT**

## I.4 Common services with DBA support

The following scenarios describe the initial discovery of the DBA function, and the creation and deletion of a T-CONT in the ONT.

### I.4.1 Initial handshake

The scope of initial handshake is from ranging to acquisition of the information to be able to start the status reporting. Allocation of the divided\_slot grant and data grants and T-CONT configuration is described in clause I.4.2.

Figure I.44 shows the initial handshake procedure.





Figure I.44/G.983.2 – Initial handshake procedure

### I.4.2 Addition of T-CONT in an ONT


Figure I.45 shows the addition of T-CONT.



**Figure I.45/G.983.2 – T-CONT addition procedure**

**I.4.3 Deletion of T-CONT in an ONT**

Figure I.46 shows the deletion of T-CONT.



**Figure I.46/G.983.2 – Deletion of T-CONT**



## Appendix II

### OMCI message set

#### II.1 General remarks

##### II.1.1 Message type identifier

In 9.1.4, the message types are given. This identifier is omitted in the message set below.

##### II.1.2 Entity class identifier

In 9.1.6, the entity class identifiers are given. This identifier is omitted in the message set below.

##### II.1.3 Result and reason

Responses to commands can indicate the result of the command. A value of "null" will indicate that the command was processed successfully. Non-null values will indicate the reason of the failure. If the result was "failure", the rest of the message contents will be filled with all 0x00s. The definition of each result and reason is as follows:

0) *command processed successfully*

There are two functions for command processing: command interpretation and command execution. This result means that the received command, such as Get/Set/Test/Reboot, was properly interpreted by the ONT's command interpretation function without errors and that the interpreted command was successfully transferred to the ONT's command execution function.

1) *command processing error*

This result means the command processing failed at the ONT due to some reason not described by items 3, 4, etc.

2) *command not supported*

This result means that the message type indicated in Byte 8 is not supported by the ONT.

3) *parameter error*

This result means that the command message received by the ONT was errored.

4) *unknown managed entity*

This result means that the managed entity class indicated in Byte 10 is not supported by the ONT.

5) *unknown managed entity instance*

This result means that the managed entity instance indicated in Bytes 11 and 12 does not exist in the ONT.

6) *device busy*

This result means that the command could not be processed due to process-related congestion at the ONT.

7) *instance exists*

This result means that the ONT already has a managed entity instance that corresponds to the one the OLT is attempting to create.

8) *Reserved*

9) *attribute(s) failed or unknown*

This result means that an optional attribute is not supported by the ONT or that a mandatory/optional attribute could not be executed by the ONT, even if it is supported. In

conjunction with this result, attribute masks are used to indicate which attributes failed or were unknown.

The following two kinds of attribute masks are used when this result/reason is raised:

- *optional attribute mask coding*, which indicates whether or not the optional attribute is supported. Bytes 14 and 15 are assigned to this mask.
- *attribute execution mask coding*, which indicates whether or not the mandatory/optional attribute was executed. Bytes 16 and 17 are assigned to this mask.

If one or more optional attributes are not supported by the ONT, the "optional attribute mask coding" for each *unsupported* optional attribute becomes 1 while the corresponding "attribute execution mask coding" remains 0.

If one or more mandatory or optional attributes were not executed by the ONT, the "optional attribute mask coding" remains 0, while the "attribute execution mask coding" becomes 1 for each *failed* attribute."

#### II.1.4 Get, get response and set messages

For an attribute mask, a bitmap is used in the "Get", "Get Current Data", "Get response", "Get Current Data Response", and "Set" messages. This bitmap indicates which attributes are requested (Get, Get Current Data) or provided (Get response, Get Current Data Response, and Set). The bitmap is composed as follows (see Table II.1):

**Table II.1/G.983.2 – Attribute mask coding**

Byte	Bit							
	8	7	6	5	4	3	2	1
1	Attribute 1	Attribute 2	Attribute 3	Attribute 4	Attribute 5	Attribute 6	Attribute 7	Attribute 8
2	Attribute 9	Attribute 10	Attribute 11	Attribute 12	Attribute 13	Attribute 14	Attribute 15	Attribute 16

The attribute numbers correspond to the ordering of the attributes in clause 7. Note that the Managed Entity identifier, which is an attribute of each managed entity, has no corresponding bit in the attribute mask. Thus, the attributes are counted starting from the first attribute after the Managed Entity identifier.

#### II.1.5 Alarm notifications

The ONT will send this notification each time an alarm has changed status for the entity indicated in the message identifier. The message shows the status of *all* alarms of this entity. It is up to the OLT to determine which alarms changed status.

The maximum number of alarms that is supported by the OMCI is 240; thus, the alarm bitmap uses 30 bytes. The bitmap is composed as follows (see Table II.2):

**Table II.2/G.983.2 – Alarm mask coding**

Byte	Bit							
	8	7	6	5	4	3	2	1
1	Alarm 0	Alarm 1	Alarm 2	Alarm 3	Alarm 4	Alarm 5	Alarm 6	Alarm 7
2	Alarm 8	Alarm 9	Alarm 10	Alarm 11	Alarm 12	Alarm 13	Alarm 14	Alarm 15
...								
30	Alarm 232	Alarm 233	Alarm 234	Alarm 235	Alarm 236	Alarm 237	Alarm 238	Alarm 239

The alarm numbers correspond to the alarm coding in clause 7. Bits in the alarm bitmap that correspond to non-existing alarms shall always be set equal to "0". Bits that correspond to an existing alarm are set to a value of "0" to indicate that the corresponding alarm is cleared or a value of "1" to indicate that the alarm has been raised.

Alarm message sequence numbers can obtain values in the interval 1 to 255. Zero is excluded in order to make this counter similar to the MIB data sync counter.

## II.1.6 Test, test response, and test result

The descriptions below indicate how Test, Test response, and Test result are related.

**Test:** This message is used to initiate either a self test or an MLT test (or additional tests defined in future).

**Test response:** This message is an immediate reaction to a Test message. The "Test response" message reports the ability of the ONT to run the required test, but it does not contain any specific results.

**Test result:** This message is used to report the result of either a self test (requested by the OLT) or a MLT test (or additional test defined in future). In the case of an AUTONOMOUS self test, the Test result notification is not used. Instead, notification is sent to the OLT via an alarm ONLY if the managed entity fails its autonomous self test.

A test on a particular managed entity instance is invoked by sending a Test message to this instance. Each managed entity that supports tests needs to have an action "Test" defined for it. The type of test that is invoked by a Test message depends on the managed entity.

The "Test response" message is an indication to the OLT that the test request is received and is being processed. The results of a requested test will be sent to the OLT via a specific "Test result" message.

The "Test response" message will be sent immediately after the Test message is received (i.e., within the normal response time). The transaction identifier of the "Test response" message is identical to the transaction identifier of the Test message that requested the test.

## II.2 Message layout

### II.2.1 Create

It should be noted that the message contents for the "Create" message apply only to attributes that are "Set-by-create". Thus, byte 13 begins with the attribute value for the first Set-by-create attribute and so forth. If the message contains attributes that are not supported by the ONT, the ONT will ignore the attributes, but it must allocate the space in the message to maintain delineation of the attribute fields.

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = create
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance

Field	Byte	8	7	6	5	4	3	2	1	Comments
Message contents	13									attribute value of first Set-by-create attribute (size depending on the type of attribute)
										...
										attribute value of last Set-by-create attribute (size depending on the type of attribute)
	xx-45	0	0	0	0	0	0	0	0	padding

## II.2.2 Create response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = create
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy 0111 = instance exists
	14-45	0	0	0	0	0	0	0	0	padding

## II.2.3 Create complete connection

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = create complete connection
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13									MSB ani VP Network CTP <sub>B-PON</sub> or VC Network CTP <sub>B-PON</sub> instance
	14									LSB ani VP Network CTP <sub>B-PON</sub> or VC Network CTP <sub>B-PON</sub> instance

Field	Byte	8	7	6	5	4	3	2	1	Comments
Message contents	15									MSB uni VP Network CTP <sub>B-PON</sub> or VC Network CTP <sub>B-PON</sub> instance
	16									LSB uni VP Network CTP <sub>B-PON</sub> or VC Network CTP <sub>B-PON</sub> instance
	17									MSB uni/ani pointer (= MSB corresponding uni instance)
	18									LSB uni/ani pointer (= LSB corresponding uni instance)
	19									MSB vpi ani side
	20									LSB VPI ani side
	21									MSB VPI uni side (= 0x00)
	22									LSB VPI uni side
	23	0	0	0	0	0	y	x	x	direction/VP-VC choice xx : 01 = uni-to-ani 10 = ani-to-uni 11 = bidirectional y : 0 = create VP CTPs 1 = create VC CTPs
	24									MSB priority queue pointer ani VP Network CTP <sub>B-PON</sub>
	25									LSB priority queue pointer ani VP Network CTP <sub>B-PON</sub>
	26									MSB priority queue pointer uni VP Network CTP <sub>B-PON</sub>
	27									LSB priority queue pointer uni VP Network CTP
	28									padding
	29									padding
	30									MSB traffic descriptor profile pointer uni VP Network CTP <sub>B-PON</sub>
	31									LSB traffic descriptor profile pointer uni VP Network CTP <sub>B-PON</sub>
	32									MSB VCI ani side (if VC CTP)
	33									LSB VCI ani side (if VC CTP)
	34									MSB VCI uni side (if VC CTP)
	35									LSB VCI uni side (if VC CTP)
	36-45	0	0	0	0	0	0	0	0	padding

## II.2.4 Create complete connection response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = create complete connection
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14-45	0	0	0	0	0	0	0	0	padding

## II.2.5 Delete

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = delete
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13-45	0	0	0	0	0	0	0	0	padding

## II.2.6 Delete response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = delete
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance

Field	Byte	8	7	6	5	4	3	2	1	Comments
Message contents	13									result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14-45	0	0	0	0	0	0	0	0	padding

## II.2.7 Delete complete connection

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = delete complete connection
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13-45	0	0	0	0	0	0	0	0	padding

## II.2.8 Delete complete connection response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = delete complete connection
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14-45	0	0	0	0	0	0	0	0	padding

## II.2.9 Set

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = set
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13									MSB attribute mask
	14									LSB attribute mask
	15									attribute value of first attribute to set (size depending on the type of attribute)
										...
										attribute value of last attribute to set (size depending on the type of attribute)
	xx-45	0	0	0	0	0	0	0	0	padding

## II.2.10 Set response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = set
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy 1001 = attribute(s) failed or unknown
	14									"optional attribute" mask (attributes 1-8), used with "1001" encoding: 0 = default 1 = unsupported attribute
	15									"optional attribute" mask (attributes 9-16), used with "1001" encoding: 0 = default 1 = unsupported attribute



Field	Byte	8	7	6	5	4	3	2	1	Comments
Message contents	16									"attribute execution" mask (attributes 1-8), used with "1001" encoding: 0 = default 1 = failed attribute
	17									"attribute execution" mask (attributes 9-16), used with "1001" encoding: 0 = default 1 = failed attribute
	18-45	0	0	0	0	0	0	0	0	padding

### II.2.11 Get

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = get
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13									MSB attribute mask
	14									LSB attribute mask
	15-45	0	0	0	0	0	0	0	0	padding

### II.2.12 Get response

Note that the optional Attribute and Attribute Execution masks should always be assumed to be present, even if result code 0x1001 is not returned. There is a consideration of interoperability on this point. Some implementations do not assume the mask is always present (which is deprecated behaviour). Even in this case, it can be shown that no failure occurs.

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = get
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance

Field	Byte	8	7	6	5	4	3	2	1	Comments
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy 1001 = attribute(s) failed or unknown
	14									MSB attribute mask
	15									LSB attribute mask
	16									attribute value of first attribute included (size depending on the type of attribute)
										...
										attribute value of last attribute included (size depending on the type of attribute)
	xx-41	0	0	0	0	0	0	0	0	padding
	42									"optional attribute" mask (attributes 1-8), used with "1001" encoding: 0 = default 1 = unsupported attribute
	43									"optional attribute" mask (attributes 9-16), used with "1001" encoding: 0 = default 1 = unsupported attribute
	44									"attribute execution" mask (attributes 1-8), used with "1001" encoding: 0 = default 1 = failed attribute
	45									"attribute execution" mask (attributes 9-16), used with "1001" encoding: 0 = default 1 = failed attribute

### II.2.13 Get complete connection

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = get complete connection
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									Entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13-45	0	0	0	0	0	0	0	0	padding

## II.2.14 Get complete connection response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = get complete connection
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14									MSB ani VP Network CTP <sub>B-PON</sub> or VC Network CTP <sub>B-PON</sub> instance
	15									LSB ani VP Network CTP <sub>B-PON</sub> or VC Network CTP <sub>B-PON</sub> instance
	16									MSB uni VP Network CTP <sub>B-PON</sub> or VC Network CTP <sub>B-PON</sub> instance
	17									LSB uni VP Network CTP <sub>B-PON</sub> or VC Network CTP <sub>B-PON</sub> instance
	18									MSB uni/ani pointer (= msb corresponding uni instance)
	19									LSB uni/ani pointer (= lsb corresponding uni instance)
	20									MSB VPI ani side
	21									LSB VPI ani side
	22									MSB VPI uni side (= 0x00)
	23									LSB VPI uni side
	24	0	0	0	0	0	y	x	x	direction/VP-VC choice xx : 01 = uni-to-ani 10 = ani-to-uni 11 = bidirectional y : 0 = create VP CTPs 1 = create VC CTPs
	25									MSB priority queue pointer ani VP Network CTP <sub>B-PON</sub>
	26									LSB priority queue pointer ani VP Network CTP <sub>B-PON</sub>

Field	Byte	8	7	6	5	4	3	2	1	Comments
Message contents	27									MSB priority queue pointer uni VP Network CTP <sub>B-PON</sub>
	28									LSB priority queue pointer uni VP Network CTP <sub>B-PON</sub>
	29									padding
	30									padding
	31									MSB traffic descriptor profile pointer uni VP Network CTP <sub>B-PON</sub> or padding
	32									LSB traffic descriptor profile pointer uni VP Network CTP <sub>B-PON</sub> or padding
	33									MSB VCI ani side (if VC CTP)
	34									LSB VCI ani side (if VC CTP)
	35									MSB VCI uni side (if VC CTP)
	36									LSB VCI uni side (if VC CTP)
	37-45	0	0	0	0	0	0	0	0	padding

## II.2.15 Get all alarms

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = get all alarms
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = ONT Data
	11	0	0	0	0	0	0	0	0	MSB entity instance
	12	0	0	0	0	0	0	0	0	LSB entity instance
Message contents	13-45	0	0	0	0	0	0	0	0	padding

## II.2.16 Get all alarms response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = get all alarms
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = ONT Data
	11	0	0	0	0	0	0	0	0	MSB entity instance
	12	0	0	0	0	0	0	0	0	LSB entity instance
Message contents	13									MSB of the number of subsequent commands
	14									LSB of the number of subsequent commands
	15-45	0	0	0	0	0	0	0	0	padding

## II.2.17 Get all alarms next

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = get all alarms next
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = ONT Data
	11	0	0	0	0	0	0	0	0	MSB entity instance
	12	0	0	0	0	0	0	0	0	LSB entity instance
Message contents	13									MSB of the command sequence number
	14									LSB of the command sequence number
	15-45	0	0	0	0	0	0	0	0	padding

The command sequence numbers shall start from 0x00 onwards.

## II.2.18 Get all alarms next response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = get all alarms next
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = ONT Data
	11	0	0	0	0	0	0	0	0	MSB entity instance
	12	0	0	0	0	0	0	0	0	LSB entity instance
Message contents	13									entity class on which the alarms are reported
	14									MSB entity instance on which the alarms are reported
	15									LSB entity instance on which the alarms are reported
	16-45	x	x	x	x	x	x	x	x	bitmap alarms

The bitmap that is used in the Get All Alarms Next response for a given managed entity class is identical to the bitmap that is used in the alarm notifications for that managed entity class.

In the case the ONT has received an Get All Alarms Next request message in which the command sequence number is out of range, the ONT shall respond with a message in which bytes 13 to 45 are all set to 0x00. This corresponds to a response with entity class 0x00, entity instance 0x0000, and bitmap all 0x00s.

## II.2.19 MIB upload

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = MIB upload
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = ONT Data
	11	0	0	0	0	0	0	0	0	MSB entity instance
	12	0	0	0	0	0	0	0	0	LSB entity instance
Message contents	13-45	0	0	0	0	0	0	0	0	padding

## II.2.20 MIB upload response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = MIB upload
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = ONT Data
	11	0	0	0	0	0	0	0	0	MSB entity instance
	12	0	0	0	0	0	0	0	0	LSB entity instance
Message contents	13									MSB of the number of subsequent commands
	14									LSB of the number of subsequent commands
	15-45	0	0	0	0	0	0	0	0	padding

## II.2.21 MIB upload next

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = MIB upload next
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = ONT Data
	11	0	0	0	0	0	0	0	0	MSB entity instance
	12	0	0	0	0	0	0	0	0	LSB entity instance
Message contents	13									MSB of the command sequence number
	14									LSB of the command sequence number
	15-45	0	0	0	0	0	0	0	0	padding

The command sequence numbers shall start from 0x00 onwards.

## II.2.22 MIB upload next response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = MIB upload next
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = ONT Data
	11	0	0	0	0	0	0	0	0	MSB entity instance
	12	0	0	0	0	0	0	0	0	LSB entity instance
Message contents	13									entity class of object
	14									MSB entity instance of object
	15									LSB entity instance of object
	16									MSB attribute mask
	17									LSB attribute mask
	18									value of first attribute (size depending on the type of the attribute)
										...
										value of the last attribute (size depending on the type of the attribute)
	xx-45	0	0	0	0	0	0	0	0	padding

If the ONT receives a MIB Upload Next request message in which the command sequence number is out of range, it shall respond with a message in which bytes 13 to 45 are all set to 0x00. This corresponds to a response with entity class 0x00, entity instance 0x0000, attribute mask 0x0000, and padding from byte 18 to byte 45.

Note that, if all attributes of a managed entity do not fit within one MIB Upload Next response message, the attributes will be split over several messages. The OLT can use the information in the attribute mask to determine which attribute values are reported in which MIB upload Next response message.

## II.2.23 MIB reset

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = MIB reset
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = ONT Data
	11	0	0	0	0	0	0	0	0	MSB entity instance
	12	0	0	0	0	0	0	0	0	LSB entity instance
Message contents	13-45	0	0	0	0	0	0	0	0	padding

## II.2.24 MIB reset response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = MIB reset
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = ONT Data
	11	0	0	0	0	0	0	0	0	MSB entity instance
	12	0	0	0	0	0	0	0	0	LSB entity instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14-45	0	0	0	0	0	0	0	0	padding

## II.2.25 Alarm

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	0						DB = 0, AR = 0, AK = 0 bits 5-1: action = alarm
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13									alarm mask
										...
	42									alarm mask
	43-44	0	0	0	0	0	0	0	0	padding
	45									alarm sequence number



## II.2.26 Attribute value change

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	0						DB = 0, AR = 0, AK = 0 bits 5-1: action = attribute value change
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13									MSB attribute mask
	14									LSB attribute mask
	15									attribute value of first attribute changed (size depending on the type of attribute)
										...
										attribute value of last attribute changed (size depending on the type of attribute)
	xx-45	0	0	0	0	0	0	0	0	padding

## II.2.27 Test

The format of the test message is specific to the target entity class. At present, two formats are defined. Future test extensions for a given entity class can be supported by adding additional encodings to presently unused bits or bytes. Future specification of tests for other entity classes may use an existing format or may define new formats for the test message. These extension mechanisms allow future tests to be supported without changing the principle of operation.

*Format for ONTb-pon, ONUb-pon, subscriber line card, PON line card entity classes*

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = test
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									Entity class NOTE – This format applies to entity classes ONTb-pon, ONUb-pon, subscriber line card, PON line card.
	11									MSB entity instance
	12									LSB entity instance
	13	0	0	0	0	x	x	x	x	xxxx = select test 0111 = self test
	14-45	0	0	0	0	0	0	0	0	Padding

*Format for POTS UNI and PPTP ISDN UNI entity classes*

Note that a single message can be used to initiate multiple tests on a given ME if desired.

Bytes 14-27 are used by the dial tone make-break test. A zero value for a timer causes the ONT to use its built-in defaults. As many as three dial tone frequencies can be specified, or omitted by setting their values to 0. Other fields are also omitted with the value 0, or controlled by flags. An ONT can support the dial tone test with internal defaults only, and is not required to support any of the attributes of bytes 14-27. Likewise, an ONT can use internal defaults for drop test, rather than the values given in bytes 28-37. The capabilities of an ONT are documented by the vendor and known through the administration's practices.

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = test
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									Entity class NOTE – This format applies to entity classes PPTP POTS UNI and PPTP ISDN UNI.
	11									MSB entity instance
	12									LSB entity instance
	13	a	0	0	0	x	x	x	x	a – test mode 0 = normal; deny test if line busy 1 = forced mode xxxx = select test 0000 = all MLT tests 0001 = hazardous potential 0010 = foreign EMF 0011 = resistive faults 0100 = receiver off-hook 0101 = ringer 0110 = NT1 dc signature test 0111 = self test 1000 = dial tone make-break test
	14									DBDT timer T1 (slow dial tone threshold), in units of 0.1 seconds. Range 0.1 to 6.0 seconds.
	15									DBDT timer T2 (no dial tone threshold), in units of 0.1 seconds. Range 1.0 to 10.0 seconds.
	16									DBDT timer T3 (slow break dial tone threshold), in units of 0.1 seconds. Range 0.1 to 3.0 seconds.
	17									DBDT timer T4 (no break dial tone threshold), in units of 0.1 seconds. Range 1.0 to 3.0 seconds.
	18							d	p	DBDT control byte d: dialed digit 1 = dialed digit specified in byte 19 0 = use default digit p = pulse (1) or tone (0) dialing

Field	Byte	8	7	6	5	4	3	2	1	Comments
Message identifier	19									Digit to be dialed, ASCII character in range "0"-"9", "*", "#".
	20-21									Dial tone frequency 1, in units of Hz
	22-23									Dial tone frequency 2, in units of Hz. 0 = unused (i.e., if only one tone is specified)
	24-25									Dial tone frequency 3, in units of Hz. 0 = unused (i.e., if only one or two tones are specified)
	26									Dial tone power threshold, absolute value, 0.1 dB resolution, range [−]0.1 to [−]25.3 dBm0. E.g., −13 dBm0 = 0x82. 0x00 = unspecified
	27									Idle channel power threshold, absolute value, 1 dB resolution, range [−]1 to [−]90 dBm0. 0x00 = unspecified
	28									DC hazardous voltage threshold, absolute value, volts 0x00 = unspecified
	29									AC hazardous voltage threshold, volts RMS 0x00 = unspecified
	30									DC foreign voltage threshold, absolute value, volts 0x00 = unspecified
	31									AC foreign voltage threshold, volts RMS 0x00 = unspecified
	32									Tip-ground and ring-ground resistance threshold, kΩ 0x00 = unspecified
	33									Tip-ring resistance threshold, kΩ 0x00 = unspecified
	34-35									Ringer equivalence minimum threshold, in 0.01 REN units 0x00 = unspecified
	36-37									Ringer equivalence maximum threshold, in 0.01 REN units 0x00 = unspecified
	38-45	0	0	0	0	0	0	0	0	Padding

## II.2.28 Test response

If an ONT does not support all tests requested in byte 13 of the test message, it should not execute any test and should respond with result 0010, command not supported. If an ONT supports all of the requested tests but cannot support one or more of the explicitly specified threshold attributes, it should not execute any test and should respond with result 0011, parameter error. The test command could be re-issued with different thresholds or default thresholds, and would be expected to succeed.

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = test
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14-45	0	0	0	0	0	0	0	0	padding

The Test response message is an indication to the OLT that the test request is received and is being processed.

## II.2.29 Start software download

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = start software download
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = software image
	11									MSB entity instance 0 = ONT <sub>B-PON</sub> 1, 2, ..., 127 = UNI card 129, 130, ..., 255 = ANI card
	12	0	0	0	0	0	0	x	x	LSB entity instance 00 = first instance 01 = second instance
Message contents	13									window size – 1
	14-17									image size in bytes
	18-45	0	0	0	0	0	0	0	0	padding

## II.2.30 Start software download response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = start software download
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = software image
	11									MSB entity instance 0 = ONT <sub>B-PON</sub> 1, 2, ..., 127 = UNI card 129, 130, ..., 255 = ANI card
	12	0	0	0	0	0	0	x	x	LSB entity instance 00 = first instance 01 = second instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14									window size – 1
	15-45	0	0	0	0	0	0	0	0	padding

## II.2.31 Download section

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	x	0						DB = 0, AR = x, AK = 0 x = 0: no response expected (section within the window) x = 1: response expected (last section of a window) bits 5-1: action = sw download section
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = software image
	11									MSB entity instance 0 = ONT <sub>B-PON</sub> 1, 2, ..., 127 = UNI card 129, 130, ..., 255 = ANI card
	12	0	0	0	0	0	0	x	x	LSB entity instance 00 = first instance 01 = second instance
Message contents	13									download section number
	14-45									data

### II.2.32 Download section response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = sw download section
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = software image
	11									MSB entity instance 0 = ONT <sub>B-PON</sub> 1, 2, ..., 127 = UNI card 129, 130, ..., 255 = ANI card
	12	0	0	0	0	0	0	x	x	LSB entity instance 00 = first instance 01 = second instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14									download section number
	15-45	0	0	0	0	0	0	0	0	padding

### II.2.33 End software download

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = end software download
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = software image
	11									MSB entity instance 0 = ONT <sub>B-PON</sub> 1, 2, ..., 127 = UNI card 129, 130, ..., 255 = ANI card
	12	0	0	0	0	0	0	x	x	LSB entity instance 00 = first instance 01 = second instance
Message contents	13-16									CRC-32
	17-20									image size in bytes
	21-45	0	0	0	0	0	0	0	0	padding

## II.2.34 End software download response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = end software download
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = software image
	11									MSB entity instance 0 = ONT <sub>B-PON</sub> 1, 2, ..., 127 = UNI card 129, 130, ..., 255 = ANI card
	12	0	0	0	0	0	0	x	x	LSB entity instance 00 = first instance 01 = second instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully (CRC correct) 0001 = command processing error (CRC incorrect) 0010 = command not supported (not applicable) 0011 = parameter error (not applicable) 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14-45	0	0	0	0	0	0	0	0	padding

## II.2.35 Activate image

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = activate image
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = software image
	11									MSB entity instance 0 = ONT <sub>B-PON</sub> 1, 2, ..., 127 = UNI card 129, 130, ..., 255 = ANI card
	12	0	0	0	0	0	0	x	x	LSB entity instance 00 = first instance 01 = second instance
Message contents	13-45	0	0	0	0	0	0	0	0	padding

## II.2.36 Activate image response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = activate image
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = software image
	11									MSB entity instance 0 = ONT <sub>B-PON</sub> 1, 2, ..., 127 = UNI card 129, 130, ..., 255 = ANI card
	12	0	0	0	0	0	0	x	x	LSB entity instance 00 = first instance 01 = second instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14-45	0	0	0	0	0	0	0	0	padding

## II.2.37 Commit image

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = commit image
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = software image
	11									MSB entity instance 0 = ONT <sub>B-PON</sub> 1, 2, ..., 127 = UNI card 129, 130, ..., 255 = ANI card
	12	0	0	0	0	0	0	x	x	LSB entity instance 00 = first instance 01 = second instance
Message contents	13-45	0	0	0	0	0	0	0	0	padding



## II.2.38 Commit image response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = commit image
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class = software image
	11									MSB entity instance 0 = ONT <sub>B-PON</sub> 1, 2, ..., 127 = UNI card 129, 130, ..., 255 = ANI card
	12	0	0	0	0	0	0	x	x	LSB entity instance 00 = first instance 01 = second instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14-45	0	0	0	0	0	0	0	0	padding

## II.2.39 Synchronize time

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = synchronize time
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13-45	0	0	0	0	0	0	0	0	padding

## II.2.40 Synchronize time response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = synchronize time
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13									Result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14-45	0	0	0	0	0	0	0	0	padding

## II.2.41 Reboot

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = reboot
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13-45	0	0	0	0	0	0	0	0	padding

## II.2.42 Reboot response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = reboot
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13									result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14-45									padding

## II.2.43 Get next

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = get next
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13									MSB attribute mask
	14									LSB attribute mask
	15									MSB of the command sequence number
	16									LSB of the command sequence number
	17-45	0	0	0	0	0	0	0	0	padding

The command sequence numbers shall start from 0x00 onwards.

## II.2.44 Get next response

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = get next
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy
	14									MSB attribute mask
	15									LSB attribute mask
	16									attribute value of first attribute included (size depending on the type of attribute)
										...
										attribute value of last attribute included (size depending on the type of attribute)
	xx-45	0	0	0	0	0	0	0	0	padding

If the ONT receives a "Get next request" message in which the command sequence number is out of range, the ONT shall respond with a message in which bytes 13 to 45 are all set to 0x00. This corresponds to a response with entity class 0x00, entity instance 0x0000, attribute mask 0x0000, and padding from byte 16 to byte 45.

## II.2.45 Test result

The test result message is used to report the result of a test. The transaction identifier of the test result message is identical to the transaction identifier of the test message that initiated the corresponding test.

Two formats are currently defined, one of which reports the result of a self test (any ME that supports self test), the other of which reports the results of a dial tone draw-break test (PPTP POTS UNI) or an MLT test (PPTP POTS UNI or PPTP ISDN UNI). If a new test for the presently-supported entities is defined in the future, the corresponding test results can be reported by extending the test result message layout. If a new test for other managed entity classes is defined in the future, a new test result message layout may be defined.

*Format for ONTb-pon, ONUb-pon, subscriber line card, PON line card entity classes*

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	0						DB = 0, AR = 0, AK = 0 bits 5-1: action = test result
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class. NOTE – This message format pertains to ONTb-pon, ONUb-pon, subscriber line card, PON line card entity classes.
	11									MSB entity instance
	12									LSB entity instance
Message contents	13	0	0	0	0	0	0	0	0	Unused
	14	0	0	0	0	0	0	x	x	self test result: xx = 00: failed xx = 01: passed xx = 10: not completed
	15-45	0	0	0	0	0	0	0	0	padding

*Format for POTS UNI and PPTP ISDN UNI entity classes*

Byte 13 reports a summary MLT test result. The result for each test category is limited to the two values "test passed or was not executed" or "test failed." Bytes 15 and 16 report the results of a dial tone test.

Byte 14 reports the result of a self test. At present, self test is not supported for the POTS UNI and PPTP ISDN UNI entity classes, and this byte should be set to 0.

There are four possible outcomes for a given test – it can pass, fail, not be run, or not be recognized by the ONT. If an ONT does not support or recognize a given test, it is expected to deny the test request message. To avoid physical damage, an ONT may cease testing if a test fails, and thus some subsequent test will not be run. In addition, the ONT may support some but not all tests of a given suite, such as power measurements in the dial tone test sequence. The category summary in byte 13 includes two values. The value 1 indicates either that all tests in a category passed or that nothing in the category was tested, while 0 indicates that at least one test in the category failed. Further information appears in flags specific to each test results attribute to indicate whether each detailed test was run or not, whether it passed or failed and whether a measured result is reported or not.

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	0						DB = 0, AR = 0, AK = 0 bits 5-1: action = test result
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class. NOTE – This message format pertains to PPTP POTS UNI and PPTP ISDN UNI entity classes.
	11									MSB entity instance

Field	Byte	8	7	6	5	4	3	2	1	Comments
Message identifier	12									LSB entity instance
Message contents	13	0	0	a	b	c	d	e	f	MLT drop test result: 0 = fail test a/b/c/d/e/f 1 = pass test, or test not run  a/b/c/d/e/f a = hazardous potential b = foreign EMF c = resistive faults d = receiver off-hook e = ringer f = NT 1 dc signature test
	14	0	0	0	0	0	0	x	x	self test result: xx = 00: failed xx = 01: passed xx = 10: not completed
	15			b	b	b	d	d	d	Dial tone make-break flags: ddd – Dial tone draw = 000 test not run = 01m failed, could not draw = 10m slow draw = 11m passed  bbb – Dial tone break = 000 test not run = 01m failed, could not break = 10m slow break = 11m passed  m – measured value flag = 0 measurement not reported = 1 measurement reported
	16			a	a	a	b	b	b	Dial tone power flags: aaa – Quiet channel power bbb – Dial tone power See Note.
	17			a	a	a	b	b	b	Loop test DC voltage flags aaa – VDC, tip-ground bbb – VDC, ring-ground See Note.
	18			a	a	a	b	b	b	Loop test AC voltage flags aaa – VAC, tip-ground bbb – VAC, ring-ground See Note.
	19			a	a	a	b	b	b	Loop test resistance flags 1 aaa – Resistance, tip-ground bbb – Resistance, ring-ground See Note.

Field	Byte	8	7	6	5	4	3	2	1	Comments
Message identifier	20			a	a	a	b	b	b	Loop test resistance flags 2 aaa – Resistance, tip-ring bbb – Ringer load test See Note.
	21									Time to draw dial tone, in 0.1 second units. Valid only if byte 15 ddd = xx1.
	22									Time to break dial tone, in 0.1 second units. Valid only if byte 15 bbb = xx1.
	23									Total dial tone power measurement, unsigned absolute value, 0.1 dB resolution, range 0 to [–]25.5 dBm0. Values above 0 dBm0 are reported as 0. Valid only if byte 16 bbb = xx1.
	24									Quiet channel power measurement, unsigned absolute value, 1 dB resolution, range 0 to [–]90 dBm0. Valid only if byte 16 aaa = xx1.
	25-26									Tip-ground DC voltage, 2's complement, resolution 1V. Valid only if byte 17 aaa = xx1.
	27-28									Ring-ground DC voltage, 2's complement, resolution 1V. Valid only if byte 17 bbb = xx1.
	29									Tip-ground AC voltage, Vrms. Valid only if byte 18 aaa = xx1.
	30									Ring-ground AC voltage, Vrms. Valid only if byte 18 bbb = xx1.
	31-32									Tip-ground DC resistance, kOhm. Infinite resistance: 0xffff. Valid only if byte 19 aaa = xx1.
	33-34									Ring-ground DC resistance, kOhm. Infinite resistance: 0xffff. Valid only if byte 19 bbb = xx1.
	35-36									Tip-ring DC resistance, kOhm. Infinite resistance: 0xffff. Valid only if byte 20 aaa = xx1.
	37									Ringer equivalence, in 0.1 REN units. Valid only if byte 20 bbb = xx1.
	38-45	0	0	0	0	0	0	0	0	padding
<p>NOTE – Coding for 3 bit flag sets is as follows:</p> <ul style="list-style-type: none"> <li>= 000 test not run</li> <li>= 010 fail, measurement not reported</li> <li>= 011 fail, measurement reported</li> <li>= 110 pass, measurement not reported</li> <li>= 111 pass, measurement reported</li> </ul>										

## II.2.46 Get current data

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	1	0						DB = 0, AR = 1, AK = 0 bits 5-1: action = get current data
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13									MSB attribute mask
	14									LSB attribute mask
	15-45	0	0	0	0	0	0	0	0	padding

## II.2.47 Get current data response

Note that the optional Attribute and Attribute Execution masks should always be assumed to be present, even if result code 0x1001 is not returned. There is a consideration of interoperability on this point. Some implementations do not assume the mask is always present (which is deprecated behaviour). Even in this case, it can be shown that no failure occurs.

Field	Byte	8	7	6	5	4	3	2	1	Comments
Transaction identifier	6-7									
Message type	8	0	0	1						DB = 0, AR = 0, AK = 1 bits 5-1: action = get current data
Device identifier type	9	0	0	0	0	1	0	1	0	OMCI = 0x0A
Message identifier	10									entity class
	11									MSB entity instance
	12									LSB entity instance
Message contents	13	0	0	0	0	x	x	x	x	result, reason 0000 = command processed successfully 0001 = command processing error 0010 = command not supported 0011 = parameter error 0100 = unknown managed entity 0101 = unknown managed entity instance 0110 = device busy 1001 = attribute(s) failed or unknown
	14									MSB attribute mask
	15									LSB attribute mask
	16									attribute value of first attribute included (size depending on the type of attribute)
										...
										attribute value of last attribute included (size depending on the type of attribute)
	xx-41	0	0	0	0	0	0	0	0	padding



Field	Byte	8	7	6	5	4	3	2	1	Comments
Message contents	42									"optional attribute" mask (attributes 1-8), used with "1001" encoding: 0 = default 1 = unsupported attribute
	43									"optional attribute" mask (attributes 9-16), used with "1001" encoding: 0 = default 1 = unsupported attribute
	44									"attribute execution" mask (attributes 1-8), used with "1001" encoding: 0 = default 1 = failed attribute
	45									"attribute execution" mask (attributes 9-16), used with "1001" encoding: 0 = default 1 = failed attribute

## Appendix III

### Support of F4/F5 maintenance flows in the ONT

#### III.1 General principle

The general principle regarding F4 and F5 maintenance flows in the ONT is to use the ITU-T Rec. I.610 [8] procedures wherever possible and to restrict the OMCI requirements to the strictly essential ones. The use of these procedures is largely independent of OMCI. The objective of this appendix is to clarify OMCI-related aspects.

#### III.2 Definition of the F4/F5 segment and end-to-end applicability

##### III.2.1 Support of F4/F5 maintenance flows with respect to ATM-UNIs

###### Segment F4 maintenance flow

The ONT always behaves as a Segment end point for the F4 segment maintenance flow towards the OLT.

The VP Network CTP<sub>B-PON</sub> located at the UNI side is by default the Segment end point.

###### End-to-end F4 maintenance flow

By definition the ONT is not involved.

###### Segment F5 and end-to-end F5 maintenance flows

By definition the ONT is not involved.

##### III.2.2 Support of F4/F5 maintenance flows with respect to non-ATM-UNIs

###### Segment F4 and end-to-end F4 maintenance flow

The ONT always behaves as a segment end point for the F4 Segment and End-to-end maintenance flow towards the OLT.

The VP Network CTP<sub>B-PON</sub> that supports the Interworking VCC Termination Point is by default the Segment end point.

### **Segment F5 and end-to-end F5 maintenance flows**

The ONT always behaves as a segment end point for the F5 Segment and End-to-end maintenance flow towards the OLT.

The Interworking VCC Termination Point is by default a Segment and End-to-end point.

## **III.3 OMCI support of F4/F5 flows in the ONT**

### **III.3.1 OMCI support of AIS and RDI fault management**

Report of End-to-end VP-AIS and VP-RDI, VC-AIS, VC-RDI receiving and generation alarms on the VP Network CTP<sub>B-PON</sub> and the Interworking VCC Termination Point respectively.

### **III.3.2 OMCI support of F4/F5 continuity check procedures**

The activation and deactivation of the Continuity Check from the OLT as well as towards the OLT is done via in-band ITU-T Rec. I.610 [8] activation and deactivation procedures. OMCI supports the reporting of Loss of Continuity alarm on the VP Network CTP<sub>B-PON</sub> and the Interworking VCC Termination Point.

### **III.3.3 OMCI support of F4/F5 loopback procedures**

The ONT supports loopback point functionality. The insertion of the loopback cell and the reporting of the loopback result are not required in the ONT. The OMCI supports setting of the loopback location identifier in selected PPTP entities described in 7.3.

### **III.3.4 OMCI support of F4/F5 performance monitoring**

The OMCI provides performance monitoring support via the performance monitoring managed entities. Creation of a PM entity will activate the PM feature, and deletion of the entity will deactivate the monitoring. In-band control and reporting of the PM features is not supported.

## Appendix IV

### Traffic management options

Depending on the trade-off between the complexity and the number of supported features, the ONT can have various traffic management options. Examples of traffic management implementation in the ONT are described in the following clauses. This appendix also indicates how the MIB defined in clause 7 is used for each implementation.

It should be pointed out that the ONT traffic management is not limited to these examples. ONT traffic management is likely a place where every vendor searches for a proprietary feature to give it a competitive advantage. However, every proprietary feature requires some kind of management that impacts the OMCI. In fact, it is difficult for the specification given in this Recommendation to keep up with the technological and feature innovations. It is envisioned that vendor-specific managed entities will be needed to manage the traffic management related functions in the ONT.

#### IV.1 Priority Queue<sub>B-PON</sub>

When the focus is on low complexity implementation, the ONT uses the priority controlled upstream traffic method. In this case, the ONT has no traffic contract or QoS awareness. The ONT is configured by the OLT with a priority for each connection for both directions.

Theoretically, UPC is needed at every multiplexing point, including the ONT. A system with the UPC function has to monitor the traffic volume entering the network from all active VP/VC connections to ensure that the agreed parameters are not violated and to deploy a cell discard or tag policy. In the priority queue implementation, the UPC function is moved to the OLT, where it protects the core network. The PON is protected by the "UPC-like" MAC. The MAC manages all connections from an ONT as a whole. Essentially, the MAC isolates ONTs from each other.

As such, CPEs sharing one ONT may have to regulate their own connection streams to maintain quality. A CPE sending out more cells on one connection will do so at the expense of the other connections established at the same ONT.

*OMCI requirements:*

The traffic management option in the ONT<sub>B-PON</sub> managed entity is set to 0x00.

*For the VP Network CTP<sub>B-PON</sub> at the ANI side:*

Priority Queue Pointer for Upstream: using priority Queue<sub>B-PON</sub> managed entity id.

## IV.2 Clarification of ONT functional blocks

Figures IV.1 and IV.2 show the ONT functional blocks for the ATM UNI case and for the non-ATM UNI case.






Figure IV.1/G.983.2 – ONT functional block diagrams for VC service



**Figure IV.2/G.983.2 – ONT functional block diagrams for VP service**


### IV.3 An example of the traffic scheduler configuration

An example of the configuration of the Traffic Scheduler is proposed in Figure IV.3. This model consists of three stages, such as 2 delay control and 1 guaranteed rate control stages. A delay control stage can be worked by Head Of the Line (HOL) scheduling. A guaranteed rate control stage can be worked by WRR.




**Figure IV.3/G.983.2 – Architectural model in ONT**

There are two operations using the above model, such as delay prioritized and guaranteed prioritized policies. These configurations can be shown in Figures IV.4 and IV.5.



**Figure IV.4/G.983.2 – Configuration of delay prioritized model**



**Figure IV.5/G.983.2 – Configuration of guaranteed rate prioritized model**

## Appendix V

### MAC addresses and Ether types

**Table V.1/G.983.2 – MAC address and Ether type for various protocols**

#	Protocol	MAC address	Ether type	Standard
1	IPv4 Multicast	0x01005E000000 ~ 0x01005E7FFFFFFF	–	RFC 1700 [B-15]
2	IPv6 Multicast	0x333300000000 ~ 0x3333FFFFFFFF	–	RFC 2464 [B-16]
3	IPv4 Broadcast	0xFFFFFFFF	0x0800	RFC 1700 [B-15]
4	RARP	0xFFFFFFFF	0x8035	RFC 1700 [B-15]
5	IPX	0xFFFFFFFF	0x8137	RFC 1700 [B-15]
		0x09001BFFFFFF, 0x09004E000002	–	
6	NetBEUI	0x030000000001	–	
7	AppleTalk	0xFFFFFFFF	0x809B, 0x80F3	RFC 1700 [B-15]
		0x090007000000 ~ 0x0900070000FC, 0x090007FFFFFF	–	
8	Bridge Management Information	0x0180C2000000 ~ 0x0180C20000FF	–	IEEE 802.1D [13]
9	ARP	0xFFFFFFFF	0x0806	RFC 1700 [B-15]
10	PPPoE Broadcast	0xFFFFFFFF	0x8863	RFC 2516 [B-17]


## Appendix VI

### Transparent support of video return path service

#### VI.1 Network overview

This clause considers support of the video return path. The following configurations are presented:

##### Configuration 1:




**Figure VI.1/G.983.2 – A B-PON with ONT transparent support of interactive video services**

In this type of configuration, the STB is Ethernet capable and can perform the TCP/IP protocols to configure itself and exchange information between the STB and the video control system.

The ONT transparently bridges the STB data to a BRAS which terminates the ATM layer and forwards the extracted Ethernet packets to the video control system.

This configuration requires no new B-PON Standardization

##### Configuration 2:



**Figure VI.2/G.983.2 – A B-PON interactive video services with external VRP adaptation**

In this configuration, the STB is compliant with SCTE 55-1/-2 and interfaces to an external VRP device that terminates the RF and performs the adaptation function from RF to Ethernet.


The interface between the ONT and the VRP device is Ethernet.

The ONT transparently bridges the STB data to a BRAS which terminates the ATM layer and forwards the extracted Ethernet packets to the video control system.

This configuration does not require new B-PON standardization.



### Configuration 3:



**Figure VI.3/G.983.2 – A B-PON interactive video services with internal VRP adaptation**

In this configuration, the STB is compliant with SCTE 55-1/-2 and interfaces to an internal VRP device that terminates the RF and performs the adaptation function from RF to Ethernet for input to the 802.1 D bridge in the ONT.

The ONT transparently bridges the STB data to a BRAS which terminates the ATM layer and forwards the extracted Ethernet packets to the video control system.

This configuration does not require new B-PON standardization.

## BIBLIOGRAPHY

- [B-1] ATM Forum AF-NM-0020.001 (1998), *M4 Interface Requirements and Logical MIB: ATM Network Element View*.
- [B-2] ATM Forum AF-PHY-0016.000 (1994), *DS1 Physical Layer Specification*.
- [B-3] ATM Forum AF-PHY-0064.000 (1996), *E1 Physical Interface Specification*.
- [B-4] ATM Forum AF-PHY-0029.000 (1995), *6312 kbit/s UNI Specification, Version 1.0*.
- [B-5] ATM Forum AF-PHY-0040.000 (1995), *Physical Interface Specification for 25.6 Mb/s over Twisted Pair Cable*.
- [B-6] ATM Forum AF-PHY-0034.000 (1995), *E3 Public UNI*.
- [B-7] ATM Forum AF-PHY-0054.000 (1996), *DS3 Physical Layer Interface Specification*.
- [B-8] ATM Forum AF-UNI-0010.002 (1994), *ATM User-Network Interface Specification, Version 3.1*.
- [B-9] ATM Forum AF-TM-0056.000 (1996), *Traffic Management Specification, Version 4.0*.
- [B-10] ATM Forum AF-VTOA-0113.000 (1999), *ATM Trunking using AAL 2 for Narrowband Services*.
- [B-11] ATM Forum AF-VMOA-0145.000 (2000), *Voice and Multimedia Over ATM-Loop Emulation Service Using AAL 2*.
- [B-12] ETSI TS 101 270-1 (1999-10), *Transmission and Multiplexing (TM); Access transmission systems on metallic access cables; Very high speed Digital Subscriber Line (VDSL); Part 1: Functional requirements*.
- [B-13] IETF RFC 815 (1982), *IP Datagram Reassembly Algorithms*.
- [B-14] IETF RFC 1213 (1991), *Management Information Base for Network Management of TCP/IP-based internets: MIB-II*.
- [B-15] IETF RFC 1700 (1994), *Assigned Numbers*.
- [B-16] IETF RFC 2464 (1998), *Transmission of IPv6 Packets over Ethernet Networks*.
- [B-17] IETF RFC 2516 (1999), *A Method for Transmitting PPP Over Ethernet (PPPoE)*.
- [B-18] IETF RFC 2662 (1999), *Definitions of Managed Objects for ADSL Lines*.
- [B-19] IETF RFC 3440 (2002), *Definitions of Extension Managed Objects for Asymmetric Digital Subscriber Lines*.
- [B-20] ITU-T Recommendation G.992.1 (1999), *Asymmetric digital subscriber line (ADSL) transceivers*.
- [B-21] ITU-T Recommendation G.992.2 (1999), *Splitterless asymmetric digital subscriber line (ADSL) transceivers*.
- [B-22] ITU-T Recommendation G.992.3 (2005), *Asymmetric digital subscriber line transceivers 2 (ADSL2)*.
- [B-23] ITU-T Recommendation G.992.4 (2002), *Splitterless asymmetric digital subscriber line transceivers 2 (splitterless ADSL2)*.
- [B-24] ITU-T Recommendation G.992.5 (2005), *Asymmetric digital subscriber line (ADSL) transceivers – Extended bandwidth ADSL2 (ADSL2+)*.

- [B-25] ITU-T Recommendation G.994.1 (2003), *Handshake procedures for digital subscriber line (DSL) transceivers*.
- [B-26] ITU-T Recommendation T.35 (2000), *Procedure for the allocation of ITU-T defined codes for non-standard facilities*.
- [B-27] IETF RFC 4069 (2005), *Definitions of Managed Object Extensions for Very High Speed Digital Subscriber Lines (VDSL) Using Single Carrier Modulation (SCM) Line Coding*.
- [B-28] IETF RFC 4070 (2005), *Definitions of Managed Object Extensions for Very High Speed Digital Subscriber Lines (VDSL) Using Multiple Carrier Modulation (MCM) Line Coding*.
- [B-29] DSL Forum TR-057 (2003), *VDSL Network Element Management*.





## SERIES OF ITU-T RECOMMENDATIONS

Series A	Organization of the work of ITU-T
Series D	General tariff principles
Series E	Overall network operation, telephone service, service operation and human factors
Series F	Non-telephone telecommunication services
<b>Series G</b>	<b>Transmission systems and media, digital systems and networks</b>
Series H	Audiovisual and multimedia systems
Series I	Integrated services digital network
Series J	Cable networks and transmission of television, sound programme and other multimedia signals
Series K	Protection against interference
Series L	Construction, installation and protection of cables and other elements of outside plant
Series M	Telecommunication management, including TMN and network maintenance
Series N	Maintenance: international sound programme and television transmission circuits
Series O	Specifications of measuring equipment
Series P	Telephone transmission quality, telephone installations, local line networks
Series Q	Switching and signalling
Series R	Telegraph transmission
Series S	Telegraph services terminal equipment
Series T	Terminals for telematic services
Series U	Telegraph switching
Series V	Data communication over the telephone network
Series X	Data networks, open system communications and security
Series Y	Global information infrastructure, Internet protocol aspects and next-generation networks
Series Z	Languages and general software aspects for telecommunication systems